



life.augmented

Using the Teseo-LIV3F/3R/3FL as an I2C positioning sensor

ADG/Positioning – Mar 2022



Introduction

- The Teseo-LIV3F/3R/3FL GNSS module embeds a 3rd generation of ST's single-die standalone positioning receiver ICs (Teseo III) able to work simultaneously on multiple constellations (GPS/Galileo/Glonass/BeiDou/QZSS).
- The Teseo-LIV3F/3R/3FL 's I2C interface emits the same NMEA stream available on its UART interface.
- The Host MCU should continuously poll the Teseo III GNSS IC's I2C bus to access real-time positioning data
- Certain applications only need to read the current position on-demand (with no interest in the NMEA stream) using the Teseo-LIV3F/3R/3FL as an I2C sensor (for example, as a gyroscope, accelerometer, etc)



The Host can use the \$PSTMNMEAREQUEST command to request on-demand only specific NMEA data based on a message-list-bitmap:

```
$PSTMNMEAREQUEST, <msg-low>, <msg-high>* <checksum>
```

Use case:

- Host requests the required NMEA message;
- Teseo-LIV3F/3R/3FL responds with the requested NMEA message;
- Host parses only the NMEA messages it wants (when it wants)



Prepare the module

Reset the I2C-MessageList

```
$PSTMCFGMSGL, 3, 1, 0, 0
```

```
$PSTMSAVEPAR
```

Disable echo-ing commands (CDB-ID 227[0])

```
$PSTMSETPAR, 1227, 1, 2
```

```
$PSTMSAVEPAR
```

Now the I2C-MessageList is empty.

This means than TeseoLIV-I2C_Readbuffer isn't filled with an autonomous NMEA message stream






Prepare the stm32cubemx project [1/4]

Using the **STM32CubeMX** graphical software configuration tool to configure your application

- 1 Enable I2C on PB9-PB8
- 2 Enable Blue-Button on PC13
- 3 Enable USART-2






Prepare the stm32cubemx project [2/4]

3 Enable Blue-Button Interrupt (EXTI interrupt)

A Open Configuration Tab

B Press NVIC button






Prepare the stm32cubemx project [3/4]

3 Enable Blue-Button Interrupt (EXTI interrupt)

C Enable EXTI IRQ handler

D Press OK button






Prepare the stm32cubemx project [4/4]

4 Generate the C initialization code

Now you can open your IDE.





Edit the C-Code

```
void Console_Write(uint8_t *string){  
    HAL_UART_Transmit(&huart2, string, strlen((char *)string), 1000);  
}
```

1

```
static volatile _read = 0;
```

```
void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)  
{  
    _read = 1;  
}
```

```
void app_main()  
{
```

```
    #define Teseo_I2C_7bits_Addr    0x3A  
    #define I2C_BUF_SIZE    180
```

```
    int i;  
    static const char *gpgga_msg = "$PSTMMMEAREQUEST,2,0\n\r";  
    static const char *gpgll_msg = "$PSTMMMEAREQUEST,10000,0\n\r";  
    char read_buf[I2C_BUF_SIZE];  
    Console_Write("Booting\n\r");
```

```
    while (1) {  
        HAL_I2C_DeInit(&hi2c1);  
        HAL_I2C_Init(&hi2c1);
```

```
        if (_read == 1) {  
            _read = 0;
```

```
            Console_Write("Sending commands...");
```

```
            HAL_I2C_Master_Transmit(&hi2c1, Teseo_I2C_7bits_Addr << 1, (uint8_t *)gpgll_msg, strlen(gpgll_msg), 2000);
```

```
            Console_Write(" got:... \n\r");
```

```
            for (read_buf[I2C_BUF_SIZE-1] = 0; read_buf[I2C_BUF_SIZE-1] != 0xff; ) {  
                HAL_I2C_Master_Receive(&hi2c1, Teseo_I2C_7bits_Addr << 1, read_buf, I2C_BUF_SIZE, 2000);  
  
                for (i = 0; i < I2C_BUF_SIZE; ++i)  
                    if (read_buf[i] != 0xff)  
                        HAL_UART_Transmit(&huart2, &read_buf[i], 1, 1000);  
            }  
  
            Console_Write("\n\r");
```

```
        }  
    }  
}
```

1 Blue-button Call-back

2 I2C-Write to request the message

3 I2C-Read to read the message





Run and final conclusion

1 Run and view result on a terminal emulator

2 Final conclusion:

- The Host MCU doesn't need to continuously poll the Teseo-LIV module
- The Host MCU can request any NMEA message it wants (when it wants)
- The Host MCU has to parse only the needed NMEA message

1

A screenshot of a terminal emulator window titled "COM45:115200baud - Tera Term VT". The window has a menu bar with "File", "Edit", "Setup", "Control", "Window", and "Help". The terminal output shows the following text:

```
Booting
Sending commands... got:...
$GPGLL,3726.50719,N,01503.61279,E,142926.000,A,D*50

Sending commands... got:...
$GPGLL,3726.50728,N,01503.61316,E,142930.000,A,D*5D

Sending commands... got:...
$GPGLL,3726.50728,N,01503.61316,E,142928.000,A,D*54
```