

WiFi Network: **STMicro**  
Password: **STMTTT19**



September 12th, 2019  
Santa Clara Convention Center - Mission City Ballroom  
Santa Clara, CA



# Agenda 2


## BlueTile (STEVAL-BCN002V1)

- Training Material Check/Installation Help
- ARM® Keil MDK Installation
- Introduction to Bluetooth® Low Energy
- BlueTile Development Kit
- ARM® Keil MDK License Installation
- Lab 1: Getting Started with BlueTile “Serial Terminal Test”
- Lab 2: Connecting to the ST BLE Sensor app
- Lab 3: LED characteristic
- Lab 4: Accelerometer embedded events detection
- Lab 5: 9-axis Acc+Gyro+Mag Sensor Data Fusion
- Lab 6: Cloud data logging on IBM Watson
- Lab 7: Bonus – Voice over BLE


WiFi Network: **STMicro**  
Password: **STMTTT19**

# BlueTile (STEVAL-BCN002V1B)

3



<http://www.st.com/bluetile>



The screenshot shows the product page for the STEVAL-BCN002V1B on the ST.com website. The page features the ST logo and 'life.augmented' tagline. A navigation bar includes links for Products, Applications, Tools & Software, About ST, Sample & Buy, Support & Community, and Login. The breadcrumb trail indicates the path: Evaluation Tools > Solution Evaluation Tools > Sensor Solution Eval Boards > STEVAL-BCN002V1B. The product title 'STEVAL-BCN002V1B' is displayed with an 'ACTIVE' status. Below the title, it is described as a 'BlueTile - Bluetooth LE enabled sensor node development kit'. A 'Download databrief' button is available. A notification box states 'This product is in stock in our e-store' with a 'Sample and buy' button. A tabbed interface at the bottom shows 'Overview' as the selected tab, with other tabs for 'Tools & Software', 'Resources', and 'Quality & Reliability'. The main content area describes the kit's features, including the STEVAL-BCN002V1 multi-sensor board based on the BlueNRG-2 SoC, and lists various sensors like accelerometer, gyroscope, magnetometer, pressure, humidity, Time-of-Flight, and microphone. It also mentions the CR2032 coin battery power source.

ST life.augmented

Products ▾ Search... Search

Contact Us English ▾

Products Applications Tools & Software About ST Sample & Buy Support & Community Login

Evaluation Tools > Solution Evaluation Tools > Sensor Solution Eval Boards > STEVAL-BCN002V1B >

STEVAL-BCN002V1B **ACTIVE** Print Save to MyST Share via Email

BlueTile - Bluetooth LE enabled sensor node development kit

Download databrief

This product is in stock in our e-store

Sample and buy

Overview Tools & Software Resources Quality & Reliability

The STEVAL-BCN002V1B Bluetooth LE enabled sensor node development kit features the STEVAL-BCN002V1 multi-sensor board based on BlueNRG-2 SoC Bluetooth Low Energy application processor. This sensor board has accelerometer, gyroscope, magnetometer, pressure, humidity, Time-of-Flight and microphone sensors, and is powered by a common CR2032 coin battery.

The sensor board communicates with a Bluetooth LE

<http://www.st.com/bluetile>

## Software Development Kit

The screenshot shows the STMicroelectronics website for the STEVAL-BCN002V1B product. The page includes a navigation bar with links for Products, Applications, Tools & Software, About ST, Sample & Buy, Support & Community, and Login. The breadcrumb trail indicates the path: Evaluation Tools > Solution Evaluation Tools > Sensor Solution Eval Boards > STEVAL-BCN002V1B. The product name STEVAL-BCN002V1B is displayed with an 'ACTIVE' status. Below the product name, it says 'BlueTile - Bluetooth LE enabled sensor node development kit'. A blue arrow points from the 'Tools & Software' tab in the navigation bar to the 'Evaluation Tool Software' link in the 'Quick links' section. Other links in the 'Quick links' section include 'Wireless Connectivity Software'. A 'Sample and buy' button is visible on the right side of the page.

Embedded Software

EVALUATION TOOL SOFTWARE >

WIRELESS CONNECTIVITY SOFTWARE >

[https://www.st.com/content/st\\_com/en/products/embedded-software/evaluation-tool-software/stsw-bluetile-dk.html](https://www.st.com/content/st_com/en/products/embedded-software/evaluation-tool-software/stsw-bluetile-dk.html)

STSW-BLUETILE-DK

ACTIVE

Print
 Save to MyST
 Share via Email

Software development kit for the BlueTile, including sensor data streaming over BLE, HID peripheral, Beacon, etc.

Get Software


Download databrief

Overview

Tools & Software

Resources

The STSW-BLUETILE-DK is based on STSW-BLUENRG1-DK evaluation SW package.




The STSW-BLUENRG1-DK package supports the BlueNRG-1 and BlueNRG-2 Bluetooth Low-Energy system-on-chip. This package includes a Wizard PC application to automatically generate the configuration header file needed for the BLE radio initialization. This package also includes BlueNRG-1 and BlueNRG-2 peripheral drivers and related examples, the BLE firmware stack together with the HAL (Hardware Abstraction Layer) and CryptoLib (Cryptographic Library).

The STSW-BLUETILE-DK supports the BlueTile platform. This package extends STSW-BLUENRG1-DK

<http://www.st.com/bluetile>

# Schematic Gerbers BOM



The screenshot shows the ST.com website interface. At the top, there is a search bar and navigation links. The main navigation bar includes 'Products', 'Applications', 'Tools & Software', 'About ST', 'Sample & Buy', 'Support & Community', and 'Login'. The breadcrumb trail indicates the path: 'Evaluation Tools > Solution Evaluation Tools > Sensor Solution Eval Boards > STEVAL-BCN002V1B >'. The product name 'STEVAL-BCN002V1B' is displayed with an 'ACTIVE' status. Below the product name, there are links for 'Print', 'Save to MyST', and 'Share via Email'. A 'Download databrief' button is visible. A blue arrow points from this button to the 'Resources' tab in the bottom navigation bar. The 'Resources' tab is active, showing a 'Quick links' section with links to 'Product Specifications', 'Bill of Materials', 'License Agreement', 'Presentations', 'Schematics', 'Board Manufacturing Specifications', and 'Brochures'. A 'Sample and buy' button is also present on the right side of the page.

# Companion ST BLE Sensor App

8



ON YOUR PHONE

- Look for “**ST BLE Sensor**” on the App Store or Google Play



Download on the  
**App Store**





GET IT ON  
**Google Play**

# Where to Get It


9



## Sample & Buy

Part Number ⌵	Marketing Status ⌵	Budgetary Price (US\$) * ⌵	Quantity ⌵	Core Product ⌵	ECCN (US) ⌵	Country of Origin ⌵	Order from Distributors ⌵	Order from ST ⌵
STEVAL- BCN002V1B	ACTIVE	50.0	1	BlueNRG-2, BALF-NRG- 02D3, LSM6DSO, LIS2MDL, VL53L1X, MP34DT05TR-A, LPS22HH, HTS221	5A992C	ITALY	 Check Availability	 Buy direct


# Where to Get It

10

[Contact Mouser \(USA\) \(800\) 346-6873](#) | [Feedback](#)Change Location  [English](#) [US](#)


[Products](#) [Manufacturers](#) [Technical Resources](#) [Services & Tools](#) [Help](#) [Order History](#) [Log In](#) [Register](#)  0

All ▾





☐ In Stock

☐ RoHS

[All Products](#) > [Embedded Solutions](#) > [Engineering Tools](#) > [Sensor Development Tools](#) > [Multiple Function Sensor Development Tools](#) > [STMicroelectronics STEVAL-BCN002V1B](#) See an Error?




**STEVAL-BCN002V1B**




[Enlarge](#)

Images are for reference only  
See Product Specifications

[Share](#)

<b>Mouser #:</b>	511-STEVAL-BCN002V1B
<b>Mfr. #:</b>	STEVAL-BCN002V1B
<b>Mfr.:</b>	<a href="#">STMicroelectronics</a>
<b>Customer #:</b>	<input type="text" value="Customer #"/>
<b>Description:</b>	Multiple Function Sensor Development Tools BlueNRG-Tile - Bluetooth LE enabled sensor node development kit
<b>Lifecycle:</b>	 <b>New Product:</b> New from this manufacturer.
<b>Datasheet:</b>	 <a href="#">STEVAL-BCN002V1B Datasheet</a>
<b>More Information:</b>	<a href="#">Learn more about STMicroelectronics STEVAL-BCN002V1B</a>
<b>Shipping Alert:</b>	 This product may require additional documentation to export from the United States.


**In Stock: 49**

<b>Stock:</b>	49 Can Ship Immediately
<b>On Order:</b>	30 <a href="#">View Delivery Dates</a>
<b>Factory Lead-Time:</b>	11 Weeks
<b>Enter Quantity:</b>	Minimum: 1 Multiples: 1 <input type="text"/> <div></div>

**Pricing (USD)**


Qty.	Unit Price	Ext. Price
1	\$50.00	\$50.00

**NEWEST PRODUCTS**  
**STMICROELECTRONICS**



**STEVAL-BCN002V1B BlueTile Development Kit**[➔](#)

<https://my.st.com/ols>



Products ▾ Search... Search

Contact Us English ▾

Products Applications Tools & Software About ST

Sample & Buy Support & Community Login

Welcome back!

Enter your e-mail address and password to login your myST user.

E-mail address

Password

☐ Remember me on this computer. ⓘ

Login


Forgot password?

New user?

myST brings you a set of personalized features:

- Participate to ST Events
- Stay informed with ST eNewsletters
- Get help with ST Online Support
- Discuss on the ST Community
- Benefit from our Online Design Tools
- Download Software
- Order free samples
- Manage your weekly product updates
- Buy ST Products & Tools

Create Account



Support



Service Portal **New Request** RAF RIVA Logout

Case Id	Subject	Status	Creation Date	Last Update On
---------	---------	--------	---------------	----------------

No Cases found. Click on 'New Request' to create one.



Service Portal **New Request** RAF RIVA Logout

### Case Details

<b>Urgency*</b> Medium	<b>Project Name</b> Project Name
<b>Category*</b>	<b>Production Forecast (Qty)</b>
<b>Notify To</b> Please specify email addresses in the 'Description' or 'Comments' boxes to add people in copy of this request. This will be added by the Support Agent.	

### Case Description

<b>Product Category or ST Part Number</b> Enter atleast 3 characters.
<b>Subject*</b> Subject
<b>Description*</b> Type something

Insert the Part Num  
**STEVAL-BCN002V**






# Introduction to Bluetooth Low Energy

# Bluetooth® Evolution

14

- 20 Years in the market!
- 2009: Classic → BLE




# Bluetooth Low Energy (LE)

## Designed for Success


15

- Lower power than Bluetooth “Classic” (or Bluetooth 3.0)
  - Lower duty cycle
  - Faster connection
  - Lower peak power (relaxed RF parameters)
- Compatible with all major platforms (iOS, Android, Windows, Linux)
- Multiple network topologies:
  - Point to point: single master connects to single slave (and each slave can connect to 2 master)
  - Star: Multiple slaves connected to a single master
  - Mesh: introduced in the 2017
- State of the Art encryption, security including privacy/authentication



- **Generic Acces Profile**
  - How a device can discover and connect with one another
- **Generic Attribute Profile**
  - How services, characteristics can be discovered and then used
- **Attribute Protocol**
  - Protocol for discovering, reading, and writing attributes on a peer
- **Security Manager**
  - Handles the secure communication
- **L2CAP**
  - Protocol multiplexer. Segmentation and reassembly of packets
- **HCI**
  - Interface between Host and Controller
- **Link Layer**
  - Handles packets, channels, advertising, scanning & connections
- **Physical Layer**
  - Transmits/receives bits


- A **BLE Radio** is a **2.4 GHz ISM Band Transceiver**
- **40 RF Channels, 2 MHz Channel Spacing.** Two types of channels:
  - **Advertising channels (3 - orange)** for Advertising Packets. Used for Discoverability and for Broadcasting/Observing
  - **Data Channels (37 - blue)** for Data Packets. Used to send application data in Connection




- **GFSK Modulation**
  - $BT = 0.5$
  - Modulation Index = 0.5
  - “pulse shaping” Gaussian filter “smooths” transitions from zero to one reduces spectral width

# Protocol Stack - GAP

18




- Who controls the radio network?
  - **GAP (Generic Access Profile)**
  - Defines 4 roles
    - **Broadcaster**
    - **Observer**
    - **Peripheral**
    - **Central**



# Protocol Stack - GATT


20



- Who controls the data flow?
  - **GATT (Generic Attribute Profile)**
  - Defines 2 roles
    - **Server**
    - **Client**


## Server contains the data.

Receives requests, executes, responds.  
Can indicate value



Requests

Responses




## Client talks to the server.

Sends requests, wait for response.  
Can confirm indications

Protocol PDU Type	Sent by	Description
Request	Client	Client requests something from server (it always causes a response)
Response	Server	Server sends response to a request from a client
Command	Client	Client commands something to server (no response)
Notification	Server	Server notifies client of new value (no confirmation)
Indication	Server	Server indicates to client new value (it always causes a confirmation)
Confirmation	Client	Confirmation to an indication


- **Data are organized** and exposed as **attributes**
- Each attribute has:
  - A **handle**: it identifies the attribute on the server
  - A **type** (defined by Universal Unique ID - **UUID**): what the value means
    - 16-bit UUID: pre-defined by Bluetooth SIG
    - 128-bit UUID: Vendor Specific identifiers
  - A **value** (0 to 512 octets)
- Example

Each **Data** element in the Server is called **Attribute**



Handle	Type	Value
0x0009	«Device Name»	“Temperature Sensor”
0x0022	«Battery State»	0x04
0x0098	«Temperature»	0x0802

Source: Bluetooth® SIG



- A GATT Profile defines how attributes are organized and how the application can access them.
- Attributes are organized in Services and Characteristics

a typical example:

1 service: “ARG” (Angular Rate and Gravity)

2 characteristics: “Gyro”, “Acc”


Values: [0,-1,+2], [-10,+15,+950]



# ST BLE Devices



## BlueNRG-Tile



# BlueNRG-2 SoC at a Glance

26

The lowest power consumption




>3 years lifetime on CR2032(\*)  
59  $\mu$ A/MHz  
0.9  $\mu$ A sleep

Processing power on demand



Low-power architecture, Cortex-M0 @ 32 MHz

Flexible memory architecture



256 KB eFLASH  
24 KB ULL SRAM  
(with full SRAM data retention)

Optimized BLE Radio stack



70 KB FLASH  
8 KB RAM  
0.9uA with full RAM retention

Maximum security



ECC-256  
AES-128  
Factory UID  
Secure KEY



Seamless connection with SENSORS



Robust and Reliable BLE Link



Small form factor



Bluetooth 5.0 certified





Privacy 1.2 and secure connection 4.2




Faster and more reliable data transfer

# Bluetooth LE Programmable Processor

27




STEVAL-IDB008V2



STEVAL-BCN002V1B




# BlueTile Development Kit




# STEVAL-BCN002V1

29





Bottom view



# STEVAL-BCN002V1 Block Diagram


30

## Test points




# STEVAL-BCN002V1D

31




[https://www.st.com/content/st\\_com/en/products/embedded-software/evaluation-tool-software/stsw-bluetile-dk.html](https://www.st.com/content/st_com/en/products/embedded-software/evaluation-tool-software/stsw-bluetile-dk.html)



1. PC Applications
2. Documentation
3. Pre-built FW images
4. Low level drivers and BLE stack library
5. Virtual COM port drivers
6. Reference examples in source code
7. Utility section: IAR BlueNRG-2 Flasher

- Open the **Docs** folder



- Double click on **index.html**

- Device Datasheet
- BLE stack documentation
  - Release notes
  - APIs and events
  - Programming manual
- Device (and kits) documentation
  - PCB design guidelines
  - Bring up guide
  - Getting started



# Hands on Overview

- **Lab 1:** Getting started with STEVAL-BCN002V1 “Serial Terminal Test”
- **Lab 2:** Connecting to the ST BLE Sensor app
- **Lab 3:** LED characteristic
- **Lab 4:** Accelerometer embedded events detection
- **Lab 5:** 9-axis Acc+Gyro+Mag Sensor Data Fusion
- **Lab 6:** Cloud data logging on IBM Watson
- **Lab 7:** Voice over BLE




# Lab 1


## Getting Started with STEVAL-BCN002V1B “Serial Terminal Test”

# “Serial Terminal Test”

37




- **Plug** the BlueTile to the PC using the USB cable
- **Install** and **open Tera Term** and **configure** serial terminal



# Connect Your STEVAL-BCN002V1B to the PC Using USB

38





# Windows7: Allow the Driver Installation

39

1. Click on **Install driver software anyway**

2. Installation starts




If you have issue with the **STMicroelectronics Virtual COM Port** device driver installation here the **instructions** for installing the Virtual COM port driver:

**Win7**

**Win10**

# Tera Term Configuration 1/4

41



## 1. Select the **STMicroelectronics Virtual COM Port**

- **NOTE:** on **Win10 PC** the serial port is labeled just as “**COMxx**”

## 2. Click **OK**

# Tera Term Configuration 2/4

42

1. In **Setup** -> **Serial port...**

Set the following:

**Baud rate : 115200**


**Data : 8 bit**

**Parity : none**

**Stop : 1 bit**

**Flow control : none**

2. Click **OK**




# Tera Term Configuration 3/4

43

1. In **Setup -> Terminal...** set  
**New-line Receive :**  
**AUTO**

2. Click **OK**




# Tera Term Configuration 4/4

44

1. Click **Setup->Save setup...**

2. Click **Save**


1



...Done!

45

Push **SW1** button on the daughterboard



```
VT COM187 - Tera Term VT
File Edit Setup Control Window Help

# STEVAL-BCN002V1 #
Scan for sensors:
- Accelerometer and Gyroscope: OK
- Pressure and Temperature: OK
- Humidity and Temperature: OK
- Magnetometer: OK
- Proximity Sensor: OK
Sensor in low-power: OK
Battery voltage is 3270mV: OK
OTA update is NOT supported
Device 'BCN-002' discoverable with MAC: ff:29:b5:c6:ca:c9

```

- If you see the output above, **Tera Term** is now properly configured




# Lab 2

Connect to the ST BLE Sensor App

# Customize YOUR STEVAL-BCN002V1


47



**+ STEVAL-BCN002V1 DK  
Sensor Demo ref FW**




**Client**



# BLE\_SensorDemo Application

48

1. In the BlueTile SDK browse the following path: STEVAL-BCN002V1 DK 1.1.0\Project\BLE\_Examples




**The BLE\_SensorDemo  
embedded application is the  
main reference**

- **MDK: Microcontroller Development Kit**
  - Complete software development environment from Arm for a wide range of Arm Cortex-M based microcontroller devices.
  - MDK includes the **µVision IDE, debugger, and Arm C/C++ compiler**
- A **FREE** license is available for ST BlueNRG-2
  - Go **HERE** to get the free license!


# BLE\_SensorDemo Application

50



# Application Structure

51



**HW peripherals drivers and platform layer files**

**Application source code**

- Main

- ATTRIBUTE Database

- Application

**Hardware Abstraction Layer and sleep management**

**BLE Stack library – provided in binary format**

**Sensor Data Fusion library**

**Voice over BLE library**

# A Look at the Main Application

52

```
int main(void) {
```

```
    SystemInit();
```

**Remap the vector table and configure all the interrupts priority**

```
    SdkEvalIdentification();
```

**Identifies STEVAL or custom PCB**

```
    PlatformInit();
```

**HW peripherals initialization**

```
    BlueNRG_Stack_Initialization(&BlueNRG_Stack_Init_params);
```

**BLE stack initialization**

```
    Sensor_DeviceInit();
```

**Sensors initialization**

```
    Set_DeviceConnectable();
```

**Set device in advertising**

```
    while(1){
```

**Start of while loop**

```
        BTLE_StackTick();
```

**Advances the stack FSM**

```
        User_AppTick();
```

**Advances the application FSM. THIS IS DEVELOPERS USER SPACE!**

```
    } // end while(1)  
}
```

# BLE Flow on the LAB


53



Central



Peripheral



## Step 2: Scan

Master is in discovery mode looking for a specific slave to connect to

## Step 3: Connection request

## Step 4: Services & Chars discovery

Master (Client) starts the BLE Service and Characteristics discovery procedure to understand the Server ATT DB

Advertise

Advertise

Advertise

Connection request

Connection created

Service & Characteristics discovery

Notification

100msecs

Notification

## Step 1: Advertising

Slave is in Peripheral mode and sends ADV\_IND PDU

## Step 5: Data flow

Slave (Server) starts sending periodically (100 ms) to the master, **notifications packets** of sensors values (acc&gyro and pressure)

# Advertising and Scanning


54



Central




Peripheral



## Step 2: Scan

Master is in discovery mode looking for a specific slave to connect to

## Step 3: Connection request



## Step 1: Advertising

Slave is in Peripheral mode and sends ADV\_IND PDU

## Master:

needs an app for discovering the slave device in advertising

Off-the-shelf app: e.g.




LightBlue® Explorer


Custom app: e.g.



## LightBlue scan results



## ST BLE Sensor scan results



Why some devices are not present in the ST BLE Sensor app?


How devices will pop up in the ST BLE Sensor scan list?



# ST BlueMS Protocol

56

- In order to be connected to the **ST BLE Sensor** app, a BLE peripheral **SHALL** **comply** with a specific advertising packet format
- ST BlueMS protocol** specifies a **26-byte packet format** composed of Advertisement Types – **ADTypes** - compliant with BT SIG definitions



# BlueST SDK for Android and IOS

57

## Android


[https://github.com/stmicroelectronics-centrallabs/bluestsdk\\_android](https://github.com/stmicroelectronics-centrallabs/bluestsdk_android)

## Source code for iOS and Android

available online and maintained on GitHub repos

## iOS

[https://github.com/stmicroelectronics-centrallabs/bluestsdk\\_ios](https://github.com/stmicroelectronics-centrallabs/bluestsdk_ios)




The screenshot displays two GitHub repository pages side-by-side. The top page is for 'STMicroelectronics-CentralLabs / BlueSTSDK\_Android', which is described as a 'Bluetooth low energy Sensors Technology Software Development Kit (Android version)'. It shows 2 commits, 2 branches, 0 releases, and 1 contributor. The commit history includes an update to the README and initial commits for various files like BlueSTExample, BlueSTSDK, .gitignore, LICENSE, README.md, build.gradle, and settings.gradle. The bottom page is for 'STMicroelectronics-CentralLabs / BlueSTSDK\_iOS', described as the 'iOS version'. It also shows 2 commits, 2 branches, 0 releases, and 1 contributor. The commit history shows a recent fix for a parse error in the same characteristics and an initial commit for the LICENSE file.

# ST BLE Sensor Scan Results

58

Len	Type	Protocol version	Device ID	Feature Mask	Device MAC	Len	Type	Local Name
-----	------	------------------	-----------	--------------	------------	-----	------	------------




Each ST Platform is recognized by means of a **Device ID**  
(for STEVAL-BCN002V1 it is equal to **0x05**)

Users can distinguish their node from the **Local Name**



# Customize Your BlueTile

59



Modify the **local name** in the advertisement payload

1. In the file **sensor.c** go to **line 52**
2. “**BCN-002**” is the default local name value
3. You can modify it as you prefer with a 7-characters string



```
51  
52 #define DEFAULT_NAME_ALLMEMS  
53
```

```
'B','C','N','-','0','0','2'
```

# Build the New Code

61

1. Click on the **Build button** (top left corner) or hit **F7** on your keyboard
2. In the **Build Output** window (bottom) wait for the build to be completed.
  - **BLE\_SensorDemo.bin** created
  - “**0 Error(s), 0 Warning(s)**” message appear



# Programming Embedded Flash


62

## 1. **UART** Bootloader

- **ROM bootloader**. HW activation through dedicate pin (**DIO7**) configured for Boot
- **PC interface** named “**BlueNRG-1\_2 Flasher Utility**” available in the SW package


## 2. **SWD** interface + ST-LINK

- Interface with the STEVAL-BCN002V1 through the **20-pin JTAG connector**
- Same PC interface **BlueNRG-1\_2 Flasher**




# Flash Memory Layout 1/2

63



# Flash Memory Layout 2/2

64




# UART Bootloader: Use BlueNRG-2 Flasher Utility

65

- On st.com at this link:

[https://www.st.com/content/st\\_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrgflasher.html](https://www.st.com/content/st_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrgflasher.html)



**STSW-BNRGFLASHER** ACTIVE

BlueNRG-1, BlueNRG-2 Flasher utility

[Get Software](#) [Download databrief](#)

[Print](#) [Save to MyST](#) [Share via Email](#)

[Overview](#) [Resources](#)

The STSW-BNRGFLASHER is a standalone PC application which allows the BlueNRG-1, BlueNRG-2 devices Flash to be read, mass erased, written and programmed.



# Open the Flasher Utility

66

## 1. Go to

C:\Program Files (x86)\STMicroelectronics\BlueNRG-1\_2 Flasher Utility 3.0.0\Application


## 1. Double click on BlueNRG-1\_Flasher\_GUI.exe



# For HD Screens...If You've Problem with the Resolution


67

- **Right Click** on the .exe file and **select Properties**
- In the **Compatibility** tab **select** either **Disable display scaling...** or **Override high DPI scaling... → Application**





# BlueNRG Flasher Utility

68



UART


SWD



# Flash the BlueNRG-2 1/6

69

## 1. Select the COM port labeled (ST DK)



The screenshot shows the ST Flasher software interface. At the top, there are two tabs: 'UART' (selected) and 'SWD'. Below the tabs, there are two main sections. On the left, under the heading 'Actions', there are two checkboxes: 'Automatic Mode (only ST DK)' which is unchecked, and 'Verify' which is checked. On the right, under the heading 'List of COM Ports:', there is a list box containing one entry: 'COM91 (ST DK)'. This entry is selected, indicated by a checkmark in a small box to its left. A red rectangular box is drawn around the 'COM91 (ST DK)' entry in the list box.

# Flash the BlueNRG-2 2/6

70

## 1. Device Memory will populate with data

Device BlueNRG-2 (max flash address: 0x1007ffff)

Reading Memory COM91

100%

Device Memory COM91 Image File


Start Address 0x10040000 Size 0x3000 Read Write

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	ASCII
0x10040000	00	60	00	20	D9	07	04	10	35	06	04	10	3D	06	04	10	` Ù 5 =
0x10040010	AA	55	55	AA	00	00	00	00	00	00	00	00	00	00	00	00	ªUUª
0x10040020	00	00	00	00	00	00	00	00	00	00	00	00	45	06	04	10	E
0x10040030	00	00	00	00	00	00	00	00	4F	06	04	10	59	06	04	10	O Y

Log

```
16:10:30.632: Device COM91 -> Read Board Started
16:10:31.701: Device COM91 -> Read Board End
```


## 1. Select Mass Erase



# Flash the BlueNRG-2 4/6

72

1. Click on the **Select Image file** button




2. And **browse** the following **path**

STEWAL-BCN002V1 DK1.1.0 ▶ Project ▶ BLE\_Examples ▶ BLE\_SensorDemo ▶ MDK-ARM ▶ BlueNRG-2 ▶ LowerApp\_OTA ▶ Objects

# Flash the BlueNRG-2 5/6

73


1. **Select** the binary file (e.g. BLE\_SensorDemo\_LowerApp\_OTA.bin) and **click Open**
2. Insert the correct **start address** (e.g. 0x10040800 for Lower App)
3. **Click** on the **Flash** button




# Flash the BlueNRG-2 6/6

74

1. Flashing starts: **green bar** proceeding



2. **Wait** for the **pop-up** window and **click** on **OK**



# SWD: Use BlueNRG ST-LINK Utility


75


- On st.com at this link:


[https://www.st.com/content/st\\_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrg1stlink.html](https://www.st.com/content/st_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrg1stlink.html)

STSW-BNRG1STLINK

ACTIVE


 Print

 Save to MyST

 Share via Email

BlueNRG-1 ST-LINK utility for BlueNRG-1, BlueNRG-2 MCU

Get Software

 Download databrief

Overview


Resources

The BlueNRG-1 ST-LINK utility is a full-featured software interface for programming BlueNRG-1 and BlueNRG-2 devices.

# Programming Embedded Flash

76

## 1. SWD interface + ST-LINK



BlueNRG-1 ST-LINK Utility

File Edit View Target ST-LINK Help

Memory display

Address: 0x10040800 Size: 0x16FA8 Data Width: 32 bits

Device: BlueNRG-2  
Version ID: Ver 0  
Revision ID: Rev 0  
Flash size: 256KBytes

Device Memory @ 0x10040800 : Binary File

Target memory, Address range: [0x10040800 0x100577A8]

Address	0	4	8	C	ASCII
0x10040800	20006000	1004764D	10047931	10047933	. M v . 1 y . 3 y .
0x10040810	AA5555AA	424C5545	00000000	00000000	^ U U ^ E U L B . . . . .
0x10040820	00000000	00000000	00000000	10047935	. . . . . 5 y .
0x10040830	00000000	00000000	100474AF	10047939	. . . . . ^ t . 9 y .
0x10040840	10047959	100474B1	00000000	00000000	Y y . . ^ t . . . . .
0x10040850	100479B5	100474B3	100479C9	100474BF	^ y . . ^ t . . ^ y . . ^ t . .
0x10040860	00000000	00000000	00000000	00000000	. . . . .
0x10040870	00000000	100474C1	100474C3	100474C5	. . . . ^ t . . ^ t . . ^ t . .
0x10040880	00000000	100474B5	100474B7	100474B9	. . . . ^ t . . ^ t . . ^ t . .

03:43:03 : ST-LINK SN : 57FF70065088495348330487  
03:43:03 : ST-LINK Firmware version : V2J31S7  
03:43:03 : Connected via SWD.  
03:43:03 : SWD Frequency = 4,0 MHz.  
03:43:03 : Connection mode : Normal.  
03:43:03 : Debug in Low Power mode enabled.  
03:43:03 : Device : BlueNRG-2  
03:43:03 : Device family : BlueNRG-2  
03:43:03 : Device flash Size : 256KBytes

Debug in Low Power mode enabled. Device : BlueNRG-2 Core State : Live Update Disabled


# Open the ST BLE Sensor App

77



Launch the **ST BLE Sensor** app previously installed

Note: in the following slides all the pictures are referred to the iOS version of the ST BLE Sensor app. The Android version is slightly different




# Connect Using the ST BLE Sensor App

78


1

Tap  
“Connect to a device”




2

Select your  
BlueTile




3

You are  
connected



Blow air on  
the  
Temperature  
sensor to  
change the  
temperature  
and humidity  
values

- **“Device connected”** will appear as connection is created
- Each time user moves on different tabs/screens in the app:
  - **BLE notifications** on different BLE characteristics **are enabled**.
  - **Environmental and Gas Gauge/Battery** characteristics are involved

A screenshot of a Tera Term VT window titled 'COM91 - Tera Term VT'. The window has a menu bar with 'File', 'Edit', 'Setup', 'Control', 'Window', and 'Help'. The main text area shows the following output:

```
### STEVAL-BCN002U1 ###  
Scan for sensors:  
- Accelerometer and Gyroscope: OK  
- Pressure and Temperature: OK  
- Humidity and Temperature: OK  
- Magnetometer: OK  
- Proximity Sensor: OK  
Sensor in low-power mode: OK  
Battery voltage is 3.31v: OK  
Device is now discoverable with MAC: f7:c1:18:09:28:0b  
Device connected  
Calibration status requested  
Environmental Notification ON  
Environmental Notification OFF  
Gas Gauge Notification ON  
Gas Gauge Notification OFF  
Environmental Notification ON  
Environmental Notification OFF
```

The text 'Device connected' is highlighted with a blue rectangular box. The last six lines of output are grouped within a larger blue rounded rectangular box.

In file **sensor.c**

Len	Type	Protocol version	Device ID	Feature Mask	Device MAC	Len	Type	Local Name	Len	Type	Pwr
-----	------	------------------	-----------	--------------	------------	-----	------	------------	-----	------	-----

```

389 uint8_t manuf_data[26] = { 2, /* length*/0x0A, 0x00, /* 0 dBm */ // Transmission Power
390 0, /* Length*/0x03, DEFAULT_NAME_ABLINENS, // Complete Name
391 13, /* Length*/0xFF, 0x01, /* SKD version */
392 0x05, /* 0x05 BlueNRG-Tile Board */
393 #if ENABLE_BLUEVOICE
394 0x6A, /* ADPCM Sync + ADPCM Audio + Led + Prox */
395 #else
396 0x22, /* Led + Prox */
397 #endif
398 0xFE, /* Acc + Gyro + Mag + Press + Hum + Temp + Batt */
399 #if ENABLE_MOTIONFX
400 0x05, /* AccEvents + iNemo Compact */
401 0x40, /* eCompass */
402 #else
403 0x04, /* AccEvents */
404 0x00,
405 #endif
406 0x00, /* BLE MAC start */
407 0x00, 0x00, 0x00, 0x00, 0x00, /* BLE MAC stop */
408 };

```

3 bytes TX output power

9 bytes Local Name

13 bytes Manufacturer Specific



# BlueMS Protocol

## Complete Feature Mask

4 Bytes

Len	Type	Protocol version	Device ID	Feature Mask	Device MAC	Len	Type	Local Name	Len	Type	Pwr
-----	------	------------------	-----------	--------------	------------	-----	------	------------	-----	------	-----

31	30	29	28	27	26	25	24	
RFU	ADPCM	Switch	CoA	ADPC	MicLevel	Proximity	Lux	
23	22	21	20	19	18	17	16	
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	

0x6A

0xFE

0x05


0x40

After all laps

# How Feature Mask is Mapped onto ATT DB?


82

- **3 services:** HWServW2ST, Config, and Console
- **Each bit** of the 4-byte Feature Mask in the Advertising packet **corresponds to a HW/SW feature**
- In the Server ATT DB a **BLE Characteristic** has to be added for each bit of the Advertising Feature Mask



# BLE\_SensorDemo ATT DB

83



The **ATT DB** is defined and created in the file **gatt\_db.c**

# BLE\_SensorDemo ATT DB

84

## ATT DB

### HWServW2ST

Environmental

Acc Gyro Mag

Acc Events

Battery

Prox

LED

Quaternions

Ecompass

ADPCM

ADPCM synch


Len	PROPERTIES	UUID TYPE	UUID VALUE
12	N,R	128-bit	001D0000000111e1ac360002a5d5c51b
20	N	128-bit	00E00000000111e1ac360002a5d5c51b
5	N,R	128-bit	00004000000111e1ac360002a5d5c51b
9	N,R	128-bit	00020000000111e1ac360002a5d5c51b
4	N,R	128-bit	02000000000111e1ac360002a5d5c51b
3	N,R	128-bit	20000000000111e1ac360002a5d5c51b
8	N	128-bit	00001000000111e1ac360002a5d5c51b
4	N	128-bit	00000400000111e1ac360002a5d5c51b
20	N	128-bit	08000000000111e1ac360002a5d5c51b
6	N	128-bit	40000000000111e1ac360002a5d5c51b

NOTE: two additional bytes for a timestamp for each char

# Example: Battery Characteristic

85

31	30	29	28	27	26	25	24	0x00
RFU	ADPCM	Switch	DoA	ADPC	MicLevel	Proximity	Lux	
23	22	21	20	19	18	17	16	0x02
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	0x00
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	0x00
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	




UUID VALUE
00020000000111e1ac360002a5d5c51b

The **UUID values** are linked to the Feature Mask in advertising

# BLE\_SensorDemo ATT DB

86



Each characteristic is defined by the following key parameters

Len	PROPERTIES	UUID TYPE	UUID VALUE
20	N,R	128-bit	00000001000E11e1ac360002a5d5c51b
20	N,R	128-bit	00000002000E11e1ac360002a5d5c51b

This byte differentiates the **Service**

Len	PROPERTIES	UUID TYPE	UUID VALUE
20	N, Ww/oR, R,W	128-bit	00000002000F11e1ac360002a5d5c51b


# BLE\_SensorDemo ATT DB

87

```
tBleStatus Add_HWServW2ST_Service(void)
```

```
aci_gatt_add_service(UUID_TYPE,UUID, ...,MAX_NB_ATTRIBUTES,&ServHandle)
```

```
aci_gatt_add_char(ServHandle,UUID_TYPE,UUID,Length,PROPERTIES,PERMISSIONS,...,&CharHandle)
```




→ **HWServW2STHandle** = 0x000C

→ **EnvironmentalCharHandle** = 0x000D

→ **AccGyroMagCharHandle** = 0x0010

→ **ConfigW2STHandle** = 0x002B

→ **ConfigCharHandle** = 0x002C



- **Declaration Handle:** used by the application to access the Characteristic
- **Characteristic Value Handle:** used by the Client for Read/Write operations
- **Client Characteristic Configurator Descriptor (CCCD):** a GATT descriptor is added by default by the stack, if **char** has **Notify/Indicate property**. Used by Client to enable notifications/indications on char value.

# Central: Services and Characteristics

## Discovery Procedure

89

UUIDs Handles


Name	Handle	Property	Value	Value Length
Service User Defined (0x00000000000011E19AB40002A5D5C51B)	0x000C			
Characteristic User Defined (0x001D0000000011E1AC360002A5D5C51B)	0x000D	Read, Notify	0x011F0111023C00018B9CA605	0x0C
Client Characteristic Configuration (0x2902)	0x000F		0x0000	0x02
Characteristic User Defined (0x00E00000000011E1AC360002A5D5C51B)	0x0010	Notify		
Client Characteristic Configuration (0x2902)	0x0012		0x0000	0x02
Characteristic User Defined (0x00000400000011E1AC360002A5D5C51B)	0x0013	Read, Notify	0x0000002405	0x05
Client Characteristic Configuration (0x2902)	0x0015		0x0000	0x02
Characteristic User Defined (0x02000000000011E1AC360002A5D5C51B)	0x0016	Read, Notify	0x88A1232E	0x04
Client Characteristic Configuration (0x2902)	0x0018		0x0000	0x02
Characteristic User Defined (0x20000000000011E1AC360002A5D5C51B)	0x0019	Read, Notify	0x0024E6	0x03
Client Characteristic Configuration (0x2902)	0x001B		0x0000	0x02
Characteristic User Defined (0x00020000000011E1AC360002A5D5C51B)	0x001C	Read, Notify	0x0180000CBA03E8AB63	0x09
Client Characteristic Configuration (0x2902)	0x001E		0x0000	0x02
Characteristic User Defined (0x00000100000011E1AC360002A5D5C51B)	0x001F	Notify		
Client Characteristic Configuration (0x2902)	0x0021		0x0000	0x02
Characteristic User Defined (0x00000040000011E1AC360002A5D5C51B)	0x0022	Notify		
Client Characteristic Configuration (0x2902)	0x0024		0x0000	0x02
Characteristic User Defined (0x08000000000011E1AC360002A5D5C51B)	0x0025	Notify		
Client Characteristic Configuration (0x2902)	0x0027		0x0000	0x02
Characteristic User Defined (0x40000000000011E1AC360002A5D5C51B)	0x0028	Notify		
Client Characteristic Configuration (0x2902)	0x002A		0x0000	0x02
Service User Defined (0x000000000000F11E19AB40002A5D5C51B)	0x002B			
Characteristic User Defined (0x00000002000F11E1AC360002A5D5C51B)	0x002C	Write w/o resp, Notify		
Client Characteristic Configuration (0x2902)	0x002E		0x0000	0x02
Service User Defined (0x000000000000E11E19AB40002A5D5C51B)	0x002F			
Characteristic User Defined (0x00000001000E11E1AC360002A5D5C51B)	0x0030	Read, Write w/o resp, Write, Notify	0x0	0x00
Client Characteristic Configuration (0x2902)	0x0032		0x0000	0x02
Characteristic User Defined (0x00000002000E11E1AC360002A5D5C51B)	0x0033	Read, Notify	0x0	0x00
Client Characteristic Configuration (0x2902)	0x0035		0x0000	0x02

Values

This is how  
ATT DB  
looks like  
from the  
Central

# BLE Sensor – Characteristic Update


90




**aci\_gatt\_update\_char\_value** (ServiceHandle, 0x000C, //HWserv handle  
CharHandle, 0x000D, //EnvChar handle  
Offset, 0x00,  
Length, 0x08,  
Value) Data) //EnvChar Value

# Cortex-M0 Sleep Management

91




- **Sleep mode** managed through specific a **library** and **API**
  - `BlueNRG_Sleep(sleepMode, gpioWakeBitMask, gpioWakeLevelMask)`
- **4 wake-up sources: timers, DIO11, DIO12 and DIO13**
  - **Timers:** 4 virtual timers mapped on 2 physical timers managed by the radio IP
  - **DIO11:** Interrupt line from UART RX or SW1 button
  - **DIO12:** Interrupt line from Magnetometer
  - **DIO13:** Interrupt line from 6-axis Accelerometer & Gyroscope



# Typical Scenarios

92



- **Deep sleep mode** can represent most of the application time.
- Efficient management of sleep mode significantly lowers the avg power consumption.

## BlueNRG-2 flexible low power architecture

Sleeping Mode	Consumption	Notes
RUNNING	1.9mA	Core running
CPU HALT	1.5mA	WFI instruction
WAKETIMER	900nA	GPIOs and Timer Wakeup
NOTIMER	<b>500nA</b>	GPIOs only Wakeup

Highest pwr

Low Power library combines requests coming from the application with the radio operating mode

Lowest pwr


- BlueNRG-2 Low Power Library **handles autonomously entering and exiting to/from the sleep mode.**
- **The library saves peripherals configurations and application context** before entering deep sleep, and **restores the context** on exiting from low power state:
  - CPU returns to execute **the next instruction after the low power function call**
  - No need to re-initialize **peripheral and radio stack**
  - RAM retention **is guaranteed**

**NO need for the application to worry about sleep management and RAM retention!**

# Current Consumption Estimation Tool

- On st.com at this link:

[http://www.st.com/content/st\\_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrg001.html](http://www.st.com/content/st_com/en/products/embedded-software/wireless-connectivity-software/stsw-bnrg001.html)



The BlueNRG current consumption estimation tool can predict the current consumption under different conditions, as defined by the Bluetooth low energy specification, for the BlueNRG and BlueNRG-MS Bluetooth® low energy wireless network processors as well as the BlueNRG-1 and BlueNRG-2 Bluetooth® low energy systems-on-chip.

# Current Consumption Estimation Tool

- **Accurate estimate** of average current consumption and battery lifetime

1. **Select** the device

2. **Select** the type of event

3. **Configure** the HW operating conditions

4. **Configure** the application use case scenario

BlueNRG Current Consumption Estimation Tool v.1.4

File Plot Settings Window Help

Calculate Consumption

Events: Advertising

General Advertising Scanning Connection

Type of Device: BlueNRG-2 DC-DC Converter Active ☒

High Power mode ☒ Pout 4 (-2dBm)

Supply Voltage (V) 3.0 Crystal Startup Time (us) 512

Retention RAM 24 KB Master SCA (ppm) 5 (31-50)

Internal Low Speed Clock ☐ Slave SCA (ppm) 100

Performance Summary

Time of active phase: 2.87 ms

Average current during the active phase: 4.9 mA

Total average current: 7.93 uA

Payload data rate: NA

Battery lifetime

Battery capacity (mAh): 230

Battery lifetime: 3 year(s), 3 month(s), 23 day(s)

5. **Specify** the Battery capacity

6. **Read** the **average current** and the estimated **battery lifetime**




# Lab 3

## LED Characteristic

# Enable LED Toggling

98




**Write  
Packet**

'1' LED ON  
'0' LED OFF

**Notification  
Packet**

'1' LED ON  
'0' LED OFF



1. **Tap** the image on the screen
2. Send **BLE notification packet**
3. Image changes color and the **RED LED toggles**

1. Client **enables LED characteristic notifications**
2. Client **Writes in Config Char**
3. Parse **write command** from the client and **send BLE notification** on LED status from the server

4 Bytes

Len	Type	Protocol version	Device ID	Feature Mask	Device MAC	Len	Type	Local Name	Len	Type	Pwr
-----	------	------------------	-----------	--------------	------------	-----	------	------------	-----	------	-----

31	30	29	28	27	26	25	24	0x20
RFU	ADPCM	Switch	DoA	ADPC	MicLevel	Proximity	Lux	
23	22	21	20	19	18	17	16	0x1E
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	0x00
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	0x00
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	

# Client Enables LED Characteristic Notifications

101

1. In the file **gatt\_db.c** go to the **line 670**
2. **Client writes** in the **LED Characteristics Client Configurator Descriptor (CCCD)** and **Server enables notifications** through the **xFeatureNotification** structure in **line 673** by **xFeatureNotification.LedNotification = true;**

```
670 } else if (attr_handle == (LedCharHandle + 2)) {  
671  
672     if (att_data[0] == 01) {  
673         xFeatureNotification.LedNotification = true;  
674         PRINTF("Led ON\n\r");  
675     } else if (att_data[0] == 0) {  
676         xFeatureNotification.LedNotification = false;  
677         PRINTF("Led OFF\n\r");  
678     }  
679 }
```

# Client Writes in Config Char

102

1. In the file **gatt\_db.c** go to the **line 806**
2. Client **writes** in the **Config Char** and **Server parses** the command through the function **ConfigCommandParsing(att\_data, data\_length)**

```
806 } else if (attr_handle == ConfigCharHandle + 1) {  
807  
808     /* Received one write command from Client on Configuration characteristic */  
809     ConfigCommandParsing(att_data, data_length);  
810  
811 }
```

# Parse Write Command And Send BLE Notification on LED Status

103

1. In file **Sensor.c** at line **1040**
2. Check on the **FeatureMask** (line **1046**)
3. If it's the LED feature mask (line **1152**)
4. Check on the command value. If **0x01** (case1)
5. Turn ON LED3
6. Send Notification on the Config char on the command received and parsed
7. Send Notification on the LED char with the LED status

```
1040 uint32_t ConfigCommandParsing(uint8_t  
1041 FeatureMask = (uint8_t)0, uint8_t Data) {  
1042     uint8_t Command = att_data[4];  
1043     uint8_t Data = att_data[5];  
1044     uint32_t SendItBack = 1;  
1045  
1046     switch (FeatureMask) {
```


```
1152  
1153  
1154  
1155  
1156  
1157  
1158  
1159  
1160  
1161  
1162  
1163  
1164  
1165  
1166  
1167  
1168  
1169  
1170  
1171  
1172
```

```
case FEATURE_MASK_LED:  
    switch (Command) {  
        case 1:  
            SdkEvalLedOn(LED1);  
            PRINTF("Enabled: LED\n\r");  
            Config_Notify(FEATURE_MASK_LED, Command, Data);  
            break;  
        case 0:  
            SdkEvalLedOff(LED1);  
            PRINTF("Disabled: LED\n\r");  
            Config_Notify(FEATURE_MASK_LED, Command, Data);  
            break;  
    }  
  
    if (xFeatureNotification.LedNotification) {  
        if (SdkEvalLedGetState(LED1))  
            Led_Update(ENABLE);  
        else  
            Led_Update(DISABLE);  
    }  
    break;
```


# Enabling LED Toggling

104

**Click on “Switch”**




**A new page will appear**



# Enable LED Toggling

105




**Write  
Packet**

'1' LED ON  
'0' LED OFF

**Notification  
Packet**

'1' LED ON  
'0' LED OFF




1. Tap the image on the screen
2. Send **BLE notification packet**
3. Image changes color and **RED LED toggles**

# LED Fast Blinking Due to Sleep Mode


106

- **Red LED** fast toggling shows the entering/exiting to/from Sleep mode



- String “**LED Notification ON**” will appear as the app tab is enabled
- Each time user **click on the LED icon** in the **BLE Sensor app**, the **Write command is sent** to the board and the **LED toggles** accordingly (“Enabled: RGB led” = ON, “Disabled: RGB led” = OFF)

```
Device is now discoverable with MAC: 3f:2c:f6:eb:da:d8
Sensor activated: OK
Device connected
Environmental Notification ON
Environmental Notification OFF
Led Notification ON
Enabled: RGB led
Disabled: RGB led
Enabled: RGB led
Disabled: RGB led
Enabled: RGB led
Disabled: RGB led
```



# Lab 4

## Accelerometer Embedded Events Detection

# Example - Single Tap


109

1. On the board **perform a Single Tap**
2. Send **BLE** notification packet



**Notification  
Packet**

←  
**'SINGLE TAP'**



**NOTE:** this is just an example for SingleTap. Other events will be displayed later in the lab!

4 Bytes



31	30	29	28	27	26	25	24	
RFU	ADPCM	Switch	DoA	ADPC	MicLevel	Proximity	Lux	0x20
23	22	21	20	19	18	17	16	0x9E
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	0x04
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	0x00
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	



- **Accuracy:** Tango and Daydream compliance
- **0.55mA** current consumption is **HP combo**
  - 15% vs. LSM6DSL/M @ same performance



- New **ultra low power mode:**  
**14uA (@100Hz ODR) Axl only**



- **I3C**



- **FIFO tag**

```

graph LR
    M[M] --> FILTER[FILTER]
    FILTER -- Y --> INTEGRATOR[INTEGRATOR]
    INTEGRATOR -- W(k) --> COMPARISON[COMPARISON OF INTEGRATED DEVIANCE]
    M --> DETERMINED[DETERMINED IN ST INFLUENCE]
    DETERMINED -- W(k) --> COMPARISON
  
```

- **Pedometer 2.x**



- **FSM** build custom sensors for XL and Gyro

## 4. INNOVATION

- MEMS: **Axl T-structure** for mechanical shock robustness
- **Compressed FIFO (3x)**
- **10 patents protecting LSM6DSO innovation**

# Client Enables Acc Event Characteristic Notifications

112

1. In the file **gatt\_db.c** go to the **line 703**
2. **Client writes** in the **Acc Event Characteristic Client Configurator Descriptor (CCCD)** and **Server enables notifications** through the **xFeatureNotification** structure in **line 714** by **xFeatureNotification.AccEventNotification = true**

```
705 } else if (attr_handle == (AccEventCharHandle + 2)) {  
706     if (xFeatureNotification.MotionNotification == false && xFeatureNotification.iNemoEngineNotification == false) {  
707         if (att_data[0] == 01) {  
708             lsm6dso_xl_data_rate_set(0, LSM6DSO_XL_ODR_52Hz);  
709             GPIO_WriteBit(GPIO_Pin_7, Bit_RESET); // Proximity OFF  
710             EnableHWMultipleEvents();  
711             ResetHWPedometer();  
712             GPIO_EXTICmd(GPIO_Pin_13, ENABLE);  
713             Config_Notify(FEATURE_MASK_ACC_EVENTS, 'm', 1);  
714             AccEvent_Notify(0, 0);  
715             xFeatureNotification.AccEventNotification = true;  
716             PRINTF("AccEvent Notification ON\n\r");  
717         } else if (att_data[0] == 0) {  
718             lsm6dso_xl_data_rate_set(0, LSM6DSO_XL_ODR_OFF);  
719             xFeatureNotification.AccEventNotification = false;  
720             GPIO_EXTICmd(GPIO_Pin_13, DISABLE);
```

# Read Event Status and Send BLE Notification

113

```
1299 void MEMSCallback(void) {  
1300  
1301     lsm6dso_all_sources_get(0, &all_source);  
  
1334     /* Check if the interrupt is due to Single Tap */  
1335     if (xHardwareFeaturePresence.HwSingleTAP || xHardwareFeaturePresence.MultipleEvent) {  
1336         if (all_source.reg.all_int_src.single_tap)  
1337             SdkEvalLedOn(LED1);  
1338             SdkEvalLedOn(LED3);  
1339             PRINTF("Event: Single Tap\n\r");  
1340             AccEvent_Notify(ACC_SINGLE_TAP, 2);  
1341     }  
1342 }  
1343
```


In the file **sensor.c**

1. **line 1299 void MEMSCallback(void)**  
Callback triggered by IO13
2. **line 1301 lsm6dso\_all\_sources\_get**  
Read accelerometer status registers
3. **line 1336 if (all\_source.reg.all\_int\_src.single\_tap)**  
Check vs. single tap event
4. **line 1340 AccEvent\_Notify**  
Send BLE notification


# Visualize Single Tap Event in ST BLE Sensor

114


Select  
“Acc Event”





Tap  
“Event Enabled”




Select  
“Single Tap”  
and hit “Select”



Enabled  
“Single Tap”



1. On the board **perform a Single Tap**
2. Send **BLE notification packet**




Tap gently on the board




Notification  
Packet

→  
'SINGLE TAP'

## Single Tap



- **“AccEvent Notification ON”**: enable notifications on the Accelerometer Event characteristic
- **“Enabled Single Tap Detection”**: user enables Single Tap event detection
- **“Event: Single Tap”**: the actual BLE notification packet is sent upon detection of the Single Tap event.



The screenshot shows a Tera Term window titled 'COM91 - Tera Term VT'. The menu bar includes File, Edit, Setup, Control, Window, and Help. The terminal output shows the following sequence of commands and responses:

```
AccEvent Notification OFF
AccEvent Notification ON
Event: 6D Orientation
Disabled: Multiple Event Detection
Enabled: Single Tap Detection
Event: Single Tap
Event: Single Tap
Event: Single Tap
```


Blue rectangular boxes highlight the following lines in the output: 'AccEvent Notification ON', 'Event: 6D Orientation', 'Event: Single Tap' (the first instance), and 'Event: Single Tap' (the second instance).

NOTE: if the phone display enters sleep mode, the notifications are not sent


# LSM6DSO Embedded Events

117


Other possible  
embedded events




No event




Free fall



Single tap




Wake up



Tilt




Pedometer




WakeUp  
example

# Visualize Hardware Wakeup Event in BLE Sensor

118




1. **Leave** the board **still** for a few seconds
2. **Shake** the board
3. Send **BLE notification packet**




**Notification  
Packet**

→  
**'WAKE UP'**

## Wake Up



- **“AccEvent Notification ON”**: enable notifications on the Accelerometer Event characteristic
- **“Enabled Hardware Wakeup”**: user enable hardware wakeup event detection
- **“Event: Hardware Wakeup”**: the actual BLE notification packet sent upon detection of the Hardware Wakeup event.



```
COM91 - Tera Term VT
File Edit Setup Control Window Help
AccEvent Notification OFF
AccEvent Notification ON
Event: 6D Orientation
Disabled: Multiple Event Detection
Enabled: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
Event: Hardware Wakeup
AccEvent Notification OFF
□
```

NOTE: if the phone display enters sleep mode, notifications are not sent

# LSM6DSO Embedded Events


121

You can go ahead later and test other events...


Other possible  
embedded events



No event




Free fall




Single tap




Wake up



Tilt



Pedometer





# Lab 5


## 9-axis Acc+Gyro+Mag Sensor Data Fusion

- In this example we are going to demonstrate how to:
  - **Enable** the embedded sensor data fusion library
    - Input: raw Acc+Gyro+Mag sensor data
    - Output: quaternions
  - **Scale the quaternions value** by a scaling factor proportional to proximity detection
  - **Send** scaled data fusion information through **BLE notifications packets** to the ST BLE Sensor app client


# Sensor Data Fusion

124


1. **Enable** Sensor Fusion library
2. **Send** quaternions information through **BLE notification packet**



  
**Notification Packet**  
←  
QUATERNIONS



**Sensors used by data fusion:**  
Acc+Gyro+Mag and Proximity




1. **Enable Sensor Data fusion library**
2. **Enable proximity sensor**
3. **Send quaternions data – scaled by proximity sensor data - through BLE notifications packets**

4 Bytes


Len	Type	Protocol version	Device ID	Feature Mask	Device MAC	Len	Type	Local Name	Len	Type	Pwr
-----	------	------------------	-----------	--------------	------------	-----	------	------------	-----	------	-----

31	30	29	28	27	26	25	24	0x22
RFU	ADPCM	Switch	DoA	ADPC	MicLevel	Proximity	Lux	
23	22	21	20	19	18	17	16	0xFE
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	0x05
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	0x40
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	


**Swipe left** to **view** the **Mems Sensor Fusion**



**“Mems Sensor Fusion”** tab




**Click on**  
**OK**



3


**Sensor Fusion**  
**enabled**



# Proximity Sensor

128

## Enable Proximity Sensor




Move your hand far and close to the BlueNRG-Tile




1

Far from BlueTile



2

Near to BlueTile



Note: ONLY for rendering purposes, the cube is scaled proportional to a clipped 30 cm distance

3rd gen **ToF sensor** with lens for **long distance** ranging & ROI selection



## Product highlights

OLGA: 4.9 x 2.5 x 1.56 mm

FoV : 27°

Compatible footprint with VL53L0X

### Enhanced performances:

- Full FoV ranging : **400cm+** (white target, no IR)
- **Programmable FOV**: SPAD zone selection – full-screen to 4x4

### Cutting-edge module and silicon :

- **Fastest miniature ToF product in the market** up to 50Hz
- **Integrated lens** for longer range and better ambient light immunity
- **Programmable settings** to best fit customer's application:
  - Low power with interrupts for user / object detection
  - Long distance ranging
  - High accuracy for small movement detection

## Applications

### Presence user detection

- Autonomous mode with interrupts
- Low-power
- Long distance 400cm+
- PC, tablets, IoT, portable handsets, security



### Obstacle detection:

- Robots: Obstacle avoidance
- Vacuum cleaners: Wall following, cliff detection
- Drones: Take-off and landing, Ceiling detection

### Accurate objects distance scanning

- Vending machines: control of objects in racks
- Coins dispensers: coins counting
- Smart shelves: Consumer scanning



# Full-range Proximity Real-time Data Plot

130






**Swipe left** to **view** the real-time data plot

**“Plot Feature”** tab

**Select Proximity**

**Select the time frame**


**View the real-time data plot**




# Logging Real-time Data Plot

131


Click on  
top right corner




1  
Select  
“Start logging”




2  
After some time  
re-click on the  
right-top corner



3  
Select  
“Stop logging”




4  
App opens your  
email client



.csv files attached  
to the email

## Sensor Fusion enabled



## Try **static** position: no drift, the cube is perfectly still

- In steady static position the **acc** and **mag** enable an accurate orientation estimate
- acc vibrations and mag bias and interferences are **rejected or compensated by the motionFX library**


## Try highly **dynamic** motion: perfect tracking

- In high dynamic motion the acc cannot be used, therefore the **gyro** is used to update the orientation
- gyro bias is **estimated and compensated at runtime** by the **motionFX library**

# Sensor Data Fusion

## MotionFX Library


133



# Sensor Data Fusion

## MotionFX Library

134




- **Accelerometer gives roll and pitch angles and the gravity vector...but only in static conditions! (or low dynamics)**

# Sensor Data Fusion

## MotionFX Library

135




- **Magnetometer gives yaw angle and heading**  
...but **only if tilt is compensated**: the accelerometer is needed!  
...and mag bias (hard-iron) **must be compensated!**

# Sensor Data Fusion

## MotionFX Library

136




- **Gyroscope gives the new orientation** based on previous orientation ...but gyro bias offset needs to be compensated for accuracy!

# Sensor Data Fusion

## MotionFX Library

137



**Motion FX library provides orientation estimation plus:**

- **Magnetometer hard-iron offset** compensation.
- **Accelerometer vibrations** rejection.
- **Gyroscope bias** offset compensation.

The gyroscope is the most important sensor in the system  
...works in highly dynamic conditions when the Acc cannot be used  
...works with magnetic anomalies when the Mag cannot be used

# Gyroscope

138


**LSM6DSO** is an inertial module with **Acc** and **Gyro**

- **Exceptional noise performance** for maximum accuracy in orientation estimation
  - 90 ug/sqrtHz acc noise density
  - 3.8 mdps/sqrtHz gyro noise density
- **Extremely low-power**
  - **650 uA peak power** at ODR 6.66kS/sec with Acc+Gyro in high performance mode!

ST <small>life.augmented</small>		LSM6DSO
		iNEMO inertial module: always-on 3D accelerometer and 3D gyroscope
		Data brief
 LGA-14L (2.5 x 3 x 0.83 mm) typ.		<b>Description</b> <p>The LSM6DSO is a system-in-package featuring a 3D digital accelerometer and a 3D digital gyroscope boosting performance at 0.55 mA in high-performance mode and enabling always-on low-power features for an optimal motion experience for the consumer.</p> <p>The LSM6DSO supports main OS requirements, offering real, virtual and batch sensors with 9 kbytes for dynamic data batching. ST's family of MEMS sensor modules leverages the robust and mature manufacturing processes already used for the production of micromachined accelerometers and gyroscopes. The various sensing elements are manufactured using specialized micromachining processes, while the IC interfaces are developed using CMOS technology that allows the design of a dedicated circuit which is trimmed to better match the characteristics of the sensing element.</p> <p>The LSM6DSO has a full-scale acceleration range of <math>\pm 2/\pm 4/\pm 8/\pm 16</math> g and an angular rate range of <math>\pm 125/\pm 250/\pm 500/\pm 1000/\pm 2000</math> dps.</p> <p>The LSM6DSO fully supports EIS and OIS applications as the module includes a dedicated configurable signal processing path for OIS and auxiliary SPI, configurable for both the gyroscope and accelerometer.</p> <p>High robustness to mechanical shock makes the LSM6DSO the preferred choice of system designers for the creation and manufacturing of reliable products. The LSM6DSO is available in a plastic land grid array (LGA) package.</p>
<b>Features</b> <ul style="list-style-type: none"><li>• Power consumption: 0.55 mA in combo high-performance mode</li><li>• "Always-on" experience with low power consumption for both accelerometer and gyroscope</li><li>• Smart FIFO up to 9 kbyte</li><li>• Android compliant</li><li>• <math>\pm 2/\pm 4/\pm 8/\pm 16</math> g full scale</li><li>• <math>\pm 125/\pm 250/\pm 500/\pm 1000/\pm 2000</math> dps full scale</li><li>• Analog supply voltage: 1.71 V to 3.6 V</li><li>• Independent IO supply (1.62 V)</li><li>• Compact footprint: 2.5 mm x 3 mm x 0.83 mm</li><li>• SPI / I<sup>2</sup>C &amp; MIPI I3C<sup>SM</sup> serial interface with main processor data synchronization</li><li>• Auxiliary SPI for OIS data output for gyroscope and accelerometer</li><li>• Advanced pedometer, step detector and step counter</li><li>• Significant Motion Detection, Tilt detection</li><li>• Standard interrupts: free-fall, wakeup, 6D/4D orientation, click and double-click</li><li>• Programmable finite state machine: accelerometer, gyroscope and external sensors</li><li>• Embedded temperature sensor</li><li>• ECOPACK<sup>®</sup>, RoHS and "Green" compliant</li></ul>		<b>Table 1. Device summary</b>

## LIS2MDL is digital Mag

- **Exceptional noise performance and dynamic range** for maximum accuracy in orientation estimation
  - 50 Gauss dynamic range
  - 3 mgauss RMS noise
- **Embedded offset compensation**
  - **Intrinsic offset is estimated and compensated automatically**
  - Extrinsic offset (hard-iron) must be estimated by host and can be compensated internally




life.augmented

LIS2MDL

Digital output magnetic sensor:  
ultra-low-power, high-performance 3-axis magnetometer

Datasheet - production data



LGA-12 (2.0x2.0x0.7 mm)

### Description

The LIS2MDL is an ultra-low-power, high-performance 3-axis digital magnetic sensor. The LIS2MDL has a magnetic field dynamic range of  $\pm 50$  gauss.

The LIS2MDL includes an I<sup>2</sup>C serial bus interface that supports standard, fast mode, fast mode plus, and high-speed (100 kHz, 400 kHz, 1 MHz, and 3.4 MHz) and an SPI serial standard interface.

The device can be configured to generate an interrupt signal for magnetic field detection.

The LIS2MDL is available in a plastic land grid array package (LGA) and is guaranteed to operate over an extended temperature range from -40 °C to +85 °C.

### Features

- 3 magnetic field channels
- $\pm 50$  gauss magnetic dynamic range
- 16-bit data output
- SPI/I<sup>2</sup>C serial interfaces
- Analog supply voltage 1.71 V to 3.6 V
- Selectable power mode/resolution
- Single measurement mode
- Programmable interrupt generator
- Embedded self-test
- Embedded temperature sensor
- ECOPACK®, RoHS and "Green" compliant

### Applications



- Tilt-compensated compasses
- Map rotation
- Intelligent power saving for handheld devices
- Gaming and virtual reality input devices

Table 1. Device summary

Part number	Temp. range [°C]	Package	Packaging
LIS2MDL	-40 to +85	LGA-12	Tray
LIS2MDLTR	-40 to +85	LGA-12	Tape and reel

# Magnetometer Calibration

140



Tap




**Move** the BlueTile with the “**8 pattern**” shown in the figure to **calibrate the magnetometer**



Calibration is **Completed** when the icon becomes **green**.

# Magnetometer ECompass


141



Tap




Select  
"Compass"



Red arrow is related to  
the current orientation  
of the BlueTile

Rotate the BlueTile



(you can check against the  
phone eCompass)




# Lab 6


## Cloud Data Logging on IBM Watson

1. Enable **IBM Watson IoT – Cloud Logging**
2. Send **BLE** notification packets on Sensor status
3. **Visualize** the data


IBM



IBM Watson




Notification  
Packets




# IBM Watson IoT Quickstart 144


## 2. Select “IBM Watson IoT - Quickstart”



## Click “Connect”




## 1. Select one or multiple features



## 2. Click “View Data on Cloud”


## Wait a few seconds



# IBM Watson IoT Quickstart

145

Quickstart will appear



Scroll down to see your selected sensor plot.

You will see the Plot of selected feature






Table of available features



Scroll down again to change sensor data or axes






# Lab 7



## Voice over BLE

- In this example we are going to demonstrate how to:
  - **Enable the BlueVoice library** for Voice Over BLE streaming
    - Input: raw data from the MEMS microphone
    - Output: ADPCM data streaming @8kHz
  - **Send ADPCM data** through **BLE notifications packets** to the ST BLE Sensor app

1. Enable **BlueVoice** library
2. Send **voice** to the ST BLE Sensor app client through **BLE notification packet**



  
**Notification  
Packet**  
←  
ADPCM  
compressed audio



**MEMS  
Microphone**

4 Bytes




31	30	29	28	27	26	25	24	0x6A
RFU	ADPCM	Switch	DoA	ADPC	MicLevel	Proximity	Lux	
23	22	21	20	19	18	17	16	0xFE
Acc	Gyro	Mag	Pressure	Humidity	Temperat	Battery	2nd Temp	
15	14	13	12	11	10	9	8	0x05
RFU	RFU	RFU	RFU	Beamform	AccEvent	FreeFall	SensFusC	
7	6	5	4	3	2	1	0	0x40
SensFus	Compass	MotionInt	Activity	Carry Pos	MemsGes	ProxGes	Pedo	

# Enable BlueVoice Library

150

Add the preprocessor symbol **ENABLE\_AUDIO** to the project

1. Right-click on **Release**
2. Select “Options for Target ‘Release’...”




# Enable BlueVoice Library

151

In the project options:


1. Go to the tab **C/C++** and then in the **Preprocessor Symbols**
2. Set the symbol **ENABLE\_AUDIO=1** and then click on **OK**



# BlueVoice: Voice over Bluetooth LE

152


Select  
“BlueVoice”



Tap




Speak close to  
the BlueNRG-Tile



Voice will be streamed over BLE  
You will hear it from the phone

Do not silence your phone,  
must **NOT** be vibration only!





**MEMS  
Microphone**

(if the mic captures the audio from  
the phone speaker, a very high  
pitch sound can happen!)

# Voice over Bluetooth LE

153




**It's a Vendor Specific Service!**

Audio: exported by the Server through **2 dedicated BLE characteristics**

Voice streaming over BLE:  
Audio @8kHz  
Codec: ADPCM  
Bitrate: 32kbps

# BlueVoice ADPCM - Audio 8kHz

154




No acknowledge required for **Notifications**:

- OK for Audio streaming
- **Minimal Latency**
- **Optimal Bandwidth**

## Voice Streaming

- Audio Format: **PCM 16 bit @ 8 kHz**
- **ADPCM Compression @ 32 Kbps**: Low latency and low complexity
- Side Information at low data rate enhances error resilience




2 packets/event  
20 bytes/packets  
100 events/sec  
=

**32kbps**



# BlueVoice Architecture


155

## “Packetization”



## “De-Packetization”






# Lab 8

## Over-The-Air (OTA) FW Upgrade

# Flash Memory Layout

157



0x1007E800

Empty

0x1005F800

BLE\_SensorDemo\_  
LowerApp\_OTA

0x10040800

BLE\_OTA\_ResetManager

0x10040000



OTA


BLE\_Chat\_Server\_HigherApp\_OTA.bin



**REMEMBER TO LOAD THE BLE OTA Reset manager!!!**

# Once OTA is Completed...

158



0x1007E800

BLE\_Chat\_Server\_  
HigherApp\_OTA

0x1005F800

Empty

0x10040800


BLE\_OTA\_ResetManager

0x10040000


# OTA FW Upgrade (1/2)

159


Click on the top right corner




Select “Firmware Upgrade”



Select your remote repository




Select the binary file





# OTA FW Upgrade (2/2)

160

**OTA data transfer begins**



**Click OK as completed**




**Re-Connect** to BlueTile, now running a new application



# Customizing Your Design

# STEVAL-BCN002V1B Block Diagram

162



# Enable/Disable Sensors & Libraries

163

- **Dedicated structure “FeaturePresence”** for enabling/disabling sensors & libraries individually. File **sensor.h**

```
typedef struct {  
    bool AccelerometerGyroscopePresence;  
    bool MagnetometerPresence;  
    bool HumidityTemperaturePresence;  
    bool PressurePresence;  
    bool ProximityLightPresence;  
    bool iNemoEngine;  
    bool Pedometer;  
} FeaturePresence;
```

- **SensorScan() function** set each field of the structure to **false** or **true**. File **sensor.c**

Disable the unneeded sensor for optimizing the power consumption!

```
// Check sensor list  
SensorsScan();  
  
// Configure discovered sensors  
if (xFeaturePresence.PressurePresence)  
    Init_Pressure_Temperature_Sensor();  
if (xFeaturePresence.HumidityTemperaturePresence)  
    Init_Humidity_Sensor();  
if (xFeaturePresence.MagnetometerPresence)  
    Init_Magnetometer();  
if (xFeaturePresence.AccelerometerGyroscopePresence)  
    Init_Accelerometer_Gyroscope();  
if (xFeaturePresence.ProximityLightPresence)  
    Init_Proximity_Sensor();  
  
// Configure sensors in low power mode  
SensorsLowPower();
```

- **Advertising intervals:**
  - Dedicated API `aci_gap_set_discoverable(Advertising_Type, Advertising_Interval_Min, Advertising_Interval_Max, ... )`
  - In file **sensor.c**
- **Connection intervals:**
  - Dictated by the Central device. Peripheral has no full control on this.
- **Notifications frequency**
  - Dedicated Virtual Timers (mapped on HW physical timers) for different functionalities
  - Timeouts defined in **sensor.h**

```
#define BATTERY_UPDATE_RATE      1000    // Fixed ODR @ 1 Hz
#define ENV_SENSOR_UPDATE_RATE   100     // Fixed ODR @ 10 Hz
#define MOTION_SENSOR_UPDATE_RATE 40     // Fixed ODR @ 25 Hz
```

- In this case redesign is of course necessary
- **Schematics and Gerbers files:**
  - online at [www.st.com/bluetile](http://www.st.com/bluetile)
- **BlueNRG-2 pin mapping**
  - Check **BlueNRG-2 DS** at **Table 129**

3.12.2

## Functional description

The table below shows the GPIO configuration table where each IO pin is associated with related functions.

**Table 129.** IO functional map


Pin name <sup>(1)</sup>	GPIO mode "000"		Serial1 mode '001'		Serial0 mode '100'		Serial2 mode '101'	
	Type	Signal	Type	Signal	Type	Signal	Type	Signal
IO0	I/O	GPIO 0	I	UART_CTS	I/O	SPI_CLK	O	CPUCLK
IO1	I/O	GPIO 1	O	UART_RTS	I/O	SPI_CS1	I	PDM_DATA
IO2	I/O	GPIO 2	O	PWM0	O	SPI_OUT	O	PDM_CLK
IO3	I/O	GPIO 3	O	PWM1	I	SPI_IN	-	-
IO4	I/O	GPIO 4	I	UART_RXD	I/O	I2C2_CLK	O	PWM0
IO5	I/O	GPIO 5	O	UART_TXD	I/O	I2C2_DAT	O	PWM1
IO6	I/O	GPIO 6	O	UART_RTS	I/O	I2C2_CLK	I	PDM_DATA
IO7	I/O	GPIO 7	I	UART_CTS	I/O	I2C2_DAT	O	PDM_CLK
IO8	I/O	GPIO 8	O	UART_TXD	I/O	SPI_CLK	I	PDM_DATA
IO9	I/O	GPIO 9	I	SWCLK	I	SPI_IN	O	XO16/32M
IO10	I/O	GPIO 10	I	SWDIO	O	SPI_OUT	O	CLK_32K
IO11	I/O	GPIO 11	I	UART_RXD	I/O	SPI_CS1	O	CLK_32K
IO12	OD	GPI 12 <sup>(2)</sup>		-	I/O	I2C1_CLK	-	-
IO13	OD	GPI 13 <sup>(2)</sup>	I	UART_CTS	I/O	I2C1_DAT	-	-
IO14	I/O	GPIO 14	I/O	I2C1_CLK	I/O	SPI_CLK	-	-



# Quick Recap


# DK 3.0.0 SW Architecture

167



# STEVAL-BCN002V1B Block Diagram


168



# Power Consumption

169

State	Avg power cons
stand-by	25uA
advertise 250ms	170uA
Battery notification	0.25mA
Environmental / AccEvents / LED control	0.3mA
Motion FX (Inertial)	1.4mA
BlueVoice	3.6mA
Motion FX plus Time Of Flight	8mA



# Battery Lifetime: CR2032

170

State	Avg Power Cons	Battery lifetime
stand-by	25uA	8800 hrs / 367 days
advertise 250ms	170uA	1294 hrs / 54 days
Battery notification	0.25mA	880 hrs / 37 days
Environmental / AccEvents / LED control	0.3mA	733 hrs / 30 days
Motion FX (Inertial)	1.4mA	157 hrs / 6.5 days
BlueVoice	3.6mA	61.1 hrs / 2.5 days
Motion FX plus Time Of Flight	8mA	27.5 hrs



# The End: Q&A





# Virtual COM Driver Installation Win7

# Open the Windows Control Panel

173

1. From **Start Menu** select **Control Panel**


2. Select **Device Manager**



# Open the Device Manager

174

1. Look for **Other devices** and right click and then select **Update Driver Software...**




# Look for the VCOM Driver

175

## 1. Select **Browse my computer for driver software**


1



# Look for the VCOM Driver

176



1. Click on **Browse** button and **go to** the folder “\STEVAL-BCN002V1 DK 1.0.9\PCDriver\Virtual COM Port Driver”
2. Click on **Include subfolder** and then on **Next**




# Allow the Driver Installation 177

1. Click on **Install driver software anyway**

2. Installation starts




1. Installation completed
2. Device is in the **COM Ports** list



Done! Now please go back from here!



2







# Virtual COM Driver Installation Win10

# Open the Windows Settings

180

1. From **Start Menu** select **Settings**

2. Select **Devices**





# Open the Device Manager

181

1. Select **Device manager**



2. Select **Other Devices** and **Unknown device**



# Update Driver Software

182

1. Right click and then select **Update Driver Software...**
2. Select **Browse my computer for driver software**




# Look for the VCOM Driver

183

1. Click on **Browse** button and **go to** the folder



“\STEVAL-BCN002V1 DK 1.0.9\PCDriver\Virtual COM Port Driver”

2. Click on **Include subfolder** and then on **Next**



1. Installation completed. Device is in the **COM Ports** list


Done! Now please go back from here!





# ARM Keil MDK Installation

- Download and install the tool from the following webpage:
  - <http://www2.keil.com/mdk5/>



The screenshot shows the Keil ARM MDK website. The header features the 'arm KEIL' logo and a navigation bar with links for Home, Products, Download, Events, and Support. A search bar is located on the right. The main content area is titled 'MDK Microcontroller Development Kit' and includes a description of the software. A red box highlights the 'Download MDK v5.27' button. To the right, there are sections for 'Quick Links' and 'Software Packs'. A 'Learning Platform' badge is also visible in the top right corner.

**arm KEIL**

Home / MDK

## MDK Microcontroller Development Kit

Keil® MDK is the most comprehensive software development solution for Arm®-based microcontrollers and includes all components that you need to create, build, and debug embedded applications.

[Download MDK v5.27](#)

**Update:** MDK v5.27 available, containing enhancements for multi-core debugging and the latest Arm Compiler 6.12.

**Quick Links**

- Getting Started
- Online Manuals
- Middleware
- Compare MDK Editions
- Arm Tools Overview

**Software Packs**

- Device List
- Evaluation Boards
- MDK v4 Legacy Support
- Third-Party Software Packs
- Public Software Packs

Learning Platform



# Arm Keil MDK Configuration

# Keil ARM MDK Configuration

188

Download and save on your PC the .zip file “**Keil.STBlueNRG-2\_DFP.1.0.1.zip**” from the following webpage: [https://www.keil.com/dd2/stmicroelectronics/bluenrg\\_2/](https://www.keil.com/dd2/stmicroelectronics/bluenrg_2/)

The screenshot shows the Keil ARM MDK website for the STM32BlueNRG-2 product. The page layout includes a top navigation bar with links to Home, Products, Download, Events, Support, and Videos, along with a search bar. The main content area is divided into a sidebar and a central product page. The sidebar contains links to Product Information, Technical Support, Software Downloads, and Other Information. The central product page displays the product name, specifications, and a list of quick links. A 'Download' button is highlighted in a red box.

**arm KEIL**

Home / MDK5 Device List / BlueNRG-2

## STMicroelectronics BlueNRG-2

Hz, , 256 kB ROM, 24 kB RAM

High performance, ultra-low power ARM Cortex-M0 32-bit based architecture core - Upgradable BLE stack (stored in embedded Flash memory, via SPI) - AES security co-processor - Low power modes - 16 or 32 MHz crystal oscillator - 12 MHz ring oscillator - 32 kHz crystal oscillator - 32 kHz ring oscillator - Compliant with the following radio frequency regulations: ETSI EN 300 328, EN 300 440, FCC CFR47 Part 15, ARIB STD - Operating temperature range: -40 to 85 Celsius

Core Hz

Memory 24 kB RAM, 256 kB ROM

**Quick Links**

- Board List
- Software Packs
- MDK Version 5
- Legacy Support
- Feedback

**Silicon Supplier**

- STMicroelectronics

**Device Family Pack** DFP



Support for this device is contained in:  
STMicroelectronics BlueNRG-2 Series  
Device Support

[Download](#)

# Keil ARM MDK Configuration

189


- Open **Keil uVision5 IDE**
- This is the main GUI



# Keil ARM MDK Configuration

190

- Open the **Pack Installer**
  - Go to **Project->Manage->Pack Installer**




# Keil ARM MDK Configuration

191

1. In the **Pack Installer**...


2. Go to **File->Import**



# Keil ARM MDK Configuration

192

1. Open the previously saved .zip file “**Keil.STBlueNRG-2\_DFP.1.0.1.zip**”



# Keil ARM MDK Configuration


193

1. Once the Device Support pack has been installed, on the **Devices** list in the left column select the vendor **STMicroelectronics**

2. Go to **STBlueNRG-2 Series** and select **STBlueNRG-2**

3. Now it will show in green **“Up to date”**

4. Close the **Pack Installer**






# BlueNRG-2 Free License for Keil ARM MDK

- You can refer to the following webpage:
  - <http://www2.keil.com/stmicroelectronics-stm32/mdk>
- Note: it is mentioned STM32L0 and STM32F0, but the same procedure applies to BlueNRG-2 device

# BlueNRG-2 License Installation 1/6

196


- Login with an account that has administration rights.
- Right-click the  $\mu$ Vision icon and select **Run as Administrator...** from the context menu.



# BlueNRG-2 License Installation 2/6

197


1. Open the dialog **File — License Management...**



# BlueNRG-2 License Installation 3/6

198

Select the **Single-User License** tab and click the button **Get LIC via Internet...**,



The screenshot shows the 'License Management' dialog box with the 'Single-User License' tab selected. The 'Customer Information' section contains fields for Name (Raffaele Riva), Company (STMicroelectronics), and Email (raffaele.riva@st.com). The 'Computer ID' section shows CID: CBZDR-I82D3. A button labeled 'Get LIC via Internet...' is highlighted with a red rectangle. Below this is a table with columns 'Product', 'License ID Code (LIC)/Product variant', and 'Support Period'. The table contains one row: 'MDK-ARM Professional', 'NH9Y9W-9SHYB-21ZB7-XTK2N-5HIEK-FI8B2', and 'Operation Expires: 13 Jul 2018'. At the bottom, there is a 'New License ID Code (LIC):' field, 'Add LIC', and 'Uninstall...' buttons. The 'Close' and 'Help' buttons are at the bottom right.


Product	License ID Code (LIC)/Product variant	Support Period
MDK-ARM Professional	NH9Y9W-9SHYB-21ZB7-XTK2N-5HIEK-FI8B2	Operation Expires: 13 Jul 2018

# BlueNRG-2 License Installation 4/6

199

Click the button **OK** to register the product.

This action opens the License Management page on the Keil web site.



# BlueNRG-2 License Installation 5/6


200

For the latest **Product Serial Number** please check on the Keil website at this URL:

<http://www2.keil.com/stmicroelectronics-stm32/mdk>

Then enter the PSN in this webpage along with your contact information and click the button **Submit**.

An e-mail is sent back with the **License ID Code (LIC)** within a few minutes.



The screenshot shows the 'arm KEIL' website. The navigation bar includes 'Products', 'Download', 'Events', and 'Support'. A search bar is on the right. The left sidebar lists 'Product Licensing' options: Overview, Single-User License, Single-User License Uninstall, and Floating-User License. The main content area is titled 'Single-User License' and contains instructions to enter the Product Serial Number (PSN) and contact information. A form titled 'Enter Your Contact Information Below' includes fields for Computer ID (CID), Product Serial # (PSN), PC Description, First Name, Last Name, E-mail, and Company. The PSN field is highlighted with a red rectangle. The CID field contains 'CBZDR-I82D3'. The First Name field contains 'Raffaele', the Last Name field contains 'Riva', the E-mail field contains 'raffaele.riva@st.com', and the Company field contains 'STMicroelectronics'.

arm KEIL

Home / Product Licensing

## Single-User License

Enter your Product Serial Number (PSN) and contact information using the following form to license your Keil product. **Be sure to include dashes.**

Please make certain your e-mail address is valid. After verifying your Product Serial Number and Computer ID (CID), we will send you a License ID Code (LIC) via e-mail. E-mail is sent from licmgr@keil.com so make sure any spam blocker you use is configured to allow this address.

**Enter Your Contact Information Below**

Computer ID (CID): CBZDR-I82D3

**Product Serial # (PSN):**

PC Description:

Enter a description of the PC on which this license is registered.  
For example: LAB PC, Office Computer, Laptop, John's PC, etc.

First Name:

Last Name:

E-mail:


Company:

# BlueNRG-2 License Installation 6/6

201

To activate the Software Product, enter the **LIC** you received by email in the field **New License ID Code (LIC)** and click **Add LIC**.

Then click on **Close**



The image shows a 'License Management' dialog box with the following components:

- Single-User License** | Floating License | Floating License Administrator | FlexLM License
- Customer Information**
  - Name: Raffaele Riva
  - Company: STMicroelectronics
  - Email: raffaele.riva@st.com
- Computer ID**
  - CID: CFW23-ATCIR
  - Get LIC via Internet...
- License Table**

Product	License ID Code (LIC)/Product variant	Support Period
MDK-ARM Cortex-M0/M0+ 256K for ST	QXJMN-YH8DA-N1Z6J-7RXNJ-VUYX7-SU4RH	Expires: Jan 2019
- New License ID Code (LIC):** QXJMN-YH8DA-N1Z6J-7RXNJ-VUYX7-SU4RH
- Add LIC** (button)
- Uninstall...** (button)
- Close** (button)
- Help** (button)