

---

## The RF-Flasher utility software package

### Introduction

This document describes the RF-Flasher utility software package (STSW-BNRGFLASHER), which includes the RF-Flasher utility PC application.

The RF-Flasher utility is a standalone PC application, which allows the BlueNRG-1, BlueNRG-2, BlueNRG-LP, and BlueNRG-LPS Bluetooth® Low Energy systems-on-chip flash memory to be read, mass erased, written, and programmed.

It currently supports the interface to the BlueNRG-LP, BlueNRG-LPS, BlueNRG-1, and BlueNRG-2 flash memory through UART mode using the device internal UART bootloader. It also currently supports the interface to the BlueNRG-LP, BlueNRG-LPS, BlueNRG-1, and BlueNRG-2 flash memory through SWD mode by using the standard SWD interface through standard hardware programming/debugging tools (CMSIS-DAP, ST-LINK, and J-Link).

Moreover, it also allows a MAC address to be stored in a specific flash memory location selected by the user in both UART and SWD modes.

The RF-Flasher software package also provides a standalone flasher launcher utility, allowing flash memory programming, reading, mass erase, and content verification. The flasher launcher utility requires a PC DOS window only.

**Note:** *The RF term currently refers to BlueNRG-LP, BlueNRG-LPS, BlueNRG-1, and BlueNRG-2 devices. Any specific differences are highlighted where needed.*

# 1 General information

## 1.1 List of acronyms

**Table 1. List of acronyms**

Term	Meaning
RF	Radio frequency
SWD	Serial wire debug
UART	Universal asynchronous receiver-transmitter
USB	Universal series bus

## 1.2 Reference documents

**Table 2. Reference documents**

Reference	Type	Title
DS11481	BlueNRG-1 datasheet	Programmable Bluetooth® Low Energy wireless SoC
DS12166	BlueNRG-2 datasheet	Programmable Bluetooth® Low Energy wireless SoC
DB3557	STSW-BNRGFLASHER data brief	Data brief for the RF-Flasher software package
DS13282	BlueNRG-LP datasheet	Programmable Bluetooth® Low Energy wireless SoC
DS13819	BlueNRG-LPS datasheet	Programmable Bluetooth® Low Energy wireless SoC

## 2 Getting started

This section describes all system requirements to run the RF-Flasher utility PC application and the related software package installation procedure.

### 2.1 System requirements

The RF-Flasher utility has the following minimum requirements:


- PC with Intel® or AMD processor running the following Microsoft® operating system:
  - Windows® 10
- At least 2 GB of RAM
- USB ports
- Adobe Acrobat Reader 6.0 or later

*Note:* Recommended display scale and settings are up to 150%.

### 2.2 Software package setup

The user can run this utility by clicking on the RF-Flasher utility icon ([Start]>[ST RF-Flasher Utility x.x.x]>[RF-Flasher Utility]).

Figure 1. RF-Flasher utility



DT73424V2


### 3 Toolbar interface

In the toolbar section of the RF-Flasher utility main window, the user can perform the following operations:

- Load an existing .bin or .hex (Intel extended) file, using [File]>[Open file...]
- Save the current memory image in a .bin file, using [File]>[Save File As...]. The start address and the size of the memory section to be saved to the file are selectable from the *Device Memory* tab.
- Close an existing .bin or .hex file, using [File]>[Close file]
- Set the ST-LINK frequency, using [Tools]>[Settings...]
- Enable or disable log file creation in UART/SWD modality, using [Tools]>[Settings...]. If log files are saved, it is possible to set the level of debug information to save (for SWD only). All log files are saved to {installation path}\ST\RF-Flasher Utility x.x.x\Logs\.
- Mass erase, using [Tools]>[Mass erase].
- Verify flash memory content [Tools]>[Verify flash content].
- Get the application version, using [Help]>[About].
- Download a file, using [Tools]>[Flash].
- Erase device sectors, using [Tools]>[Erase Pages...]
- Compare device memory with the selected image file, using [Tools]>[Compare Device Memory with file]. The two image files are displayed in the *Compare Device Memory with Image File* tab and the related differences are highlighted in red.
- Compare two files, using [File]>[Compare two files]
- Read bootloader sector (only in SWD mode), using [Tools]>[Read Bootloader Sector (SWD)].
- Read OTP area (only in SWD mode), using [Tools]>[Read OTP Area (SWD)].
- Save bootloader sectors or OTP area in a .bin file, using [File]>[Save File As...].

The user can also select two image files and compare them. The two image files are displayed in the *Compare Two Files* tab and the related differences are highlighted in red. .bin and .hex file formats are supported.

Figure 2. Compare Two Files tab



DT73425V2

In the upper section of the RF-Flasher utility main window, the user can select the image file through the [**Select Image File**] button. The user can select the type of memory: flash memory, bootloader, or OTP area. For the flash memory area, the user can set the start address (only for the bin file)

All these options are available in UART and SWD mode.


The user needs to enable access to the selected mode (UART or SWD). They can do this by opening the associated COM port for UART mode, or by connecting an SWD hardware programming/debugging tool to the device SWD lines.

## 4 UART main window

In the UART main window tab of the RF-Flasher utility main window, the user can select the COM port to be used to interface the device through the *List of COM Ports* section.

The serial baud rate used for the RF device evaluation board is 460800 bps.

**Figure 3. Flasher utility UART main window**



### 4.1 UART mode: how to run

#### Image file selection

To load an existing `.bin` or `.hex` file, use the **[Select Image File]** button on the main page, navigate to **[File]>[Open File...]**, or go to the *Image File* tab. The full path of the selected file appears next to the button and the **[Flash]** button becomes active when the file has loaded.

The *List of COM Ports* tab displays all connected devices on the PC USB ports. The **[Select All]**, **[Unselect All]**, and **[Invert All]** buttons let the user define which connected devices (all, none, or some of them) should be the target of the utility operations. This way, the same operation (that is, flash memory programming) can be performed simultaneously on multiple devices. The **[Refresh]** button allows the user to refresh the list of connected devices.

By default, the **[Mass erase]** option in the **[Actions]** section is not checked, and only the required memory pages are erased and written with the file content. When this option is checked, a full mass erase precedes the flash memory programming phase.

The **[Verify]** option forces a check to ensure that the memory content has been written correctly.

Check the **[Update Device Memory]** option to update the device memory table after an operation on the flash memory.


The readout protection option enables readout protection of the device after flash memory programming.

Check the **[Auto Baudrate]** option only if a hardware reset is performed on the board to force the **[Auto Baudrate]** operation. By default, the **[Auto Baudrate]** option is not checked.

#### The *Image File* tab

The selected file name, size, and parsed contents to be programmed in the device flash memory can be viewed in the *Image File* tab.


Figure 4. Flasher utility UART mode: Image File tab



### The Device Memory tab

Select this tab to view the memory contents of a connected device (through the **[Read]** button) and the log containing operations performed on the selected device.

Figure 5. Flasher utility UART mode: Device Memory tab



Click on the **[Read]** button to transfer the memory segment defined by **[Start Address and Size]** into the table.


To read the entire flash memory, check the **[Entire Memory]** option.

The first column gives the base address of the following 16 bytes in a row (for example, row 0x10040050, column 4 holds the hexadecimal byte value at 0x10040054. The user can change the byte values by double-clicking a cell and entering a new hexadecimal value. Edited bytes appear in red.

Click on the **[Write]** button to program the entire page with the new byte values into the device flash memory.

The **[Flash]** button allows a flash memory programming operation to start with the selected option. If the **[MAC Address]** checkbox is checked, the user can specify the memory address where the selected MAC address is stored. When the **[Flash]** button is clicked on, the MAC address is programmed after the image file.

Figure 6. Flasher utility UART mode: changing memory fields




DT73429V2

## The Compare Device Memory with Image File tab

The user can compare the current device memory with the selected image file. The two image files are displayed and any differences are highlighted in red. .bin and .hex files format are supported.

Figure 7. Flasher utility UART mode: Compare Device Memory with Image File tab



DT73430V2




### Using the RF-Flasher utility with other boards

The RF-Flasher utility automatically detects the BlueNRG-1, BlueNRG-2, BlueNRG-LP, and BlueNRG-LPS evaluation boards (displayed as STDK) connected to the PC USB ports. It uses an auxiliary STM32 (driven by the GUI) to reset the device and put it in UART bootloader mode.

The application also works with custom boards, providing simple UART access to the connected device, but the user must put the device in bootloader mode manually. Upon the selection of any non-STEVAL COM ports, the following pop-up appears:

Figure 8. Flasher utility UART mode: UART Comport Setting pop-up



When this pop-up appears and depending on the device type, bootloader mode is activated as follows:

- For BlueNRG-LP and BlueNRG-LPS devices, the user must set the PA10 pin to a high value and perform a reset cycle of the device (keeping PA10 at a high value).
- For BlueNRG-1 and BlueNRG-2 devices, the user must set the DIO7 pin to a high value and reset the device (keeping DIO7 at a high value).

The user can also set a preferred baud rate for the UART in the pop-up window and then press OK to return to the GUI.

**Note:** The user must avoid resetting the device while using the RF-Flasher utility, unless the ComPort Setting pop-up is active. If the device is reset, the user must toggle the COM port to use the Flasher utility again.

**Note:** When custom boards are used by providing UART access to the BlueNRG-1, BlueNRG-2, BlueNRG-LP, and BlueNRG-LPS devices through a USB FTDI interface, the user should double-check the latency associated with the USB FTDI PC driver. This allows the connected port to be recognized as a USB virtual COM. On a typical USB-FTDI PC driver, double-check the related device USB driver settings in **[Properties]>[Port Settings]>[Advanced]**. Make sure that the latency timer value is set to 1 ms. This setting is strongly recommended to speed up flash memory operations on custom boards.

## 5 SWD main window

To use the SWD main window tab in the RF-Flasher utility main window, the user must connect the SWD hardware programming/debugging tool to the device SWD lines (BlueNRG-1, BlueNRG-2, BlueNRG-LP, and BlueNRG-LPS devices).

The following SWD hardware programming/debugging interfaces are supported, assuming that the selected hardware and related software tools support the connected device:

1. CMSIS-DAP
2. ST-LINK
3. J-Link


**Note:** To use the J-Link as a debug adapter, the USB driver needs to be changed from the J-Link driver to WinUSB. This can be done easily by using the tool **HYPERLINK** Zadig (<https://zadig.akeo.ie>) as follows:

- Select J-Link from the device list
- Select "WinUSB" as the driver
- Click on **[Install Driver]** to install the WinUSB driver

**Note:** Refer to the **HYPERLINK** J-Link OpenOCD website (<https://wiki.segger.com/OpenOCD>) for more information.

**Note:** **WARNING:** Once the J-Link USB driver has been replaced, no SEGGER software from the J-Link software package is able to communicate with J-Link. To use SEGGER J-Link software again, the USB driver needs to be switched back to its default.

**Figure 9. Flasher utility: SWD main window**



### 5.1 SWD mode: how to run

#### Image file selection

Use the **[Select Image File]** button on the main page or go to **[File]>[ Open File...]** to load an existing .bin or .hex file. The full path of the selected file appears next to the button and the **[Flash]** button becomes active at the end of the file loading.

In the **Actions** tab, the user can select the following options:

- **[Verify]**: forces a check to ensure that the memory content has been written correctly
- **[Readout protection]**: enables the device readout protection after programming the selected image file
- **[Mass erase]**: allows a mass erase of the device to be performed before programming the selected image file

- **[Update Device Memory]:** allows the device memory table to be updated after a flash memory programming operation
- **[Plug&Play mode]:** allows the plug-and-play flash memory programming mode to be enabled/disabled when only one SWD programming tool is available. In this case, boards are programmed one at a time. When the programming operation has completed on one board, it is possible to unplug it and plug another board.

By default, the **[Mass erase]** option next to the **[Flash]** button is not checked, and only the required memory pages are erased and written with the file content.

The **[List of connected interfaces]** tab displays all the connected SWD interfaces (CMSIS-DAP, ST-LINK, and J-Link). Press the **[Refresh]** button to update the list of connected interfaces.

The user can also select which specific SWD hardware interface must be displayed through the **[Interface]** field.

The **[Select All]**, **[Unselect All]**, and **[Invert All]** buttons allow the user to define which connected SWD interfaces (all, none, or some of them) should be the target of the utility operations. This way, the same operation (that is, flash memory programming) can be performed simultaneously on multiple devices.

The **[Flash]** button allows a flash memory programming operation to start with the selected option. If the **[MAC Address]** checkbox is checked, the user can specify the memory address where the selected MAC address is stored. When the **[Flash]** button is clicked on, the MAC address is programmed after the image file.


### 'Image File' tab

The selected file name, size, and parsed contents to be programmed in the device flash memory can be viewed in the *Image File* tab.

### The Device Memory tab

Select this tab to view the memory contents of a connected device (through the **[Read]** button) and the log containing operations performed on the selected device.

**Figure 10. Flasher utility SWD mode: Device Memory tab**



Click the **[Read]** button to transfer the memory segment defined by **[Start Address and Size]** into the table.

To read the entire flash memory, check the **[Entire Memory]** option.

The first column gives the base address of the following 16 bytes in a row (for example, row 0x10040050, column 4 holds the hexadecimal byte value at 0x10040054. The user can change byte values by double-clicking a cell and entering a new hexadecimal value. Edited bytes appear in red.

Click on the **[Write]** button to program the entire page with the new byte values into the device flash memory.

### Figure 11. Flasher utility SWD mode: changing memory fields



**Note:** *[Compare Device Memory to File]* is also supported in SWD mode, with the same features as described in [Section 4.1: UART mode: how to run](#).

## 5.2 SWD mode: read bootloader sector

The user can read the bootloader sector of the connected device through the SWD hardware programming interface by selecting **[Tools]>[Read Bootloader Sector (SWD)]**. The bootloader sector content is displayed in the *Bootloader/OTP* tab.

*Note: This feature is supported only in SWD mode and accessible only through the GUI.*

**Figure 12. Flasher utility SWD mode: read bootloader**




### 5.3 SWD mode: read OTP area

The user can read the OTP area connected device (where supported) through the SWD hardware programming interface by selecting **[Tools]>[Read OTP Area (SWD)]**. The OTP area content is displayed in the *Bootloader/OTP* tab.

**Note:** This feature is not supported in UART mode.

### Figure 13. Flasher utility SWD mode: read OTP



DT73436V2


## 6 SWD Plug&Play programming mode

The SWD Plug&Play programming mode allows the user to enter a programming loop by connecting a new device platform to be programmed. When the flash memory image file and programming actions have been selected, the Flasher PC application asks the user to connect a device to the SWD interface (a *Waiting for device N. 1* message is displayed).

When the user connects the device, a *Device N. 1 connected* message is displayed, and the application starts programming the device with the selected image file and options. When the programming operation has finished, the Flasher application displays the message *Please disconnect device N. 1*. When the user disconnects the device, the message *Waiting for device N. 2* is displayed. The user can stop this automatic mode by pressing the [Stop] button.

When using the Plug&Play mode, the user must select the interface to be used (CMSIS-DAP, ST-LINK, or J-Link).

Figure 14. Flasher utility: SWD Plug&Play mode



DT73437V2

## 7 MAC address programming

MAC address programming allows the MAC address to be stored in a specific flash memory location on the device.

The user can choose to enable this option or not by checking or unchecking the **[MAC address]** checkbox. The specific flash memory location is set through the **[MAC Flash location]** field.

The **[Set MAC address]** button allows the user to select the MAC address as follows:

1. Check the **[Range]** checkbox and provide the start address in the **[Start Address]** field. The start address is the MAC address to be stored on the first connected device.
  - It is possible to set incremental steps starting from the **[Start Address]** value by entering the number of boards to be programmed in the *Num. Boards* tab, or by entering the **[End Address]** value:
    - If automatic mode has been selected in the *Actions* tab, the selected MAC address list is used for the automatic programming operations. If not, only one device is programmed, using the **[Start Address]** field.
2. The user can provide a list of MAC addresses to be used through an input file:
  - Check the **[File]** checkbox and select the input text file in the **[Load File]** field.
  - If automatic mode has been selected in the *Actions* tab, the selected MAC address list is used for the automatic programming operations. If not, only the first address is used for a single programming operation.

The **[Save MAC Address log]** checkbox allows the list of used MAC addresses to be stored in a file, selected in the **[File Name]** field.

MAC address programming can be combined with the automatic programming mode. For each connected device, the image file is programmed first, followed by the MAC address. The number of selected MAC addresses (incremental address list size or input file size) triggers the end of the automatic programming operations. Each programmed MAC address is displayed in the *Log* window.


MAC address programming is supported in UAR and SWD mode.

Figure 15. Flasher utility: MAC address selection

The screenshot shows the 'ST MAC Address' dialog box. It has a title bar with the ST logo and the text 'MAC Address'. Below the title bar, there are two tabs: 'Range' (selected) and 'File'. The 'Range' tab contains three input fields: 'Start Address' with the value '0x112233445566' and '(hex)' next to it, 'End Address' with the value '0x1122334455c9' and '(hex)' next to it, and 'Num. Boards' with the value '100' and a spinner control. The 'File' tab contains a 'Load File' label and a text input field with a file selection icon (three dots). At the bottom of the dialog are 'OK' and 'Cancel' buttons.


DT73438V2

Figure 16. Flasher utility: UART MAC address programming



DT73439V2

Figure 17. Flasher utility: SWD MAC address programming



DT73440V2

The user can select whether or not a timestamp is added to the saved MAC address log file name (as a suffix). If the timestamp is not added to the name of the log file, all log information is saved in the same log file. If the timestamp is added, the log information for each run is saved in a different log file. The name of the log file can be specified using the [File Name] field.



## 8 RF-Flasher launcher utility

The RF-Flasher launcher is a standalone utility allowing the user to run RF-Flasher utility commands using the RF-Flasher utility GUI.

A DOS command window is required and both UART and SWD modes are supported (using `.bin` and `.hex` image files).

The RF-Flasher launcher utility (`RF-Flasher_Launcher.exe`) is included in the RF-Flasher utility software package within the application folder. The "Release folder" in the RF-Flasher utility software package start menu item (ST RF-Flasher utility x.x.x) allows direct access to the application folder.

### 8.1 Requirements

In order to use the RF-Flasher launcher utility on a specific device, the following prerequisites must be met:

- UART mode: the BlueNRG-1, BlueNRG-2, BlueNRG-LP, or BlueNRGLPS platform must be connected to a PC USB port
- SWD mode: an SWD hardware programming/debugging tool must be connected to the BlueNRG-1, BlueNRG-2, BlueNRG-LP, or BlueNRG-LPS SWD lines.

**Note:** *With the `-l` option, all operation steps are tracked in log files, stored in the "Logs" folder, which is created in the RF-Flasher utility software package "Application" folder.*

### 8.2 RF-Flasher launcher utility options

To use the RF-Flasher launcher utility on a specific device, the user must open a Windows DOS shell and launch `RF-Flasher_Launcher.exe` with the proper command, and options (use `-h` to get a list of all supported options).

```
RF-Flasher_Launcher.exe -h:
```

**Usage:** RF-Flasher Launcher [-h]

```
{flash, read, mass_erase, verify_memory, erase_pages, uart, swd, read_OTP, write_OTP}
```

RF-Flasher launcher version x.x.x.

**Optional arguments:**

- `-h, --help`: show this help message and exit

**Commands:**

```
{flash, read, mass_erase, verify_memory, erase_pages, uart, swd, read_OTP, write_OTP}
```

- `flash`: program a flash memory
- `read`: read a flash memory
- `mass_erase`: erase a flash memory
- `verify_memory`: verify the content of an RF device with a file
- `erase_pages`: erase one or more pages from a flash memory
- `uart`: show all connected COM ports (UART mode)
- `swd`: show all devices connected via the SWD interface: ST-LINK, CMSIS-DAP, J-Link (SWD mode)
- `read_OTP`: read OTP area (only in SWD mode)
- `write_OTP`: write OTP area (only in SWD mode)

### 8.3 RF-Flasher launcher utility: UART & SWD modes

The RF-Flasher launcher utility supports two operating modes:

- UART mode (connect the selected device to a PC USB port)
- SWD mode (connect the selected BlueNRG-1, BlueNRG-2, BlueNRG-LP, or BlueNRG-LPS device SWD lines to a SWD programming/debugging tool).

RF-Flasher launcher utility: use the `uart` command to get a list of all available COMx ports (devices connected to the PC USB ports):

```
RF-Flasher_Launcher.exe uart
CONNECTED PORT = COM194 (ST DK), COM160 (ST DK)
RF-Flasher launcher utility: use the swd command to get a list of all available connected SWD hardware
programming/debugging tools:
RF-Flasher_Launcher.exe swd
CONNECTED BY ST-LINK = NO ST-LINK CONNECTED
CONNECTED BY CMSIS-DAP (serial number of CMSIS-DAP interfaces):
1) 07200001066fff333231545043084259a5a5a5a597969908
2) 07200001066dff383930545043205830a5a5a5a597969908
3) 07200001066dff333231545043084255a5a5a5a597969908
CONNECTED BY J-Link = NO J-Link CONNECTED
```

## 8.4 RF-Flasher launcher utility: flash command

To use the RF-Flasher launcher utility to program a specific device flash memory, the `flash` command is available (us the `-h` option to get a list of all supported options):

```
>RF-Flasher_Launcher.exe flash -h
```

### Flash command usage

```
RF-Flasher_Launcher.exe flash [-h] [-address START_ADDRESS] [-f FILE_TO_FLASH
[FILE_TO_FLASH, ...]] [-erase] [-verify] [-rp] [-mac] [-mac_address MAC_ADDRESS] [-
mac_log_file MAC_LOG_FILE] [-mac_start MAC_START_ADDRESS | -mac_file
MAC_FILE_ADDRESS] (-all | -d DEVICE_ID) [-verbose {0, 1, 2, 3, 4}] [-l] (-UART |
-SWD) [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}]
```

### Flash command optional arguments

- `-address START_ADDRESS, --address START_ADDRESS`: start address.
- `-all, --all`: all connected devices (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-erase, --erase`: enable the **[Mass Erase]** option.
- `-f FILE_TO_FLASH [FILE_TO_FLASH ...], --fileToFlash FILE_TO_FLASH [FILE_TO_FLASH ...]`: list of `.bin` or `.hex` files to program the RF device: a BlueNRG-1, BlueNRG-2, BlueNRG-LP, or BlueNRG-LPS device.
- `frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-mac, --mac`: enable the **[Mac Address]** option.
- `-mac_address --MAC_ADDRESS`: the flash memory location where the Bluetooth® public address is stored.
- `-mac_file MAC_FILE_ADDRESS, --mf MAC_FILE_ADDRESS`: file containing a list of MAC addresses.
- `-mac_log_file MAC_LOG_FILE, --ml MAC_LOG_FILE`: files containing the logs of stored/unstored and used/unused MAC addresses.
- `-mac_start MAC_START_ADDRESS, --ms MAC_START_ADDRESS`: first MAC address.
- `-rp, --readout_protection`: enable the **[ReadOut Protection]** option.
- `-SWD, --swd`: SWD modality (ST-LINK, CMSIS-DAP, J-Link hardware programming/debugging tool).
- `-UART, --uart`: UART mode. A custom board must be put in bootloader mode (DIO7 pin value high while performing a reset cycle of the BlueNRG-1 or BlueNRG-2 device; PA10 pin value high while resetting a BlueNRG-LP or BlueNRG-LPS device) before performing the operation.

- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.
- `-verify, --verify`: enable the **[Verify]** option.

**Note:**

- *If UART mode is selected, the device must be connected to a PC USB COM port and the `-UART` option must be used. If more than one device is connected to PC USB ports, the `-all` option allows all of them to be selected. Alternatively, the user can specify each COM port using the `-d` option.*
- *If SWD mode is selected, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines, and it is necessary to use the `-SWD` option. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.*

- *The binary file to be loaded is specified using the `-f` option. If the user wants to program the BlueNRG-1, BlueNRG-2, BlueNRG-LP, or BlueNRG-LPS devices with different binary files during the same programming session, they can specify the respective binary images following this order: BlueNRG-1, BlueNRG-2, BlueNRG-LP, BlueNRG-LPS.*

```
RF-Flasher_Launcher.exe flash -UART -all
```

```
-f "C:\{user_path}\BlueNRG-1_2 DK
```

```
3.2.2\Firmware\BlueNRG1_Periph_Examples\Micro\Hello_World\BlueNRG-1\Micro_Hello_World.bin"
```

```
-f "C:\{user_path}\BlueNRG-1_2 DK
```

```
3.2.2\Firmware\BlueNRG1_Periph_Examples\Micro\Hello_World\BlueNRG-2\Micro_Hello_World.bin" -l
```

```
-f "C:\{user_path}\BlueNRG-LP DK 1.4.0\Firmware
```

```
\Peripheral_Examples\Examples_MIX\MICRO\MICRO_Hello_World\STEVAL-IDB011V1\Micro_Hello_World.bin"
```

```
-f "C:\{user_path}\BlueNRG-LP DK 1.4.0\Firmware
```

```
\Peripheral_Examples\Examples_MIX\MICRO\MICRO_Hello_World\STEVAL-IDB012V1\Micro_Hello_World.bin"
```

*The first file is programmed on the connected BlueNRG-1 devices; the second file is programmed on the connected BlueNRG-2 devices; the third file is programmed on the connected BlueNRG-LP devices; the fourth file is programmed on the connected BlueNRG-LPS devices.*

- *If the `-f` option is not used, the binary images files specified in `Application/config_file.conf` are used:*

```
#Image file for BlueNRG_1 device
```

```
BLUENRG_1 = "user_path"/bluenrg_1_binary_file.hex
```

```
#Image file for BlueNRG_2 device
```

```
BLUENRG_2 = "user_path"/bluenrg_2_binary_file.hex
```

```
#Image file for BlueNRG_LP device
```

```
BLUENRG_LP = "user_path"/bluenrg_lp_binary_file.hex
```

```
#Image file for BlueNRG_LPS device
```

```
BLUENRG_LPS = "user_path"/bluenrg_lps_binary_file.hex
```

*The user must specify the full binary image path for each device.*

## 8.5 RF-Flasher launcher utility: read command

To use the RF-Flasher launcher utility to read a specific device flash memory, the `read` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe read -h
```

### Read command usage

```
RF-Flasher_Launcher.exe read [-h] [-address START_ADDRESS] [-size SIZE] [-entire] [-s] (-all | -d DEVICE_ID) (-UART | -SWD) [-verbose {0, 1, 2, 3, 4}] [-l] [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}]
```

### Read command optional arguments

- `-address START_ADDRESS, --address START_ADDRESS`: start address (the default value is 0x10040000).
- `-all, --all`: all connected devices (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).

- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-entire, --entire`: read the entire flash memory.
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-s, --show`: show the flash memory after a read operation.
- `-size SIZE, --size SIZE`: size of the flash memory to read (the default value is 0x3000).
- `-SWD, --swd`: SWD modality (ST-LINK, CMSIS-DAP, J-Link hardware programming/debugging tool).
- `-UART, --uart`: UART modality. Custom boards must be put in bootloader mode before performing this operation. For BlueNRG-LP and BlueNRG-LPS devices, the user must set the PA10 pin to a high value and perform a reset cycle of the device, keeping PA10 at a high value. For BlueNRG-1 and BlueNRG-2 devices, the user must set the DIO7 pin to a high value and reset the device, keeping DIO7 at a high value.
- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

**Note:**

- *If UART mode is selected, the device must be connected to a PC USB COM port and the `-UART` option must be used. If more than one device is connected to PC USB ports, the `-all` option allows all of them to be selected. Alternatively, the user can specify each COM port using the `-d` option.*
- *If SWD mode is selected, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines, and it is necessary to use the `-SWD` option. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.*

## 8.6 RF-Flasher launcher utility: mass erase command

To use the RF-Flasher launcher utility to perform a mass erase of the flash memory of a specific device, the `mass_erase` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe mass_erase -h
```

### Mass erase command usage

```
RF-Flasher_Launcher.exe mass_erase [-h] [-s] (-all | -d DEVICE_ID) (-UART | -SWD) [-verbose {0, 1, 2, 3, 4}] [-l][-frequency {5,15,25,50,100,125,240,480,900,1800,4000}]
```

### Mass erase command optional arguments

- `-all, --all`: all connected devices (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-s, --show`: show the flash memory after a mass erase operation.
- `-SWD, --swd`: SWD modality (ST-LINK, CMSIS-DAP, J-Link hardware programming/debugging tool).
- `-UART, --uart`: UART modality. Custom boards must be put in bootloader mode before performing this operation. For BlueNRG-LP and BlueNRG-LPS devices, the user must set the PA10 pin to a high value and perform a reset cycle of the device, keeping PA10 at a high value. For BlueNRG-1 and BlueNRG-2 devices, the user must set the DIO7 pin to a high value and reset the device, keeping DIO7 at a high value.
- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

Note:

- If UART mode is selected, the device must be connected to a PC USB COM port and the `-UART` option must be used. If more than one device is connected to PC USB ports, the `-all` option allows all of them to be selected. Alternatively, the user can specify each COM port using the `-d` option.
- If SWD mode is selected, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines, and it is necessary to use the `-SWD` option. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.

## 8.7

### RF-Flasher launcher utility: verify memory command

To use the RF-Flasher launcher utility to verify the flash memory content of a specific device, the `verify_memory` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe verify_memory -h
```

#### Verify memory command usage

```
RF-Flasher_Launcher.exe verify_memory [-h] -f FLASH_VERIFY_FILE[-s] [-address START_ADDRESS] (-all | -d DEVICE_ID) [-verbose {0, 1, 2, 3, 4}] [-l] (-UART | -SWD) [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}]
```

#### Verify memory command optional arguments

- `-address START_ADDRESS`, `--address START_ADDRESS`: start address for verification (for `.bin` files only). The default value is `0x10040000`.
- `-all`, `--all`: all connected devices (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID`, `--device DEVICE_ID`: set the ID of the hardware tool used for the connection (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-f FLASH_VERIFY_FILE`, `--file FLASH_VERIFY_FILE`: file to be used to verify the flash memory
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}`, `--frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is `4000`.
- `-h`, `--help`: show this help message and exit
- `-l`, `--log`: log data.
- `-s`, `--show`: show the flash memory after a verify operation
- `-SWD`, `--swd`: SWD mode (ST-LINK, CMSIS-DAP, J-Link hardware programming/debugging tool).
- `-UART`, `--uart`: UART mode.
- `-verbose {0, 1, 2, 3, 4}`, `--verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

Note:

- If UART mode is selected, the device must be connected to a PC USB COM port and the `-UART` option must be used. If more than one device is connected to PC USB ports, the `-all` option allows all of them to be selected. Alternatively, the user can specify each COM port using the `-d` option.
- If SWD mode is selected, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines, and it is necessary to use the `-SWD` option. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.

## 8.8

### RF-Flasher launcher utility: erase pages command

To use the RF-Flasher launcher utility to erase a flash memory content page from a specific device, the `erase_pages` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe erase_pages -h
```

#### Erase pages command usage

```
RF-Flasher_Launcher.exe erase_pages [-h] (-UART | -SWD) (-all | -d DEVICE_ID) [-l] [-verbose {0, 1, 2, 3, 4}] [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}] [-s] (-p PAGES | -range RANGE RANGE)
```

### Erase pages command optional arguments

- `-all, --all`: all connected devices (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (COM port in UART mode; ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-p PAGES, --page PAGES`: list of pages to erase (starts at 0).
- `-range RANGE RANGE, --range RANGE RANGE`: range of pages to erase (where the first RANGE indicates the smallest page number and the second RANGE indicates the highest page number).
- `-s, --show`: show the flash memory after a verify operation.
- `-SWD, --swd`: SWD modality (ST-LINK, CMSIS-DAP, J-Link hardware programming/debugging tool).
- `-UART, --uart`: UART modality. Custom boards must be put in bootloader mode before performing this operation. For BlueNRG-LP and BlueNRG-LPS devices, the user must set the PA10 pin to a high value and perform a reset cycle of the device, keeping PA10 at a high value. For BlueNRG-1 and BlueNRG-2 devices, the user must set the DIO7 pin to a high value and reset the device, keeping DIO7 at a high value.
- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

Note:

- *If UART mode is selected, the device must be connected to a PC USB COM port and the `-UART` option must be used. If more than one device is connected to PC USB ports, the `-all` option allows all of them to be selected. Alternatively, the user can specify each COM port using the `-d` option.*
- *If SWD mode is selected, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines, and it is necessary to use the `-SWD` option. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.*

## 8.9 RF-Flasher launcher utility: read OTP command

To use the RF-Flasher launcher utility to read the OTP of a specific device, the `read_OTP` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe read_OTP -h
```

### Read OTP command usage

```
RF-Flasher_Launcher.exe read_OTP [-h] (all | -d DEVICE_ID) [-address OTP_ADDRESS]
[-num NUM] [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}] [-l] [-s] [-
verbose {0,1,2,3,4}]
```

### Read OTP command optional arguments

- `-address OTP_ADDRESS, --address OTP_ADDRESS`: address of the OTP area (default: 0x10001800 - word aligned).
- `-all, --all`: all connected devices (ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-num NUM, --number NUM`: number of words to read inside the OTP area. The default value is 256.



- `-s, --show`: show the OTP area.
- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

**Note:** *The `read_OTP` command only works in SWD mode. Therefore, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.*

## 8.10 RF-Flasher launcher utility: write OTP command

To use the RF-Flasher launcher utility to read the OTP of a specific device, the `write_OTP` command is available (use `-h` to get a list of all supported options):

```
RF-Flasher_Launcher.exe write_OTP -h
```

### Write OTP command usage

```
RF-Flasher_Launcher.exe write_OTP [-h] (all | -d DEVICE_ID) -address OTP_ADDRESS  
-value OTP_VALUE [-frequency {5,15,25,50,100,125,240,480,900,1800,4000}] [-l] [-  
verbose {0,1,2,3,4}]
```

### Write OTP command optional arguments

- `-address OTP_ADDRESS, --address OTP_ADDRESS`: address of the OTP area (default: 0x10001800 - word aligned).
- `-all, --all`: all connected devices (ST-LINK ID, CMSIS-DAP ID, and J-link ID in SWD mode).
- `-d DEVICE_ID, --device DEVICE_ID`: set the ID of the hardware tool used for the connection (ST-LINK ID, CMSIS-DAP ID, and J-Link ID in SWD mode).
- `-frequency {5,15,25,50,100,125,240,480,900,1800,4000}, --frequency {5,15,25,50,100,125,240,480,900,1800,4000}`: set frequency value (only for SWD modality - ST-LINK hardware). The default value is 4000.
- `-h, --help`: show this help message and exit.
- `-l, --log`: log data.
- `-s, --show`: show the flash memory after a verify operation.
- `-value OTP_VALUE, --value OTP_VALUE`: OTP value (a word, such as 0x11223344)
- `-verbose {0, 1, 2, 3, 4}, --verbose {0, 1, 2, 3, 4}`: increase output verbosity; set debug level up to 4 (only for SWD modality and log data). The default value is 2.

**Note:** *The `write_OTP` command only works in SWD mode. Therefore, an SWD hardware programming/debugging tool must be connected to the selected device SWD lines. If more than one device is connected to the PC through the SWD interface, the `-all` option allows all of them to be selected. Alternatively, the user can specify each interface using the `-d` option.*

## 8.11 RF-Flasher launcher utility: examples

Program a binary image on the connected BlueNRG-1 and BlueNRG-2 devices with an ST-LINK hardware tool (in SWD mode):

```
RF-Flasher_Launcher.exe flash -SWD -all -f "User_Application.hex" -l
```

Program a binary image on the connected Bluetooth® Low Energy devices via the USB COM ports (in UART mode):

```
RF-Flasher_Launcher.exe flash -UART -all -f "User_Application.hex" -l
```

Program a binary image on the connected devices via the CMSIS-DAP channel using the erase, verify, and log data options (in SWD mode):

Figure 18. RF-Flasher launcher: flash command with `-erase`, `-l`, `-verify` option

```

Command Prompt
C:\RF-Flasher_Launcher>RF-Flasher_Launcher.exe flash -swd -all -erase -verify -f C:\MICRO_Hello_World.bin -l

Working on SWD (serial number of interfaces) :
1) \x30\x30\x33\x41\x30\x32\x35\x33\x33\x31\x35\x31\x31\x39\x34\x33\x33\x38\x33\x34

08:53:39.390: ST-Link A -> Call FlashBoardSWD
08:53:39.393: ST-Link A -> Waiting device to flash...
08:53:39.648: ST-Link A -> Device to flash connected
08:53:39.872: ST-Link A -> Call identifyDeviceSWD
08:53:39.875: ST-Link A -> Device Identification: SUCCESS (STM32WB09)
08:53:40.102: ST-Link A -> Call analyzedSWDLog
08:53:40.104: ST-Link A -> Mass Erase Operation: SUCCESS
08:53:40.364: ST-Link A -> Call analyzedSWDLog
08:53:40.366: ST-Link A -> Device Flash Programming: SUCCESS
08:53:40.366: ST-Link A -> Device Flash Programmed in 0.259607 sec.
08:53:40.596: ST-Link A -> Call analyzedSWDLog
08:53:40.598: ST-Link A -> Device Flash Verify Operation: SUCCESS
08:53:40.832: ST-Link A -> Device Disconnection: SUCCESS

**** INPUT PARAMETERS FOR FLASH OPERATION****

- OPERATING MODE = SWD
- ALL CONNECTED DEVICES = True
- FREQUENCY = 4000
- BLUENRG-1 DEVICE FILE = C:\MICRO_Hello_World.bin
- BLUENRG-2 DEVICE FILE = C:\MICRO_Hello_World.bin
- BLUENRG-LP DEVICE FILE = C:\MICRO_Hello_World.bin
- BLUENRG-LPS DEVICE FILE = C:\MICRO_Hello_World.bin
- STM32WB09 DEVICE FILE = C:\MICRO_Hello_World.bin
- VERIFY = True
- MASS ERASE = True
- START ADDRESS = 0x10040000 (only for .bin image file)
- READOUT PROTECTION = False
- MAC ADDRESS OPTION = False
- LOG = True
- LOG PATH = C:\Logs\20230611_085339
- VERBOSE = 2

**** RESULTS OF FLASH OPERATION ***

1 - Device connected A (\x30\x30\x33\x41\x30\x32\x35\x33\x33\x31\x35\x31\x31\x39\x34\x33\x33\x38\x33\x34)
Type of Connection = ST-Link
Type of Device = STM32WB09
Command -> FLASH = Success
File = C:\MICRO_Hello_World.bin
LIST OF OPTION -> IDENTIFICATION = Success, MASS_ERASE = Success, VERIFY = Success

C:\RF-Flasher_Launcher>

```



## Revision history

**Table 3. Document revision history**

Date	Version	Changes
15-May-2018	1	Initial release.
03-Jul-2018	2	Updated Figure 1. BlueNRG-1, BlueNRG-2 Flasher Utility, Figure 2. Flasher Utility UART main window, Figure 3. Flasher utility UART mode: image file , Figure 4. Flasher utility UART mode: device memory , Figure 5. Flasher utility UART mode: changing memory fields, Figure 7. Flasher Utility: SWD main window, Figure 8. Flasher Utility SWD mode: device memory , Figure 10. Flasher Utility: SWD automatic mode, Figure 11. Flasher utility: UART automatic mode, Figure 12. Flasher utility: UART automatic programming is completed and Figure 13. Flasher Utility: SWD MAC address selection. Minor text changes throughout the document.
26-Feb-2019	3	Updated the Section Introduction and Section 3.1 UART mode: how to run. Added Section 8 Flasher launcher utility and all its sub sections.
09-Apr-2019	4	Added reference to "Application folder" in <a href="#">Section 8: RF-Flasher launcher utility</a> . Updated <a href="#">Section 8.4: RF-Flasher launcher utility: flash command</a> .
14-Jul-2020	5	Changed BlueNRG-1 and BlueNRG-2 to BlueNRG-X Flasher software package Added reference to BlueNRG-LP device. Updated <a href="#">Figure 1. RF-Flasher utility</a> , <a href="#">Figure 3. Flasher utility UART main window</a> , <a href="#">Figure 5. Flasher utility UART mode: Device Memory tab</a> , <a href="#">Figure 6. Flasher utility UART mode: changing memory fields</a> , <a href="#">Figure 9. Flasher utility: SWD main window</a> , <a href="#">Figure 10. Flasher utility SWD mode: Device Memory tab</a> , <a href="#">Figure 14. Flasher utility: SWD Plug&amp;Play mode</a> , <a href="#">Figure 15. Flasher utility: MAC address selection</a> and <a href="#">Figure 18. RF-Flasher launcher: flash command with –erase, -l, -verify option</a>
05-Dec-2020	6	Updated <a href="#">Section Introduction</a> , <a href="#">Section 2.1: System requirements</a> , <a href="#">Section 4.1: UART mode: how to run</a> , <a href="#">Section 5: SWD main window</a> , <a href="#">Section 5.1: SWD mode: how to run</a> , <a href="#">Section 8.1: Requirements</a> , <a href="#">Section 8.2: RF-Flasher launcher utility options</a> , <a href="#">Section 8.3: RF-Flasher launcher utility: UART &amp; SWD modes</a> , <a href="#">Section 8.4: RF-Flasher launcher utility: flash command</a> , <a href="#">Section 8.5: RF-Flasher launcher utility: read command</a> , <a href="#">Section 8.6: RF-Flasher launcher utility: mass erase command</a> , <a href="#">Section 8.7: RF-Flasher launcher utility: verify memory command</a> . Added <a href="#">Section 8.8: RF-Flasher launcher utility: erase pages command</a> .
04-Oct-2021	7	Added <a href="#">Section 5.2: SWD mode: read bootloader sector</a> and <a href="#">Section 5.3: SWD mode: read OTP area</a> . Updated the title, <a href="#">Section Introduction</a> , <a href="#">Section 2: Getting started</a> , <a href="#">Section 2.1: System requirements</a> , <a href="#">Section 2.2: Software package setup</a> , <a href="#">Section 3: Toolbar interface</a> , <a href="#">Section 4: UART main window</a> , <a href="#">Section 8: RF-Flasher launcher utility</a> , <a href="#">Section 8.1: Requirements</a> , <a href="#">Section 8.2: RF-Flasher launcher utility options</a> , <a href="#">Section 8.3: RF-Flasher launcher utility: UART &amp; SWD modes</a> , <a href="#">Section 8.4: RF-Flasher launcher utility: flash command</a> , <a href="#">Section 8.5: RF-Flasher launcher utility: read command</a> , <a href="#">Section 8.6: RF-Flasher launcher utility: mass erase command</a> , <a href="#">Section 8.7: RF-Flasher launcher utility: verify memory command</a> , <a href="#">Section 8.8: RF-Flasher launcher utility: erase pages command</a> , <a href="#">Section 1.1: List of acronyms</a> and <a href="#">Section 1.2: Reference documents</a> .

Date	Version	Changes
		Updated Figure 1. RF-Flasher utility, Figure 2. Compare Two Files tab, Figure 3. Flasher utility UART main window, Figure 4. Flasher utility UART mode: Image File tab, Figure 5. Flasher utility UART mode: Device Memory tab, Figure 6. Flasher utility UART mode: changing memory fields, Figure 7. Flasher utility UART mode: Compare Device Memory with Image File tab, Figure 9. Flasher utility: SWD main window, Figure 10. Flasher utility SWD mode: Device Memory tab, Figure 16. Flasher utility: UART MAC address programming, Figure 17. Flasher utility: SWD MAC address programming and Figure 18. RF-Flasher launcher: flash command with – erase, -l, -verify option.
06-Apr-2022	8	Added the BlueNRG-LPS reference throughout the document. Updated Section 8.3: RF-Flasher launcher utility: UART & SWD modes and Section 8.4: RF-Flasher launcher utility: flash command.
10-Jul-2024	9	Updated: <ul style="list-style-type: none"> <li>• Document title</li> <li>• Section Introduction</li> <li>• Section 1.1: List of acronyms</li> <li>• Section 1.2: Reference documents</li> <li>• Figure 1. RF-Flasher utility</li> <li>• Section 3: Toolbar interface</li> <li>• Figure 3. Flasher utility UART main window</li> <li>• Section 4.1: UART mode: how to run</li> <li>• Section 5: SWD main window</li> <li>• Section 5.1: SWD mode: how to run</li> <li>• Figure 12. Flasher utility SWD mode: read bootloader</li> <li>• Section 5.3: SWD mode: read OTP area</li> <li>• Figure 14. Flasher utility: SWD Plug&amp;Play mode</li> <li>• Section 7: MAC address programming</li> <li>• Section 8.1: Requirements</li> <li>• Section 8.2: RF-Flasher launcher utility options</li> <li>• Section 8.3: RF-Flasher launcher utility: UART &amp; SWD modes</li> <li>• Section 8.4: RF-Flasher launcher utility: flash command</li> <li>• Section 8.5: RF-Flasher launcher utility: read command</li> <li>• Section 8.6: RF-Flasher launcher utility: mass erase command</li> <li>• Section 8.7: RF-Flasher launcher utility: verify memory command</li> <li>• Section 8.8: RF-Flasher launcher utility: erase pages command</li> <li>• Section 8.9: RF-Flasher launcher utility: read OTP command</li> <li>• Section 8.10: RF-Flasher launcher utility: write OTP command</li> </ul>

## Contents

<b>1</b>	<b>General information</b>	<b>2</b>
1.1	List of acronyms	2
1.2	Reference documents	2
<b>2</b>	<b>Getting started</b>	<b>3</b>
2.1	System requirements	3
2.2	Software package setup	3
<b>3</b>	<b>Toolbar interface</b>	<b>4</b>
<b>4</b>	<b>UART main window</b>	<b>6</b>
4.1	UART mode: how to run	6
<b>5</b>	<b>SWD main window</b>	<b>10</b>
5.1	SWD mode: how to run	10
5.2	SWD mode: read bootloader sector	12
5.3	SWD mode: read OTP area	13
<b>6</b>	<b>SWD Plug&amp;Play programming mode</b>	<b>14</b>
<b>7</b>	<b>MAC address programming</b>	<b>15</b>
<b>8</b>	<b>RF-Flasher launcher utility</b>	<b>17</b>
8.1	Requirements	17
8.2	RF-Flasher launcher utility options	17
8.3	RF-Flasher launcher utility: UART & SWD modes	17
8.4	RF-Flasher launcher utility: flash command	18
8.5	RF-Flasher launcher utility: read command	19
8.6	RF-Flasher launcher utility: mass erase command	20
8.7	RF-Flasher launcher utility: verify memory command	21
8.8	RF-Flasher launcher utility: erase pages command	21
8.9	RF-Flasher launcher utility: read OTP command	22
8.10	RF-Flasher launcher utility: write OTP command	23
8.11	RF-Flasher launcher utility: examples	23
	<b>Revision history</b>	<b>25</b>

## List of figures

<b>Figure 1.</b>	RF-Flasher utility. . . . .	3
<b>Figure 2.</b>	Compare Two Files tab . . . . .	4
<b>Figure 3.</b>	Flasher utility UART main window . . . . .	6
<b>Figure 4.</b>	Flasher utility UART mode: Image File tab . . . . .	7
<b>Figure 5.</b>	Flasher utility UART mode: Device Memory tab . . . . .	7
<b>Figure 6.</b>	Flasher utility UART mode: changing memory fields . . . . .	8
<b>Figure 7.</b>	Flasher utility UART mode: Compare Device Memory with Image File tab . . . . .	8
<b>Figure 8.</b>	Flasher utility UART mode: UART Comport Setting pop-up. . . . .	9
<b>Figure 9.</b>	Flasher utility: SWD main window . . . . .	10
<b>Figure 10.</b>	Flasher utility SWD mode: Device Memory tab . . . . .	11
<b>Figure 11.</b>	Flasher utility SWD mode: changing memory fields . . . . .	12
<b>Figure 12.</b>	Flasher utility SWD mode: read bootloader . . . . .	12
<b>Figure 13.</b>	Flasher utility SWD mode: read OTP . . . . .	13
<b>Figure 14.</b>	Flasher utility: SWD Plug&Play mode . . . . .	14
<b>Figure 15.</b>	Flasher utility: MAC address selection . . . . .	15
<b>Figure 16.</b>	Flasher utility: UART MAC address programming . . . . .	16
<b>Figure 17.</b>	Flasher utility: SWD MAC address programming . . . . .	16
<b>Figure 18.</b>	RF-Flasher launcher: flash command with –erase, -l, -verify option . . . . .	24

**IMPORTANT NOTICE – READ CAREFULLY**

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to [www.st.com/trademarks](http://www.st.com/trademarks). All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2024 STMicroelectronics – All rights reserved