




### Introduction

This document describes the software stack for the **L9962** battery management IC, including device driver, interface, hardware abstraction layers, and utility macros. The stack provides a robust and portable solution for cell monitoring, current sensing, balancing, diagnostics, and configuration via I2C, with STM32 HAL as the reference platform.

# 1 Main modules description

## 1.1 Modules and dependencies overview


**Figure 1. Drivers architecture**



**Table 1. Dependencies table**

| Module            | Depends On   |
|-------------------|--|
| L9962 Driver      | L9962_interface, L9962_regmap, utils, commontypes, L9962_HAL_wrapper |
| L9962 Interface   | L9962_HAL_wrapper, commontypes, utils, L9962_regmap                  |
| L9962 HAL Wrapper | STM32 HAL, main.h, commontypes                                       |
| utils             | -  |
| commontypes       | -  |

**Figure 2. Dependencies diagram**



**Files:**

- L9962.c, L9962.h, L9962\_regmap.h

**Description:**

Implements all device-specific logic for the L9962, including cell monitoring, current measurement, balancing, threshold configuration, diagnostics, and NVM operations.

**Key data structures & types:**

- CELL\_FILTER\_T, CURR\_FILTER\_T, SC\_FILTER\_T, HS\_LS\_T, etc.
- Mask enums for VB, die temp, current, balancing, NTC, and cell events.

**Important functions:**

Initialization, enable/disable, configuration, measurement, diagnostics, NVM, FSM, and mask management.

## 1.2 L9962 interface module

**Files:**

- L9962\_interface.c, L9962\_interface.h

**Description:**

Handles I<sup>2</sup>C protocol, CRC calculation, register read/write, and device address management. Abstracts low-level communication for the driver.

**Key functions:**

- L9962\_write\_reg, L9962\_read\_reg, L9962\_crc\_use, L9962\_i2c\_crc\_check\_set/get, etc.

## 1.3 L9962 HAL wrapper module

**Files:**

- L9962\_HAL\_wrapper.c, L9962\_HAL\_wrapper.h

**Description:**

Microcontroller (MCU) abstraction layer for I<sup>2</sup>C, GPIO, and delay. Only this file needs to be ported for a new MCU.

**Key Functions:**

- HALWRP\_I2C\_write/read, HALWRAP\_read\_pin, HALWRAP\_write\_pin, HALWRP\_delay\_ms

**Hardware Resources:**

- I<sup>2</sup>C interface (e.g., hi2c2)
- GPIOs: WKP, NSHIP, FLTN, RDY

## 1.4 Utility macros module

### Files:

- utils.h, utils.c (currently empty)

### Description:

Provides essential macros for register and bitfield manipulation, used throughout the driver and interface layers.

### Key Macros:

- UTILS\_mask\_data(width, offset): Create a bitmask for a field.
- UTILS\_set\_field\_in\_reg(reg, field, field\_width, field\_offset): Set a field in a register.
- UTILS\_get\_field\_from\_reg(reg, field\_width, field\_offset): Extract a field from a register.
- UTILS\_SignExtendINT(data, dataSize): Sign-extend an integer value.

### Usage Example:

```
uint16_t reg;  
UTILS_set_field_in_reg(reg,value, 3, 5); // Set a 3-bit field at offset 5  
uint8_t field = UTILS_get_field_from_reg(reg,3, 5); // Extract the same field
```

### Note:

- utils.c is currently a placeholder for future utility function implementations.

## 2 L9962 driver function descriptions

### 2.1 Summary table

Table 2. Summary table

| Function name         | Purpose   |
|-----------------------|---|
| L9962_CELL_enable_set | Enable monitoring for selected cells via bitmask          |
| L9962_CELL_enable_get | Get current enabled cell bitmask                          |
| L9962_CELL_filter_set | Set cell voltage filter time constant                     |
| L9962_CELL_filter_get | Get cell voltage filter time constant                     |
| L9962_CELL_UV_set     | Set cell undervoltage thresholds and counter              |
| L9962_CELL_UV_get     | Get cell undervoltage thresholds and counter              |
| L9962_CELL_OV_set     | Set cell overvoltage thresholds and counter               |
| L9962_CELL_OV_get     | Get cell overvoltage thresholds and counter               |
| L9962_VB_enable_set   | Enable/disable VB monitoring and UVLO                     |
| L9962_VB_enable_get   | Get VB monitoring and UVLO enable status                  |
| L9962_NTC_enable_set  | Enable/disable NTC monitoring                             |
| L9962_NTC_enable_get  | Get NTC monitoring enable status                          |
| L9962_tmeas_set       | Set measurement period in ms                              |
| L9962_tmeas_get       | Get measurement period in ms                              |
| L9962_CURR_enable_set | Enable/disable current measurement and Coulomb counter    |
| L9962_CURR_enable_get | Get current measurement and Coulomb counter enable status |
| L9962_CURR_filter_set | Set current filter time constant                          |
| L9962_CURR_filter_get | Get current filter time constant                          |
| L9962_BAL_en_set      | Enable balancing for selected cells                       |
| L9962_BAL_en_get      | Get balancing enable bitmask                              |
| L9962_CB_enable_set   | Enable/disable charge/discharge circuit breaker           |
| L9962_CB_enable_get   | Get charge/discharge circuit breaker enable status        |
| L9962_VB_UV_set       | Set VB undervoltage threshold and counter                 |
| L9962_VB_OV_set       | Set VB overvoltage threshold and counter                  |
| L9962_VB_UV_get       | Get VB undervoltage threshold and counter                 |
| L9962_VB_OV_get       | Get VB overvoltage threshold and counter                  |
| L9962_NTC_OT_set      | Set NTC overtemperature thresholds and counter            |
| L9962_NTC_OT_get      | Get NTC overtemperature thresholds and counter            |
| L9962_NTC_UT_set      | Set NTC undertemperature threshold and counter            |
| L9962_NTC_UT_get      | Get NTC undertemperature threshold and counter            |
| L9962_VB_vs_sum_set   | Set VB vs sum threshold                                   |
| L9962_VB_vs_sum_get   | Get VB vs sum threshold                                   |
| L9962_NTC_MEAS_get    | Get NTC measurement value                                 |
| L9962_VB_diag_get     | Get VB diagnostic flags                                   |
| L9962_NTC_diag_get    | Get NTC diagnostic flags                                  |

| Function name                 | Purpose   |
|-------------------------------|---|
| L9962_VB_meas_get             | Get VB voltage measurement                        |
| L9962_Vcell_meas_get          | Get cell voltage measurement                      |
| L9962_DIE_TEMP_meas_C_get     | Get die temperature in Celsius                    |
| L9962_chipid_get              | Get silicon and metal ID                          |
| L9962_devaddr_get             | Get device address                                |
| L9962_CELL_sum_meas_get       | Get sum of all cell voltages                      |
| L9962_CELL_diag_get           | Get cell diagnostic flags                         |
| L9962_CURR_inst_meas_get      | Get instantaneous current measurement             |
| L9962_CURR_overcurr_set       | Set overcurrent thresholds and enable             |
| L9962_CURR_overcurr_get       | Get overcurrent thresholds and enable             |
| L9962_BAL_threshold_set       | Set balancing undervoltage threshold and counter  |
| L9962_BAL_threshold_get       | Get balancing undervoltage threshold and counter  |
| L9962_OVC_diag_get            | Get overcurrent diagnostic flags                  |
| L9962_VB_mask_set             | Set VB event/fault mask                           |
| L9962_VB_mask_get             | Get VB event/fault mask                           |
| L9962_DIE_T_mask_set          | Set die temperature event/fault mask              |
| L9962_DIE_T_mask_get          | Get die temperature event/fault mask              |
| L9962_CURR_mask_set           | Set current event/fault mask                      |
| L9962_CURR_mask_get           | Get current event/fault mask                      |
| L9962_DIE_TEMP_diag_get       | Get die temperature diagnostic flags              |
| L9962_BAL_mask_set            | Set balancing event/fault mask                    |
| L9962_BAL_mask_get            | Get balancing event/fault mask                    |
| L9962_BAL_diag_get            | Get balancing diagnostic flags                    |
| L9962_CB_mode_set             | Set charge/discharge circuit breaker mode (HS/LS) |
| L9962_CB_mode_get             | Get charge/discharge circuit breaker mode (HS/LS) |
| L9962_NTC_mask_set            | Set NTC event/fault mask                          |
| L9962_NTC_mask_get            | Get NTC event/fault mask                          |
| L9962_FUSE_ext_get            | Get fuse deployment status                        |
| L9962_CELLS_mask_set          | Set cell event/fault mask                         |
| L9962_CELLS_mask_get          | Get cell event/fault mask                         |
| L9962_CURR_short_set          | Set short-circuit detection parameters            |
| L9962_CURR_short_get          | Get short-circuit detection parameters            |
| L9962_CURR_short_diag_get     | Get short-circuit diagnostic flags                |
| L9962_FUSE_deploy             | Deploy fuse                                       |
| L9962_global_diag_get         | Get global diagnostic status                      |
| L9962_NVM_operation           | Perform NVM upload/download operation             |
| L9962_NVM_upload_cnt_get      | Get NVM upload counter                            |
| L9962_CURR_ADC_correction_get | Get current ADC gain correction factor            |
| L9962_CURR_ADC_correction_set | Set current ADC gain correction factor            |
| L9962_i2c_crc_check_set       | Enable/disable I2C CRC check                      |
| L9962_i2c_crc_check_get       | Get I2C CRC check enable status                   |

| Function name          | Purpose                         |
|------------------------|---------------------------------|
| L9962_CURR_cc_meas_get | Get Coulomb counter measurement |
| L9962_WAKEUP_set       | Enable/disable wake-up function |
| L9962_NSHIP_get        | Get nSHIP pin status            |
| L9962_RDY_get          | Get RDY pin status              |
| L9962_FLTN_get         | Get FLTN pin status             |
| L9962_FSM_go_to        | Set device to FSM state         |

## 2.2 Detailed descriptions

### L9962\_CELL\_enable\_set

- **Purpose:** Enable monitoring for selected cells using a bitmask.
- **Parameters:** *bit\_msk* (bitmask of cells to enable)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_enable\_get

- **Purpose:** Get the current enabled cell bitmask.
- **Parameters:** *bit\_msk* (pointer to store bitmask)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_filter\_set

- **Purpose:** Set the filter time constant for cell voltage measurements.
- **Parameters:** *Cell\_filter* (filter time constant)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_filter\_get

- **Purpose:** Get the current filter time constant for cell voltage measurements.
- **Parameters:** *Cell\_filter* (pointer to store filter time constant)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_UV\_set

- **Purpose:** Set undervoltage thresholds and counter for cell monitoring.
- **Parameters:** *th\_uV* (threshold in uV), *severe\_th\_uV* (severe threshold in uV), *cnt\_th* (counter threshold)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_UV\_get

- **Purpose:** Get undervoltage thresholds and counter for cell monitoring.
- **Parameters:** *th\_uV*, *severe\_th\_uV*, *cnt\_th* (pointers to store values)
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_OV\_set

- **Purpose:** Set overvoltage thresholds and counter for cell monitoring.
- **Parameters:** *th\_uV*, *severe\_th\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

### L9962\_CELL\_OV\_get

- **Purpose:** Get overvoltage thresholds and counter for cell monitoring.
- **Parameters:** *th\_uV*, *severe\_th\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

### L9962\_VB\_enable\_set

- **Purpose:** Enable or disable VB (battery voltage) monitoring and UVLO.
- **Parameters:** *en* (enable), *uvlo\_en* (UVLO enable)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_enable\_get**

- **Purpose:** Get VB monitoring and UVLO enable status.
- **Parameters:** *en*, *uvlo\_en* (pointers to store status)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_enable\_set**

- **Purpose:** Enable or disable NTC (temperature sensor) monitoring.
- **Parameters:** *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_enable\_get**

- **Purpose:** Get NTC monitoring enable status.
- **Parameters:** *en* (pointer to store status)
- **Returns:** Result code indicating success or error.

**L9962\_tmeas\_set**

- **Purpose:** Set the measurement period in milliseconds.
- **Parameters:** *time\_ms* (measurement period)
- **Returns:** Result code indicating success or error.

**L9962\_tmeas\_get**

- **Purpose:** Get the measurement period in milliseconds.
- **Parameters:** *time\_ms* (pointer to store period)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_enable\_set**

- **Purpose:** Enable or disable current measurement and Coulomb counter.
- **Parameters:** *inst\_en* (instantaneous current enable), *coulomb\_cnt* (Coulomb counter enable)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_enable\_get**

- **Purpose:** Get current measurement and Coulomb counter enable status.
- **Parameters:** *inst\_en*, *coulomb\_cnt* (pointers to store status)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_filter\_set**

- **Purpose:** Set the filter time constant for current measurements.
- **Parameters:** *Curr\_filter* (filter time constant)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_filter\_get**

- **Purpose:** Get the filter time constant for current measurements.
- **Parameters:** *Curr\_filter* (pointer to store filter time constant)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_en\_set**

- **Purpose:** Enable balancing for selected cells using a bitmask.
- **Parameters:** *bit\_mask* (bitmask of cells)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_en\_get**

- **Purpose:** Get balancing enable bitmask.
- **Parameters:** *bit\_mask* (pointer to store bitmask)
- **Returns:** Result code indicating success or error.

**L9962\_CB\_enable\_set**

- **Purpose:** Enable or disable charge/discharge circuit breaker.
- **Parameters:** *chg\_en* (charge enable), *dchg\_en* (discharge enable)
- **Returns:** Result code indicating success or error.

**L9962\_CB\_enable\_get**

- **Purpose:** Get charge/discharge circuit breaker enable status.
- **Parameters:** *chg\_en*, *dchg\_en* (pointers to store status)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_UV\_set**

- **Purpose:** Set VB undervoltage threshold and counter.
- **Parameters:** *th\_uV* (threshold in uV), *cnt\_th* (counter threshold)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_OV\_set**

- **Purpose:** Set VB overvoltage threshold and counter.
- **Parameters:** *th\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_VB\_UV\_get**

- **Purpose:** Get VB undervoltage threshold and counter.
- **Parameters:** *th\_uV*, *cnt\_th* (pointers to store values)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_OV\_get**

- **Purpose:** Get VB overvoltage threshold and counter.
- **Parameters:** *th\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_OT\_set**

- **Purpose:** Set NTC overtemperature thresholds and counter.
- **Parameters:** *th\_uV*, *th\_severe\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_OT\_get**

- **Purpose:** Get NTC overtemperature thresholds and counter.
- **Parameters:** *th\_uV*, *th\_severe\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_UT\_set**

- **Purpose:** Set NTC undertemperature threshold and counter.
- **Parameters:** *th\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_UT\_get**

- **Purpose:** Get NTC undertemperature threshold and counter.
- **Parameters:** *th\_uV*, *th\_severe\_uV*, *cnt\_th*
- **Returns:** Result code indicating success or error.

**L9962\_VB\_vs\_sum\_set**

- **Purpose:** Set VB vs sum threshold.
- **Parameters:** *th\_uV* (threshold in uV)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_vs\_sum\_get**

- **Purpose:** Get VB vs sum threshold.
- **Parameters:** *th\_uV* (pointer to store threshold)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_MEAS\_get**

- **Purpose:** Get NTC measurement value.
- **Parameters:** *NTC\_uV* (pointer to store value)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_diag\_get**

- **Purpose:** Get VB diagnostic flags (UV, OV, UVLO, vs\_sum).
- **Parameters:** *UV*, *OV*, *UVLO*, *vs\_sum* (pointers to store flags)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_diag\_get**

- **Purpose:** Get NTC diagnostic flags (UT, OT, OT\_severe).
- **Parameters:** *UT* (pointer to undertemperature flag), *OT* (pointer to overtemperature flag), *OT\_severe* (pointer to severe overtemperature flag)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_meas\_get**

- **Purpose:** Get VB (battery voltage) measurement.
- **Parameters:** *voltage\_uV* (pointer to store measured voltage in microvolts)
- **Returns:** Result code indicating success or error.

**L9962\_Vcell\_meas\_get**

- **Purpose:** Get voltage measurement for a specific cell.
- **Parameters:** *cell\_idx* (cell index), *voltage\_uV* (pointer to store measured voltage)
- **Returns:** Result code indicating success or error.

**L9962\_DIE\_TEMP\_meas\_C\_get**

- **Purpose:** Get die temperature in Celsius.
- **Parameters:** *Tj\_X* (pointer to store temperature in Celsius)
- **Returns:** Result code indicating success or error.

**L9962\_chipid\_get**

- **Purpose:** Get silicon and metal ID of the device.
- **Parameters:** *silicon* (pointer to silicon ID), *metal* (pointer to metal ID)
- **Returns:** Result code indicating success or error.

**L9962\_devaddr\_get**

- **Purpose:** Get device address.
- **Parameters:** *devaddr* (pointer to store device address)
- **Returns:** Result code indicating success or error.

**L9962\_CELL\_sum\_meas\_get**

- **Purpose:** Get sum of all cell voltages.
- **Parameters:** *voltage\_uV* (pointer to store sum voltage)
- **Returns:** Result code indicating success or error.

**L9962\_CELL\_diag\_get**

- **Purpose:** Get cell diagnostic flags (UV, OV, OV\_severe, UV\_severe).
- **Parameters:** *UV*, *OV*, *OV\_severe*, *UV\_severe* (pointers to store flags)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_inst\_meas\_get**

- **Purpose:** Get instantaneous current measurement.
- **Parameters:** *voltage\_uV* (pointer to store measured current in microvolts)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_overcurr\_set**

- **Purpose:** Set overcurrent detection thresholds and enable.
- **Parameters:** *en* (enable), *chg\_th\_nV* (charge threshold in nV), *dchg\_th\_nV* (discharge threshold in nV), *th\_persist\_nV* (persistence threshold in nV)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_overcurr\_get**

- **Purpose:** Get overcurrent detection thresholds and enable.
- **Parameters:** *en*, *chg\_th\_nV*, *dchg\_th\_nV*, *th\_persist\_nV* (pointers to store values)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_threshold\_set**

- **Purpose:** Set balancing undervoltage threshold and counter.
- **Parameters:** *UV\_uV* (undervoltage threshold in uV), *cnt* (counter threshold)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_threshold\_get**

- **Purpose:** Get balancing undervoltage threshold and counter.
- **Parameters:** *UV\_uV*, *cnt* (pointers to store values)
- **Returns:** Result code indicating success or error.

**L9962\_OVC\_diag\_get**

- **Purpose:** Get overcurrent diagnostic flags.
- **Parameters:** *ovc\_chg*, *ovc\_dchg*, *persistent\_ovc\_chg*, *persistent\_ovc\_dchg* (pointers to store flags)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_mask\_set**

- **Purpose:** Set VB event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_VB\_mask\_get**

- **Purpose:** Get VB event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_DIE\_T\_mask\_set**

- **Purpose:** Set die temperature event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_DIE\_T\_mask\_get**

- **Purpose:** Get die temperature event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_mask\_set**

- **Purpose:** Set current event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_mask\_get**

- **Purpose:** Get current event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_DIE\_TEMP\_diag\_get**

- **Purpose:** Get die temperature diagnostic flags.
- **Parameters:** *ot* (pointer to overtemperature flag)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_mask\_set**

- **Purpose:** Set balancing event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_mask\_get**

- **Purpose:** Get balancing event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_BAL\_diag\_get**

- **Purpose:** Get balancing diagnostic flags.
- **Parameters:** *cell\_UV* (pointer to store cell undervoltage flags)
- **Returns:** Result code indicating success or error.

**L9962\_CB\_mode\_set**

- **Purpose:** Set charge/discharge circuit breaker mode (High-Side/Low-Side).
- **Parameters:** *chg\_mode* (charge mode), *dchg\_mode* (discharge mode)
- **Returns:** Result code indicating success or error.

**L9962\_CB\_mode\_get**

- **Purpose:** Get charge/discharge circuit breaker mode (High-Side/Low-Side).
- **Parameters:** *chg\_mode*, *dchg\_mode* (pointers to store modes)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_mask\_set**

- **Purpose:** Set NTC event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_NTC\_mask\_get**

- **Purpose:** Get NTC event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_FUSE\_ext\_get**

- **Purpose:** Get fuse deployment status.
- **Parameters:** *deploy* (pointer to store deployment status)
- **Returns:** Result code indicating success or error.

**L9962\_CELLS\_mask\_set**

- **Purpose:** Set cell event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_CELLS\_mask\_get**

- **Purpose:** Get cell event/fault mask.
- **Parameters:** *mask\_sel* (mask selection), *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_short\_set**

- **Purpose:** Set short-circuit detection parameters.
- **Parameters:** *en* (enable), *th\_uV* (threshold in uV), *sc\_filter* (filter selection), *th\_persist\_uV* (persistence threshold)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_short\_get**

- **Purpose:** Get short-circuit detection parameters.
- **Parameters:** *en*, *th\_uV*, *sc\_filter*, *th\_persist\_uV* (pointers to store values)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_short\_diag\_get**

- **Purpose:** Get short-circuit diagnostic flags.
- **Parameters:** *sc\_dchg*, *persist\_sc\_dchg* (pointers to store flags)
- **Returns:** Result code indicating success or error.

**L9962\_FUSE\_deploy**

- **Purpose:** Deploy the fuse.
- **Parameters:** None
- **Returns:** Result code indicating success or error.

**L9962\_global\_diag\_get**

- **Purpose:** Get global diagnostic status.
- **Parameters:** *sel* (diagnostic selection), *value* (pointer to store value)
- **Returns:** Result code indicating success or error.

**L9962\_NVM\_operation**

- **Purpose:** Perform NVM upload or download operation.
- **Parameters:** *OP* (operation: upload or download)
- **Returns:** Result code indicating success or error.

**L9962\_NVM\_upload\_cnt\_get**

- **Purpose:** Get NVM upload counter.
- **Parameters:** *value* (pointer to store counter)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_ADC\_correction\_get**

- **Purpose:** Get current ADC gain correction factor.
- **Parameters:** *gain\_factor* (pointer to store gain factor)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_ADC\_correction\_set**

- **Purpose:** Set current ADC gain correction factor.
- **Parameters:** *gain\_factor* (gain correction value)
- **Returns:** Result code indicating success or error.

**L9962\_i2c\_crc\_check\_set**

- **Purpose:** Enable or disable I2C CRC check.
- **Parameters:** *en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_i2c\_crc\_check\_get**

- **Purpose:** Get I2C CRC check enable status.
- **Parameters:** *en* (pointer to store enable status)
- **Returns:** Result code indicating success or error.

**L9962\_CURR\_cc\_meas\_get**

- **Purpose:** Get Coulomb counter measurement.
- **Parameters:** *voltage\_nV* (pointer to store measured value in nV), *smp\_cnt* (pointer to sample count), *cc\_sat* (pointer to saturation flag)
- **Returns:** Result code indicating success or error.

**L9962\_WAKEUP\_set**

- **Purpose:** Enable or disable wake-up function.
- **Parameters:** *wkup\_en* (enable)
- **Returns:** Result code indicating success or error.

**L9962\_NSHIP\_get**

- **Purpose:** Get nSHIP pin status.
- **Parameters:** *nship\_en* (pointer to store status)
- **Returns:** Result code indicating success or error.

**L9962\_RDY\_get**

- **Purpose:** Get RDY pin status.
- **Parameters:** *rdy* (pointer to store status)
- **Returns:** Result code indicating success or error.

**L9962\_FLTN\_get**

- **Purpose:** Get FLTN pin status.
- **Parameters:** *fltn* (pointer to store status)
- **Returns:** Result code indicating success or error.

**L9962\_FSM\_go\_to**

- **Purpose:** Set device finite state machine (FSM) state.
- **Parameters:** *sts* (desired state)
- **Returns:** Result code indicating success or error.

**Additional notes**

- All functions return a `RESULT_T` type, which indicates the success or failure of the operation. Typical values are implementation-specific but usually include codes for success, invalid parameters, or hardware communication errors.
- For functions that use pointers as parameters, the caller must ensure that the pointers are valid and point to sufficient memory to store the results.
- Many functions use bitmasks or enumerated types to select channels, features, or configuration options. Refer to the corresponding enum definitions in the header for valid values.
- Measurement functions typically return values in microvolts (uV), nanovolts (nV), or degrees Celsius (°C), depending on the context.
- Mask and diagnostic functions allow fine-grained control and monitoring of fault and event reporting for safety-critical applications.
- NVM (Non-Volatile Memory) operations are used to save or restore configuration settings to or from the internal device memory.

**Example usage**

```
uint16_t cell_mask = 0x0F; // Enable first 4 cells
RESULT_T res = L9962_CELL_enable_set(cell_mask);
if (res == RESULT_OK) { // Cells enabled successfully }
uint32_t cell_voltage;
res = L9962_Vcell_meas_get(2, &cell_voltage); // Get voltage for cell 2
if (res == RESULT_OK) { // Use cell_voltage }
```

## 3 L9962 driver functions description

### 3.1 Summary table

**Table 3. Summary table**

| Function Name               | Purpose/Description                                 |
|-----------------------------|---|
| L9962_CELL_enable_set/get   | Enable/disable cells (bitmask)                      |
| L9962_CELL_filter_set/get   | Set/get cell filter                                 |
| L9962_CELL_UV_set/get       | Set/get cell undervoltage threshold                 |
| L9962_CELL_OV_set/get       | Set/get cell overvoltage threshold                  |
| L9962_VB_enable_set/get     | Enable/disable VB and UVLO                          |
| L9962_NTC_enable_set/get    | Enable/disable NTC                                  |
| L9962_tmeas_set/get         | Set/get measurement time                            |
| L9962_CURR_enable_set/get   | Enable/disable current measurement, coulomb counter |
| L9962_CURR_filter_set/get   | Set/get current filter                              |
| L9962_BAL_en_set/get        | Enable/disable cell balancing (bitmask)             |
| L9962_CB_enable_set/get     | Enable/disable charge/discharge                     |
| L9962_VB_UV_set/get         | Set/get VB undervoltage threshold                   |
| L9962_VB_OV_set/get         | Set/get VB overvoltage threshold                    |
| L9962_NTC_OT_set/get        | Set/get NTC overtemperature threshold               |
| L9962_NTC_UT_set/get        | Set/get NTC undertemperature threshold              |
| L9962_VB_vs_sum_set/get     | Set/get VB vs sum threshold                         |
| L9962_NTC_MEAS_get          | Get NTC voltage measurement                         |
| L9962_VB_diag_get           | Get VB diagnostic flags                             |
| L9962_NTC_diag_get          | Get NTC diagnostic flags                            |
| L9962_VB_meas_get           | Get VB voltage measurement                          |
| L9962_Vcell_meas_get        | Get cell voltage measurement                        |
| L9962_DIE_TEMP_meas_C_get   | Get die temperature (Celsius)                       |
| L9962_chipid_get            | Get chip silicon and metal ID                       |
| L9962_devaddr_get           | Get device address                                  |
| L9962_CELL_sum_meas_get     | Get sum of all cell voltages                        |
| L9962_CURR_inst_meas_get    | Get instantaneous current measurement               |
| L9962_CURR_overcurr_set/get | Set/get overcurrent protection                      |
| L9962_BAL_threshold_set/get | Set/get balancing undervoltage threshold            |
| L9962_OVC_diag_get          | Get overcurrent diagnostic flags                    |
| L9962_CURR_cc_meas_get      | Get current accumulator measurement                 |
| L9962_CURR_short_set/get    | Set/get short-circuit protection                    |
| L9962_CURR_short_diag_get   | Get short-circuit diagnostic flags                  |
| L9962_FUSE_deploy           | Deploy fuse   |
| L9962_FUSE_ext_get          | Get fuse deployment status                          |
| L9962_global_diag_get       | Get global diagnostic (e.g., CRC config fail)       |

| Function Name                     | Purpose/Description                            |
|-----------------------------------|--|
| L9962_NVM_operation               | Perform NVM upload/download                    |
| L9962_NVM_upload_cnt_get          | Get NVM upload count                           |
| L9962_CURR_ADC_correction_set/get | Set/get current ADC correction gain            |
| L9962_i2c_crc_check_set/get       | Enable/disable I2C CRC check                   |
| L9962_WAKEUP_set                  | Set WKP pin                                    |
| L9962_NSHIP_get                   | Get NSHIP pin status                           |
| L9962_RDY_get                     | Get RDY pin status                             |
| L9962_FLTN_get                    | Get FLTN pin status                            |
| L9962_FSM_go_to                   | Set device FSM state                           |
| Mask management functions         | Set/get event masks (VB, Die T, Current, etc.) |

### 3.2 Detailed descriptions

See previous detailed section in Chapter 2.2 for function-by-function descriptions, parameters, and return values.

---

## 4 General notes

---

- **Portability:** Only L9962\_HAL\_wrapper needs to be ported for a new MCU.
- **Communication:** All register access is via I2C, with optional CRC checking.
- **Device Abstraction:** All device logic is in the driver, with clear separation from hardware.
- **Error Handling:** All functions return a RESULT\_T code for robust error detection.
- **Masking:** Fine-grained event masking for all major protection/diagnostic events.
- **NVM:** Upload/download and upload count supported.
- **FSM:** Shipment, Standby, and Normal states supported.

## 5 Error codes

```
typedef enum {  
    RES_OK,  
    RES_FAIL,  
    RES_HAL_ERR,  
    RES_CRC_ERR,  
    RES_INVALID_PARAM,  
} RESULT_T;
```

## 6 Bitfield macros and register map

---

All register addresses and bitfield offsets/widths are defined in `L9962_regmap.h`. Use utility macros for bitfield manipulation (e.g., `UTILS_set_field_in_reg`, `UTILS_get_field_from_reg`).

## Revision history

**Table 4. Document revision history**

| Date        | Version | Changes          |
|-------------|---------|------------------|
| 08-Jan-2026 | 1       | Initial release. |

## Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Main modules description</b>           | <b>2</b>  |
| 1.1      | Modules and dependencies overview         | 2         |
| 1.2      | L9962 interface module                    | 3         |
| 1.3      | L9962 HAL wrapper module                  | 3         |
| 1.4      | Utility macros module                     | 4         |
| <b>2</b> | <b>L9962 driver function descriptions</b> | <b>5</b>  |
| 2.1      | Summary table                             | 5         |
| 2.2      | Detailed descriptions                     | 7         |
| <b>3</b> | <b>L9962 driver functions description</b> | <b>16</b> |
| 3.1      | Summary table                             | 16        |
| 3.2      | Detailed descriptions                     | 17        |
| <b>4</b> | <b>General notes</b>                      | <b>18</b> |
| <b>5</b> | <b>Error codes</b>                        | <b>19</b> |
| <b>6</b> | <b>Bitfield macros and register map</b>   | <b>20</b> |
|          | Revision history                          | 21        |
|          | List of tables                            | 23        |
|          | List of figures                           | 24        |

## List of tables

|                 |                                     |    |
|-----------------|-------------------------------------|----|
| <b>Table 1.</b> | Dependencies table . . . . .        | 2  |
| <b>Table 2.</b> | Summary table . . . . .             | 5  |
| <b>Table 3.</b> | Summary table . . . . .             | 16 |
| <b>Table 4.</b> | Document revision history . . . . . | 21 |

## List of figures

|           |                                |   |
|-----------|--------------------------------|---|
| Figure 1. | Drivers architecture . . . . . | 2 |
| Figure 2. | Dependencies diagram . . . . . | 3 |

**IMPORTANT NOTICE – READ CAREFULLY**

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice.

In the event of any conflict between the provisions of this document and the provisions of any contractual arrangement in force between the purchasers and ST, the provisions of such contractual arrangement shall prevail.

The purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgment.

The purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of the purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

If the purchasers identify an ST product that meets their functional and performance requirements but that is not designated for the purchasers’ market segment, the purchasers shall contact ST for more information.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to [www.st.com/trademarks](http://www.st.com/trademarks). All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2026 STMicroelectronics – All rights reserved