

FW Examples/No configuration possible in MC Workbench tools:

		STM32 series																									
		F0		F1		F3		F4		F7		L4		G0		G4		H7 CM4		STSpin32 F0							
SDK version		5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y	5.4.6	5.Y						
Key features																											
6 Step	FW Examples (No configuration possible in MC workbench tools)						✓		✓										✓		✓				✓		✓
DUAL CORE	FW Examples																				✓						
ACIM motor (Asynchronous motor)	FW Examples																				✓						