



RS232/UART



METROLOGY CIRCUIT



To assemble in case current sensor is Shunt
 To assemble in case current sensor is Current Transformer