



Industrial digital output software expansion for STM32Cube





Features

- Complete software to build applications for IPS160HF and IPS161HF high-side smart power solid-state relay
- · GPIOs, PWMs and IRQs
- · Fault/Diagnostics interrupt handling
- Sample implementation available on the X-NUCLEO-OUT08A1 or X-NUCLEO-OUT10A1 expansion boards when connected to a NUCLEO-F401RE or NUCLEO-G431RB development board
- Easy portability across different MCU families, thanks to STM32Cube
- Free, user-friendly license terms

Description

The X-CUBE-OUT8 expansion software package for STM32Cube runs on the STM32 microcontroller and includes a driver to control the IPS160HF and/or the IPS161HF (single high-side switches for industrial safety compliant systems).

The software provides an affordable and easy-to-use solution for the development of 2 A (X-NUCLEO-OUT08A1) or 0.5 A (X-NUCLEO-OUT10A1) digital output modules, letting you easily evaluate the driving and diagnostic capabilities of IPS160HF and IPS161HF with industrial loads.

The expansion is built on STM32Cube software technology to ease portability across different STM32 microcontrollers.

The software comes with an example implementation of a single channel driver running on the X-NUCLEO-OUT08A1 or X-NUCLEO-OUT10A1 expansion board connected to a NUCLEO-F401RE or NUCLEO-G431RB development board.

You can also evaluate a dual channel digital output module by stacking any combination of X-NUCLEO-OUT08A1 and/or X-NUCLEO-OUT10A1 with shared or independent supply rail and independent loads.

When two X-NUCLEO-OUT08A1 expansion boards are stacked and connected so that the output of the first board supplies the second, the software allows you to evaluate IPS160HF performance in a 2 A digital output module, also by using the additional signals OUT FB and Nch DRV.

Similarly, IPS161HF performance can be evaluated for a 0.5 A safety digital output module when two X-NUCLEO-OUT10A1 expansion boards are stacked.

When two expansion boards are stacked, the configuration resistors between signals and Arduino connectors must be properly set between default and alternate positions to guarantee the desired control of the hardware.

Product summary	
Industrial digital output software expansion for STM32Cube	X-CUBE- OUT8
Industrial digital output expansion board based on IPS160HF for STM32 Nucleo	X-NUCLEO- OUT08A1
Industrial digital output expansion board based on IPS161HF for STM32 Nucleo	X-NUCLEO- OUT10A1
STM32 Nucleo-64 development board with STM32F401RE/ STM32G431RB MCU	NUCLEO- F401RE/ NUCLEO- G431RB
Applications	Industrial Safety Industrial Tools



1 Detailed description

1.1 What is STM32Cube?

STM32Cube is a combination of a full set of PC software tools and embedded software blocks running on STM32 microcontrollers and microprocessors:

- STM32CubeMX configuration tool for any STM32 device; it generates initialization C code for Cortex-M cores and the Linux device tree source for Cortex-A cores
- STM32CubeIDE integrated development environment based on open-source solutions like Eclipse or the GNU C/C++ toolchain, including compilation reporting features and advanced debug features
- STM32CubeProgrammer programming tool that provides an easy-to-use and efficient environment for reading, writing and verifying devices and external memories via a wide variety of available communication media (JTAG, SWD, UART, USB DFU, I2C, SPI, CAN, etc.)
- STM32CubeMonitor family of tools (STM32CubeMonRF, STM32CubeMonUCPD, STM32CubeMonPwr) to help developers customize their applications in real-time
- STM32Cube MCU and MPU packages specific to each STM32 series with drivers (HAL, low-layer, etc.), middleware, and lots of example code used in a wide variety of real-world use cases
- STM32Cube expansion packages for application-oriented solutions

1.2 How does this software complement STM32Cube?

The software supports dual channel digital output applications and safety digital output applications.

The package is based on the STM32CubeHAL, the hardware abstraction layer for the STM32 microcontroller. The package extends STM32Cube by providing a Board Support Package (BSP) for the STM32 Nucleo expansion board based on the IPS160HF and IPS161HF.

The drivers abstract low-level details of the hardware to access the IPS160HF and IPS161HF device data in a hardware independent manner.

The software package includes a set of examples that the developer can use to start experimenting with the code. The IPS160HF and IPS161HF output channel is controlled via GPIO peripheral and application debugging is supported on the X-NUCLEO-OUT08A1 and X-NUCLEO-OUT10A1 through LEDs, GPIO and interrupt signals for activity and diagnostics.

DB4178 - Rev 1 page 2/4



Revision history

Table 1. Document revision history

Date	Version	Changes
12-Jun-2020	1	Initial release.

DB4178 - Rev 1 page 3/4



IMPORTANT NOTICE - PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics - All rights reserved

DB4178 - Rev 1 page 4/4