










default position
closed between 1-2













Bus voltage monitoring




Phase voltage monitoring



Solder bridge configuration for NUCLEO-G0 boards



3.3V selector
default close 1-2: VDD from the STDRIVE102
close 2-3: VDD from the Nucleo Board



Board Title EVLDRIVE102P

Sheet Title Connectors

Doc No

Date
Tuesday, November 26, 2024

Rev
1.0

Sheet
4 / 4

This drawing and the information herein are property of STMicroelectronics and are intended for evaluation purpose only