
VCC
SIGNAL CLAMP
FAULT DETECTION
POWER LIMITATION
LSA_OVERTEMPERATURE
HSA_OVERTEMPERATURE
OV+UV
LSB_OVERTEMPERATURE
HSB_OVERTEMPERATURE
CLAMP HSA
CLAMP HSB
HSA
DRIVER HSA
LOGIC
DRIVER HSB
HSB
CURRENT LIMITATION A
CURRENT LIMITATIONB
OUTA
1/K
1/K
OUTB
CLAMP LSA
CLAMP LSB
LSA
DRIVER LSA
DRIVER LSB
LSB
OVERLOAD DETECTO R A
OVERLOAD DETECTOR B
GNDA
DIAGA/ENA
INA
CS
PWM
CS_DIS
INB
DIAGB/ENB
GNDB