
How to run self-test in the SPC58NN84xx device

Introduction

This application note describes how to run the logic and memory BISTs (L/MBIST) implemented in the SPC58NN84xx device.

The user typically executes these self-tests during the startup phase. They are transparent for the application.

Last generations of microcontroller (55 and 40 nm), including the SPC58NN84xx, offer a high flexibility in the self-test configuration.

The user can:

- Choose at which frequency self-test runs
- Decide if BIST runs in parallel or sequential mode
- Split the self-tests in different subsets:
 - during key-on (such as self-test in off-line mode)
 - during key-off (such as self-test in on-line mode)

The possibility to split the self-tests guarantees a faster boot time and at the same time maintains a high diagnostic coverage against latent failures.

This application note focuses on SPC58NN84xx, but most concepts are valid also for other 40 and 55 nm devices.

Contents

1	Overview	6
1.1	Off-line mode configuration	7
1.2	On-line mode configuration	7
1.3	Modules used in self-test phase	8
1.3.1	Offline mode	8
1.3.2	Online mode	9
1.4	L/MBIST scheduling activity	10
1.5	Clock configurations of self-test	11
1.5.1	Clock in off-line mode	12
1.5.2	How to configure the PLL0	13
1.5.3	Clock in online mode	13
2	STCU registers list	14
3	Functional reset sequence in off-line mode	17
4	LBIST and MBIST partitions	18
4.1	MBIST partition	18
4.2	LBIST partition	20
4.3	DCF records to program in off-line mode	23
4.3.1	Self-test in off-line mode	24
5	On-line test	26
5.1	Self-test flow	26
5.2	MEMU results	27
5.3	On-line configuration	27
6	How to read STCU register results and possible reactions	29
6.1	MBIST reaction	29
6.2	LBIST reaction	30
7	Summary	32
Appendix A FCCU reaction		33

Appendix B Reference code 36

Appendix C Other informations..... 42

 C.1 Document reference 42

 C.2 Acronyms 42

Revision history 43

List of tables

Table 1. Example of MBIST settings 11

Table 2. List of STCU on/off line registers 14

Table 3. MBIST partition 18

Table 4. LBIST partition 20

Table 5. Acronyms 42

Table 6. Document revision history 43



List of figures

Figure 1.	Basic single LBIST architecture	6
Figure 2.	Module interconnections while the BIST runs in off-line mode	8
Figure 3.	Module interconnections while the BIST runs in on-line mode	10
Figure 4.	Shift and capture frequencies	12
Figure 5.	Destructive and functional reset sequence in case off-line L/MBISTs are enabled	17
Figure 6.	Sequence of DCF records in the UTEST	24
Figure 7.	Self test flow in on-line mode	27
Figure 8.	MBIST reaction scheme	29
Figure 9.	LBIST reaction scheme	30
Figure 10.	Behavior of the FCCU in case NO fault is detected by LBIST	35
Figure 11.	Behavior of the FCCU in case at least a fault is detected by LBIST.	35

1 Overview


BISTs (Built-In Self-Tests) are periodic tests that detect latent faults in the functional logic of the device according to the ISO26262 standard.

The SPC58NN84xx device includes two different types of BIST:

- Memory BIST (MBIST): for all volatile memories^(a)
- Logic BIST (LBIST): for digital logic

Figure 1 shows a basic schema of the LBIST architecture.

Figure 1. Basic single LBIST architecture



Logic blocks are divided in LBIST partitions. LBIST partitions are tested by the LBIST controller. It consists of a series of chains that are scanned by a pseudo random pattern generator. A hardware comparator compares the generated signatures (MISR) versus an expected one.

a. MBIST verifies the integrity of the array of the volatile memory only. For non volatile memories another type of test is in place, such as Array Integrity Check. Have a look at the reference manual to have all details on this test.

Running all LBIST/MBIST at the power-on takes a certain amount of time. If this time is too long to satisfy the user needs, a "mixed" methodology can be used: for example splitting the L/MBISTs in two groups of self-tests^(b):

- the first group is executed in off-line mode, during the key on phase (off-line self-test phase)
- the second one is executed in on-line mode, during the key off phase (on-line self-test phase)

The Self-Test Control Unit (STCU) hardware module controls the BIST execution for both modes, such as on-line and off-line.

STCU has two sets of registers that collect the L/MBIST results separately for the off-line and on-line modes. Moreover a programmable watchdog timer (WDG), inside STCU peripheral, checks that the self-test operations (both LBIST and MBIST) have been completed within the assigned time slot.

1.1 Off-line mode configuration

The users configure STCU according to their needs. The SSCM loads this configuration during the boot phase from UTest sector of the FLASH (through DCF records).

User saves the right configuration in the UTest sectors.

The main parameters necessary to execute the off-line self-test are:

- L/MBIST scheduling activity
- LBIST setup (MISR expected values included)
- Unrecoverable/Recoverable faults management
- CRC
- PLL management

They are discussed in more detail in the next paragraphs.

1.2 On-line mode configuration

The user can run the BIST on-line. For example a possible strategy is to run this test before the key off event.

Software configures the STCU and triggers the BIST execution. Afterward the software can save the result of the self-test in the NVM (Flash) before shutdown. Application can read this result after the next key-on.

For a comprehensive description of the STCU, please refer to the STCU's dedicated chapter of SPC58NN84xx reference manual.

b. This is an example. Other methodologies can be thought.

The main parameters necessary to execute the on-line self-test are:

- L/MBIST scheduling activity
- LBIST setup (MISR expected values included)
- Unrecoverable/Recoverable faults management
- CRC

A functional reset must be issued to the entire SoC by hardware at the completion of the self-test procedure^(c). STCU module is not affected by a functional reset. This gives the possibility to read the self-test results after that.

1.3 Modules used in self-test phase

There are several hardware modules involved in the self-test execution. Their logical interconnection is different according to the self-test mode (either off-line or on-line mode).


1.3.1 Offline mode

In off-line mode, the modules involved are:

- The Reset Generation Module (RGM)
- L/MIST controllers
- The System Status and Configuration Module (SSCM)
- The Self-Test Control Unit (STCU2)
- The Fault Collection and Control Unit (FCCU)

Figure 2 shows the interconnection of these modules.

Figure 2. Module interconnections while the BIST runs in off-line mode



Either the IRC or PLL0 generates the PBRIDGE clock. Its value is IRC/4 or PLL0/4^(d)

c. In order to enable the automatic generation of the functional reset after the execution of the on-line LBIST, the flag LBRMSWx of the STCU_LBRMSW reset management register needs to be set '1'.

In offline mode, the STCU has the direct control of the PLL0 and according to the MBP_LLEN/LBP_LLEN flags of the STCU_RUN register, is selected the specific clock:

- if MBP_LLEN/LBP_LLEN = 0 ->> *STCU core clock* = (IRC/4)/(1 + STCU_CFG.CLK_CFG)^(e)
- if MBP_LLEN/LBP_LLEN = 1 ->> *STCU core clock* = (PLL0/4)/(1 + STCU_CFG.STCU.CLK_CFG)

The self-test is executed at the start-up by the STCU whose configuration has been loaded by the SSCM from the Utest sector.

To run an MBIST, the STCU doesn't access directly the memories under test, but programs the MBIST controller.

Any LBIST/MBIST failure event can be managed by FCCU^(f) (see [Appendix A: FCCU reaction](#) for further clarifications). The STCU error lines (unrecoverable failures/recoverable failures) are linked to this module.

FCCU alerts the external environment in different modes: by an interrupt, by reset or reporting the error by external lines.

STCU is also connected to the RGM. After the LBIST execution a functional reset is triggered.

1.3.2 Online mode

In on-line mode the interconnection scheme is different. In this case the involved modules are^(g):

- The Reset Generation Module (RGM)
- The Self-Test Control Unit (STCU2)
- The Fault Collection and Control Unit (FCCU)
- L/MBIST controllers


[Figure 3](#) shows the modules involved.

d. '4' is the fixed division factor of the CGM_SC_DC2 divider.

e. STCU core clock depends also by an internal divider of the STCU, i.e. CLK_CFG.CLK_CFG is '3 bit' flag of the STCU_CFG register. If CLK_CFG = 0 then STCU core clock is the PBRIDGE.

f. On SPC58NN84xx device only Recoverable/Not Critical fault condition can be managed.

g. Another module not directly connected to the STCU but involved in the self-test, is the MEMU. The MEMU collects information about single bit and double bit events in the memories.

Figure 3. Module interconnections while the BIST runs in on-line mode

The on-line self-test is initiated by the software code which provides the proper commands to the STCU via IPS interface.

Connection between STCU and the memories and MBIST controller are the same as the off-line self-test.

STCU is connected to RGM and FCCU modules to report errors.

The STCU only monitors the lock signal and according to the MBPLEN/LBPLEN flags of the STCU_RUN register is selected the specific clock:

- if MBSWPLEN/LBSWPLEN = 1 ->> MBIST/LBIST are executed once PLL1 is locked
- if MBPLEN/LBPLEN = 0 ->> MBIST/LBIST doesn't depend on PLL1

In online mode the software configures both PLL modules, and the source of the PBRIDGE clock. We recommend that the PLL1 drives the PBRIDGE clock because the STCU monitors it while the online self test runs.

1.4 L/MBIST scheduling activity

STCU2 is very flexible in terms of scheduling L/MBIST. It allows programming the concurrent^(h) or sequential execution of the MBISTs or LBISTs.

Although the concurrent execution is shorter in terms of time, it causes higher power dissipation.

h. Also referenced as parallel.

The mechanism used to provide this flexibility is a linked list where the starting pointer is the bitfield STCU_CFG[PTR].

The additional pointers are in the bitfield STCU_LB_CTRLx[PTR] for LBISTx (where x is the selected LBIST) and STCU_MB_CTRLy[PTR] for MBIST (where y is the selected MBIST) and have to be filled depending on the selected sequence of run.

The additional bitfield STCU_LB_CTRL[CSM] and STCU_MB_CTRL[CSM] provides the flexibility to run the chosen set of the LBISTs or MBISTs either concurrently or sequentially or to close the linked list by setting the NIL pointer.

Next example shows how these registers have to be configured in case the first 3 MBISTs are configured to run in parallel:

Table 1. Example of MBIST settings

STCU_CFG = 0x10000101	PTR = 10h-> MBIST_0
	CLK_CFG = 0x101 -> It isn't the self-test frequency, but related to the memory controller frequency (in this case is sys_clk/6)
STCU_MB_CTRL_0 = 0x11800000	PTR = 11h-> MBIST_1
	CSM = 1 (concurrent/parallel mode)
STCU_MB_CTRL_1 = 0x12800000	PTR = 12h-> MBIST_2
	CSM = 1 (concurrent/parallel mode)
STCU_MB_CTRL_2 = 0xFF000000	PTR = FFh-> pointer to NIL. No BIST execution
	CSM = 0 (last MBIST)

In case of LBISTs runs, it needs to map 00h in STCU_CFG register (first LBIST). Next LBISTs will be mapped in STCU_LB_CTRLx.

1.5 Clock configurations of self-test

Depending on the selected mode, the LBIST/MBIST can run with different clock configurations. The PBRIDGE clock drives the clock of the STCU and its watchdog. The clock source of the PBRIDGE clock depends on the reset phases and STCU configuration.

The MBIST runs with the STCU clock. Its max frequency is 200 MHz, but there are some constraints:

- GTM memory works up to 80 MHz
- FlexRay memory works up to 40 MHz.

It's worth noticing that in offline mode the user can't choose the frequency of each MBIST separately. As a consequence, if the user wants to verify the integrity of the FlexRay memory using its MBIST, all MBISTs must run at 40 MHz.


In online mode, the user has more degrees of freedom because the software can configure the frequency of different memories with different values (e.g., system RAM at 200 MHz and FlexRay memory at 40 MHz).

The execution of the LBIST depends on two clock frequencies:

- the capture frequency that is equal to the STCU core frequency and
- the shift frequency that is equal to the STCU core frequency divided by STCU_LB[x]_CTRL.SHS parameter.

Figure 4 shows the functionality of these two clock frequencies.

Figure 4. Shift and capture frequencies



The max value of the STCU capture frequency is 100 MHz for the LBIST0 and 50 MHz for the other partitions.

The max frequency of the MBIST is 200 MHz and the max frequency of the LBIST is 100 MHz.

1.5.1 Clock in off-line mode

The clock involved during the sequence of events that occurs in offline self test is not the PBRIDGE since the beginning, but changes according to the different reset phases:

1. PHASE3[DEST] - "Device Configuration"
The RC oscillator – working at 16 MHz - drives the PBRIDGE oscillator until the end of the PHASE3[DEST]. The duration of this phase depends on the number of DCF records that the user stores in the UTEST. Approximately the device remains in this phase for 1 ms.
2. IDLE[DEST] - "Self-test execution":
When the device enters the IDLE[DEST] phase, the clock source the PBRIDGE clock switch either to the RC clock divided by 4 or to the PLL0 divided by 4. The user can select the source clock of the PBRIDGE by configuring the MBPLLEN/LBPLLEN bit by the respective DCF record.
During this phase, the LBIST and MBIST run.

The device remains in the IDLE[DEST] phase until either the STCU watchdog expires or the execution of the self-test ends. If the user doesn't configure the execution of any self-test, the device remains in the IDLE[DEST] phase until the STCU watchdog expires.

Afterward, the device goes to the PHASE1[FUNC] and proceeds with the other reset phases until the application starts.

1.5.2 How to configure the PLL0

The STCU controls the PLL0 during the execution of the off-line self-test operation depending on the status of the STCU_RUN[MBPLEN] and STCU_RUN[LBPLEN] flag.

The STCU can set up the working frequency of the some by some fields of the STCU_PLL_CFG register (i.e., PLLODF, PLLIDF, and PLLDF).

Below the formula of the output frequency of the PLL:

$$f_{\text{PLLout}} = \frac{f_{\text{VCO}}}{\text{PLLDF} \times 2}$$

Where

$$f_{\text{VCO}} = f_{\text{PLLin}} \times (\text{PLLDF} \times 2) = \left(\frac{f_{\text{RC}}}{\text{PLLIDF}} \right) \times (\text{PLLDF} \times 2)$$

fRC is the frequency if the internal RC oscillator (i.e., 16 MHz).

fPLLin must be higher than 8 MHz.

1.5.3 Clock in online mode

In online mode, the software chooses what the clock source of the PBRIDGE_CLK is.

Since during the execution of the online self-tests, the STCU monitors the output of the PLL1, the preferred configuration is that this PLL1 drives the PRIDGE_CLK.

2 STCU registers list

STCU offers two sets of independent registers to collect the L/MBIST results. One set is used during the off-line mode and the other during the on-line mode.

To increase the safety capability of this module, a different security key sequence is also required during off/on-line self-test in order to unlock the write access to the relevant STCU registers.

Next table summarizes which STCU registers are dedicated to on-line test and STCU registers dedicated to off-line test.

Table 2. List of STCU on/off line registers

N.	Off-line register	On-line register	Description
1	STCU_RUN	STCU_RUN_SW	Run Register. Start STCU.
2	STCU_SCK Off-line 0xD3FEA98Bh:key1-0x2C015674h:key2 On-line 0x753F924Eh: key1 - 0x8AC06DB1h: key2		SK Code Register
3	STCU_CFG		Configuration Register. Global configuration of the STCU2.
4	STCU_PLL_CFG		PLL Configuration Register. It defines the parameters used to program the PLL only when the off-line L/MBIST are performed and STCU_RUN[MBPLEN] = 1 or STCU_RUN[LBPLEN] = 1
5	STCU_WDG		Watchdog Register Granularity. It defines the time budget of LBIST and MBIST.
6		STCU_INT_FLG	Interrupt Flag Register. Only when the related control bit into the STCU_RUNSW register (MBIE and LBIE) are enabled.
7	STCU_CRCE		Expected Status Register. It includes the expected signature of the CRC-32 (Ethernet protocol)
8	STCU_CRCR		Read Status Register. It reports the value obtained at the end of the off/on-line self-test sequence.
9	STCU_ERR_STAT		Error Register. It includes the status flags related to the STCU2 internal error conditions occurred during the configuration or the on/off-line self-testing execution.
10	STCU_ERR_FM		Error FM Register. It defines the fault mapping of the STCU2 faults described into the register. STCU_ERR_STAT in terms of unrecoverable or recoverable fault.

Table 2. List of STCU on/off line registers (continued)

N.	Off-line register	On-line register	Description
11	STCU_LBS	STCU_LBSSW	LBIST Status Register. It includes the results corresponding to the execution of the selected off/on-line LBIST. 0: failed LBIST execution 1: successful LBIST execution
12	STCU_LBE	STCU_LBESW	LBIST End Flag Register. It includes the end flag related to the execution of the selected off-line LBIST. 0: LBIST execution not yet completed 1: LBIST execution finished
13		STCU_LBRMSW	LBIST Reset Management. It defines the on- line reset mapping for each LBIST.
14	STCU_LBUFM		It defines the fault mapping of each LBIST in terms of unrecoverable or recoverable fault
15	STCU_MBSL	STCU_MBSLSW	Status Low Register (from 0 to 31 MBIST).It includes the results corresponding to the execution of the selected off/on-line MBIST.
16	STCU_MBSM	STCU_MBSMSW	Status Medium Register (from 32 to 63 MBIST). It includes the results corresponding to the execution of the selected off/on-line MBIST.
17	STCU_MBSH	STCU_MBSHSW	Status High Register (from 64 to 95 MBIST). It includes the results corresponding to the execution of the selected off/on-line MBIST.
18	STCU_MBEL	STCU_MBELSW	End Flag Low Register (from 0 to 31). It includes the end flag related to the execution of the selected off/on-line MBIST.
19	STCU_MBEM	STCU_MBEMSW	End Flag Medium Register (from 32 to 63). It includes the end flag related to the execution of the selected off/on-line MBIST.
20	STCU_MBEH	STCU_MBEHSW	End Flag High Register (from 64 to 95). It includes the end flag related to the execution of the selected off/on-line MBIST.
21	STCU_MBUFML		Unrecoverable FM Low Register (from 0 to 31). It defines the fault mapping, in terms of unrecoverable or recoverable fault of the MBIST.
22	STCU_MBUFMM		Unrecoverable FM Medium Register (from 0 to 31). It defines the fault mapping, in terms of unrecoverable or recoverable fault of the MBIST.
23	STCU_MBUFMH		Unrecoverable FM High Register (from 0 to 31). It defines the fault mapping, in terms of unrecoverable or recoverable fault, of the MBIST.

Table 2. List of STCU on/off line registers (continued)

N.	Off-line register	On-line register	Description
24	STCU_LB_CTRL		LBIST Control Register. It defines the control setting of each LBIST controller.
25	STCU_LB_PCS		LBIST PC Stop Register. It defines the pattern counter stop of each LBIST controller.
26	STCU_LB_PRPGL		LBIST PRPG Low Register. It defines the LSB part (31...0) of the PRPG start value of the LBIST controller.
27	STCU_LB_PRPGH		LBIST PRPG High Register. It defines the MSB part (32...63) of the PRPG start value of the LBIST controller.
28	STCU_LB_MISREL	STCU_LB_MISRELSW	MISR Expected Low Register. It defines the LSB part (31..0) of the expected MISR of the off/on-line LBIST controller.
29	STCU_LB_MISREH	STCU_LB_MISREH_SW	MISR Expected High Register. It defines the MSB part (32...63) of the expected MISR of the off/on-line LBIST controller.
30	STCU_LB_MISRRL	STCU_LB_MISRRLSW	MISR Read Low Register. It reports the LSB part (31...0) of the MISR obtained at the end of the off/on-line LBIST controller execution.
31	STCU_LB_MISRRH	STCU_LB_MISRRHSW	MISR Read High Register. It reports the MSB part (32...63) of the MISR obtained at the end of the off/on-line LBIST controller execution.
32	STCU_MB_CTRL		MBIST Control Register. It defines the control setting of MBIST controller.

3 Functional reset sequence in off-line mode

After a LBIST execution, a functional reset is automatically generated. [Figure 5](#) shows the reset generation sequence.


The sequence starts with a destructive reset that is triggered by an external or internal event. After the L/MBIST execution, a functional reset is automatically generated by STCU. Finally the device is ready to execute the code in DRUN mode.

During the MBIST/LBIST execution:

- a dedicated watchdog is configured to monitor self-test execution completion within expected time. The length of this phase is variable depending on the self-test requirements.
- the Self-Test Control Unit (STCU) executes all tests specified by the DCF records
- the self-test engine updates the self-test completion flag and triggers an associated functional reset on completion of self-test. In case of error, a fault is forwarded to the FCCU.

The length of this phase is variable depending on the self-test requirements.

Figure 5. Destructive and functional reset sequence in case off-line L/MBISTs are enabled



In case of on-line mode there is no the need of a destructive reset before L/MBIST execution. A functional reset needs to be triggered after execution of the self-test. Note that an off-line self-test will not run after this functional reset according to what was previously explained (see [Figure 5](#)).

For more details refer to Reset and Boot chapter of SPC58NN84xx reference manual (see [C.1: Document reference](#)).

4 LBIST and MBIST partitions

In terms of self-test, SPC58NN84xx is composed by 92 MBIST memory partitions (from #0 to #91) and 7 LBIST logical partitions (from #0 to #6). Detailed lists are shown in the next paragraph.

4.1 MBIST partition

Table 3. MBIST partition

Processor / Module	Memory Instance Name	MBIST partition
Core 0	ram_zxa_imem	21
	ram_zxa_dmem_0_0	25
	ram_zxa_dmem_0_1	24
	ram_zxa_dmem_1_0	23
	ram_zxa_dmem_1_1	22
	ram_zxa_ichache_0	29
	ram_zxa_ichache_1	28
	ram_zxa_ichache_2	27
	ram_zxa_ichache_3	26
	ram_zxa_dcache_0	34
	ram_zxa_dcache_1	33
	ram_zxa_dcache_2	32
	ram_zxa_dcache_3	31
	ram_zxa_itag	30
	ram_zxa_dtag	35

Table 3. MBIST partition (continued)

Processor / Module	Memory Instance Name	MBIST partition
Core 1	ram_zxb_imem	53
	ram_zxb_dmem_0_0	57
	ram_zxb_dmem_0_1	56
	ram_zxb_dmem_1_0	55
	ram_zxb_dmem_1_1	54
	ram_zxb_icache_0	61
	ram_zxb_icache_1	60
	ram_zxb_icache_2	59
	ram_zxb_icache_3	58
	ram_zxb_dcache_0	66
	ram_zxb_dcache_1	65
	ram_zxb_dcache_2	64
	ram_zxb_dcache_3	63
	ram_zxb_itag	62
	ram_zxb_dtag	67
Core_2 (IOP)	ram_zxc_imem	3
	ram_zxc_dmem_0_0	7
	ram_zxc_dmem_0_1	6
	ram_zxc_dmem_1_0	5
	ram_zxc_dmem_1_1	4
	ram_zxc_icache_0	11
	ram_zxc_icache_1	10
	ram_zxc_icache_2	9
	ram_zxc_icache_3	8
	ram_zxc_dcache_0	18
	ram_zxc_dcache_1	17
	ram_zxc_dcache_2	16
	ram_zxc_dcache_3	15
	ram_zxc_itag	12
	ram_zxc_dtag	14

Table 3. MBIST partition (continued)

Processor / Module	Memory Instance Name	MBIST partition
GTM	ram_gtm_fifo	76
	ram_gtm_ram0_0	79
	ram_gtm_ram0_1	78
	ram_gtm_ram0_2	77
	ram_gtm_ram0_3	81
	ram_gtm_ram0_4	80
	ram_gtm_ram1_0	84
	ram_gtm_ram1_1	83
	ram_gtm_ram1_2	82
	ram_gtm_ram1_3	86
	ram_gtm_ram1_4	85
	ram_gtm_dp1l_ram1a	87
	ram_gtm_dp1l_ram1b	88
	ram_gtm_dp1l_ram2	89
NEXUS	ram_nexus_nar_0	75
	ram_nexus_nar_1	74
	ram_nexus_nar_2	73
	ram_nexus_nar_3	72
AMU	ram_amu	71
ST FLASH	ram_mpf1ash	2
ROM	rom_bar	0
	rom_mpf1ash	1

4.2 LBIST partition

Table 4. LBIST partition

LBIST0	LBIST1	LBIST2	LBIST3	LBIST4	LBIST5	LBIST6
XBAR	gtm	hsm	cansubsys_1	psi5_1	platform	cansubsys_0
XBIC		flash_0	flexray_0	ethernet_0		dma_ch_mux_1_checker
AHB		sent_0	memu	adcsar_dig_2		dma_ch_mux_0_checker
AIC_0_1_2		sent_1	emios_1	linflex_0		dma_ch_mux_2_checker

Table 4. LBIST partition (continued)

LBIST0	LBIST1	LBIST2	LBIST3	LBIST4	LBIST5	LBIST6
DMC		emios_0	psi5_s_0	adcsar_dig_3		dma_ch_mux_3_checker
AIPS_0_1_2		psi5_0	fccu	adcsar_seq_1		dma_ch_mux_4_checker
PFLASH		dspl_4	ethernet_1	adcsar_seq_2		dma_ch_mux_5_checker
PRAM		dspl_5	adcsd_ana_1	adcsar_seq_b		dma_ch_mux_0
RCCU			adcsd_ana_3	adcsar_seq_0		dma_ch_mux_1
CPU checker			adcsd_ana_2	adcsar_seq_3		dma_ch_mux_2
			adcsd_ana_5	iic_0		dma_ch_mux_3
			adcsd_ana_4	dspl_0		dma_ch_mux_4
			adcsd_ana_0	dspl_9		dma_ch_mux_5
			crc_0	dspl_1		
			crc_1	dspl_2		
			body_ctu_0	dspl_3		
			fosu	dspl_8		
			cmu_2_hpbn	dspl_7		
			cmu_13_pfbbridge	dspl_6		
			cmu_7_sent	adcsar_dig_1		
			cmu_11_fbridge	linflex_13		
			bam	linflex_10		
			adcsd_dig_2	linflex_4		
			adcsd_dig_4	linflex_6		
			adcsd_dig_5	linflex_1		
			adcsd_dig_1	linflex_14		
			adcsd_dig_0	linflex_15		
			adcsd_dig_3	linflex_16		
				linflex_17		
				linflex_7		
				linflex_5		
				linflex_3		
				linflex_9		

Table 4. LBIST partition (continued)

LBIST0	LBIST1	LBIST2	LBIST3	LBIST4	LBIST5	LBIST6
				linflex_12		
				linflex_11		
				linflex_2		
				linflex_8		
				adcsar_dig_0		
				adcsar10_dig_0		
				adcsar10_dig_1		
				pit_rti_0		
				fr_rom_1		
				fr_rom_0		
				ips_read_mux_2		
				adcsar_10bit_seq_0		
				adcsar_10bit_seq_1		
				ima		
				ips_read_mux_1		
				intg_ima_readmux_top		
				pit_rti_1		
				cmu_0_pll0_xoc_ir_cosc		
				cmu_4_gtm		
				cmu_12_emios		
				cmu_10_psi5_1us		
				cmu_5_sdadc		
				cmu_3_pbridge		
				cmu_9_psi5_f125		
				cmu_8_psi5_f189		
				cmu_6_saradc		
				cmu_1_core_xbar_bd		
				adcsar_ana_wrap_2		
				adcsar_ana_wrap_3		
				adcsar_ana_wrap_0		

Table 4. LBIST partition (continued)

LBIST0	LBIST1	LBIST2	LBIST3	LBIST4	LBIST5	LBIST6
				adcsar_ana_wrap _1		
				adcsar_ana_wrap _b		
				adcsar_ana_wrap _comp_0		
				adcsar_ana_wrap _comp_1		
				adcsar_bias		
				adcsd_bias		
				adcsar_dig_b		

Off-line self-test is performed during the boot phases (see [Table 2](#)).

4.3 DCF records to program in off-line mode

DCF records are used to configure certain registers in the device during system boot while the reset signal is asserted.

There are two categories of DCF:

- **TEST DCF records**
They are programmed into TEST flash during production with some information about trimming parameters (for example trip points for voltage comparators, adjusting analog to digital voltage supplies parameters, trimming oscillator parameters, frequencies and enabling RAM repair). This memory is not visible to the user who cannot modify its content.
- **UTEST DCF records**
Some UTEST DCF records are written by the factory and programmed during production testing. Others are written by the end user. The user-defined DCF records are used for several configurations, for example configuring memory blocks as OTP, protecting flash blocks with specific password groups and define which, and how, self-tests are executed.

A DCF record consists of 2 of 32 bit contiguous words: a pointer to the location of a register⁽ⁱ⁾ and the data to be written to such a register.

First 32 bits contain the data information. The other 32 bits contain information about chip select, address, start and stop bit. All details about DCF and how it needs to be used can be found at the section "Device Configuration Format (DCF) Records" of the RM.

In SPC58NN84xx device, UTEST memory is located between 0x00400300 and 0x00400FFF.

i. This word also includes additional configuration.

Figure 6 shows an example of DCF sequence in order to start self-test in off-line mode. This sequence describes the starting of LBIST0 + all MBIST partitions of the device.

Figure 6. Sequence of DCF records in the UTEST

address	0	4	8	C	0123456789ABCDEF
SD:00400360	D3FEA98B	00080008	2C015674	00080008	FFFFFFFFFFFFFFFF
SD:00400370	04020032	00080010	005A0011	0008000C	EAUANNNN\$4Vx@NS
SD:00400380	FFFFFFFF	00080014	A5A5A5A5	00080028	0AUFUUUU\$4Vx@UX
SD:00400390	10014400	00080100	00001388	00080104	\$4Vx@N\$K\$4Vx@NL
SD:004003A0	59411F1D	00080110	C94CCCC9	00080114	\$4Vx@NS\$4Vx@NS
SD:004003B0	11800000	00080600	12800000	00080604	\$4Vx@NS\$4Vx@NS
SD:004003C0	13800000	00080608	14800000	0008060C	\$4Vx@NS\$4Vx@NS
SD:004003D0	15800000	00080610	16800000	00080614	\$4Vx@NS\$4Vx@NS
SD:004003E0	17800000	00080618	18800000	0008061C	\$4Vx@NS\$4Vx@NS
SD:004003F0	19800000	00080620	1A800000	00080624	\$4Vx@NS\$4Vx@NS
SD:00400400	1B800000	00080628	1C800000	0008062C	\$4Vx@NS\$4Vx@NS
SD:00400410	1D800000	00080630	1E800000	00080634	\$4Vx@NS\$4Vx@NS
SD:00400420	1F800000	00080638	20800000	0008063C	\$4Vx@NS\$4Vx@NS
SD:00400430	21800000	00080640	22800000	00080644	\$4Vx@NS\$4Vx@NS
SD:00400440	23800000	00080648	24800000	0008064C	\$4Vx@NS\$4Vx@NS
SD:00400450	25800000	00080650	26800000	00080654	\$4Vx@NS\$4Vx@NS
SD:00400460	27800000	00080658	28800000	0008065C	\$4Vx@NS\$4Vx@NS
SD:00400470	29800000	00080660	2A800000	00080664	\$4Vx@NS\$4Vx@NS
SD:00400480	2B800000	00080668	2C800000	0008066C	\$4Vx@NS\$4Vx@NS
SD:00400490	2D800000	00080670	2E800000	00080674	\$4Vx@NS\$4Vx@NS
SD:004004A0	2F800000	00080678	30800000	0008067C	\$4Vx@NS\$4Vx@NS
SD:004004B0	31800000	00080680	32800000	00080684	\$4Vx@NS\$4Vx@NS
SD:004004C0	33800000	00080688	34800000	0008068C	\$4Vx@NS\$4Vx@NS
SD:004004D0	35800000	00080690	36800000	00080694	\$4Vx@NS\$4Vx@NS
SD:004004E0	37800000	00080698	38800000	0008069C	\$4Vx@NS\$4Vx@NS
SD:004004F0	39800000	000806A0	3A800000	000806A4	\$4Vx@NS\$4Vx@NS
SD:00400500	3B800000	000806A8	3C800000	000806AC	\$4Vx@NS\$4Vx@NS
SD:00400510	2C015674	00080008	2C015674	00080008	\$4Vx@NS\$4Vx@NS
SD:00400520	3D800000	000806B0	3E800000	000806B4	\$4Vx@NS\$4Vx@NS
SD:00400530	3F800000	000806B8	40800000	000806BC	\$4Vx@NS\$4Vx@NS
SD:00400540	41800000	000806C0	42800000	000806C4	\$4Vx@NS\$4Vx@NS

Next paragraph describes a complete example of self-test that includes MBIST and LBIST tests.

4.3.1 Self-test in off-line mode

After unlocking the STCU, some important registers have to be configured in order to run the test.

Hereafter the most important:

- Watchdog timer (WDG): STCU_WDG register
It enables to check if the self-test operations (both LBIST and MBIST) have been completed within the assigned time slot or the STCU_RUN or BYPASS bits have been programmed before watchdog time-out. The datasheet reports the execution time of L/MBISTs.
The watchdog timeout must be higher than the sum of the execution times of all selected BISTs.

In order to estimate the execution time, user needs to consider that off-line self-test can be driven either by the IRCOSC or PLL0.

In case RCOSC is used, the only parameter to configure is related to STCU_CFG[CLK_CFG]. These bits define the ratio between the sys_clk and the TCK used to program both the LBIST and the MBIST and the STCU core clock.

- Fault mapping of the STCU faults: STCU_ERR_FM register.
It defines if a fault is considered either as unrecoverable or recoverable.
- Pointer to the first LBIST or MBIST should be scheduled: STCU_CFG[PTR].
The methodology of this test is to create a linked list where the starting pointer is the bit field STCU_CFG[PTR]. The additional pointers are in the bit field STCU_MB_CTRL[CSM] and STCU_LB_CTRL[CSM].
- Sequential or concurrent mode: STCU_MB_CTRL[CSM] and STCU_LB_CTRL[CSM].
These fields configure if the chosen set of the LBISTs or MBISTs run concurrently or sequentially. These fields are also used to close the linked list by setting the NIL pointer.
- LBIST pattern counter stop value: STCU_LB_PCS
- LBIST expected signatures: STCU_LB_MISREL and STCU_LB_MISREH.
These registers contain the expected signatures which are compared to the ones calculated by the STCU.
Evaluated signatures are saved in some STCU registers, such as STCU_LB_MISRRL and STCU_LB_MISRRH.
- Start STCU: STCU_RUN[RUN]
This is the software trigger which starts the L/MBIST execution.
As an example, please refer to the cmm file:
"lbist0_allMBIST_PLL100Mhz_parallel_PCS0x1388" which contains the Lauterbach's script showing a configuration to run the off-line self-test. 91 MBISTs and LBIST0 (that is like 0) run in parallel mode at 100 MHz, with 5000 (0x1388) number of patterns.
[Figure 6](#) shows these DCF saved in the UTest.
After LBIST execution an automatic functional reset is generated (see [Figure 5](#)).

5 On-line test

On-line self-test is performed during the application code execution and it is triggered by the software which configures and starts the L/MBISTs execution without involving the SSCM module.

5.1 Self-test flow

LBISTs and MBISTs are destructive and the state of tested modules is not recovered automatically by the hardware to the state before the test execution. A functional reset is performed after the on-line L/MBIST before going into operation again.

To enable the automatic generation of the functional reset after the execution of the on-line LBIST, the flag LBRMSWx of the STCU_LBRMSW reset management register needs to be set '1'.

STCU, which reports the results of L/MBISTs, is not affected by this functional reset. Then software can access such results by reading the STCU registers.

[Figure 7](#) reports an example of on-line self-tests of both LBISTs and MBISTs. The user can run these tests in inverse order (first MBISTs then LBISTs) or alternately to run only some MBISTs or to run only some LBISTs. The important point is not to forget to setup the functional reset after LBIST execution^(j).

Considering this example, after the MBIST execution, the RAM contains random data^(k) and a read access can trigger ECC events. Before starting executing application code, the RAM needs to be initialized^(l).

Before LBIST execution, it is necessary to initialize the RAM and to store in the NVM the MEMU information about MBIST results.


The logical flow is shown in [Figure 7](#).

j. By the STCU_LBRMSW register.

k. It means stack, heap and similar sections are destroyed by MBIST.

l. Initializing the RAM means to initialize the bit of the ECC checksum. It is done by writing the all RAM with 32bit/64bit access depending on the ECC implementation.

Figure 7. Self test flow in on-line mode



MBIST results can be interpreted reading both the STCU and the MEMU.

5.2 MEMU results

MBIST errors are collected by the MEMU module. MEMU implements multiple error tables used to collect memory errors coming from peripheral SRAM, flash memory and RAM.

MEMU saves more details about ECC errors than the ones reported by STCU (for example address, bit error and so on).

It can trigger an error to the FCCU.

The integrity of the MEMU is verified by LBIST3. For this reason it is suggested to perform the LBIST3 during off-line mode at boot time. When MEMU is LBISTed, it is not usable for MBIST failures during the off-line mode.

5.3 On-line configuration

First of all, it is necessary to enable the writing in the STCU module.

Afterwards the user unlocks the write protection to the STCU registers. The couple of keys used in on-line mode are:

- 0x753F_924Eh key1
- 0x8AC0_6DB1h key2

Similar setting used for the off-line self-test has to be followed in on-line mode.

After unlocking the STCU, some important registers have to be set in order to start up the test.

Below the most important:

- Watchdog timer (WDG): STCU_WDG.
It is used to check if the self-test operations (both LBIST and MBIST) have been completed within the assigned time slot or the STCU_RUN or BYPASS bits have been programmed before watchdog time-out.
- STCU operative frequency.
- Fault mapping of the STCU2 faults: STCU_ERR_FM. It defines unrecoverable or recoverable faults.
- Pointer to the first LBIST or MBIST to be scheduled: STCU_CFG[PTR].
The philosophy of this kind of test is to create a linked list where the starting pointer is the bit field STCU_CFG[PTR]. The additional pointers are in the bit field STCU_MB_CTRL[CSM]/STCU_LB_CTRL[CSM].
- Sequential or concurrent mode: STCU_MB_CTRL[CSM] and STCU_LB_CTRL[CSM].
These bit fields need to run concurrently or sequentially the chosen set of the LBIST or MBIST or to close the linked list setting the NIL pointer.
- LBIST pattern counter stop value: STCU_LB_PCS.
- LBIST expected signatures: STCU_LB_MISRELSW and STCU_LB_MISREHSW.
Considering [Figure 1](#) as reference, this couple of registers have to be compared with the signature (low and high) evaluated that is STCU_LB_MISRRLSW and STCU_LB_MISRRHSW. Consider that expected LBIST signatures in on-line mode are different from the ones used in off-line mode.
- Start STCU: STCU_RUNSW[RUN].

[Appendix A: FCCU reaction](#) reports a complete example on how to run MBIST and LBIST in on-line mode. It includes example code for the RAM initialization code and how to store the MBIST results in the NVM before a LBIST execution.

The flash section (NVM) used to store MBIST result is the DATA FLASH BLOCK of SPC58NN84xx.

As in any application code, some actions have been performed before the real self-test execution, including:

- MCU initialization (clocks, MPU, mode entry, cores, XBAR and so on...)
- FCCU initialization
- Flash unlocking
- STCU initialization

6 How to read STCU register results and possible reactions

The following sections show:

- The reaction scheme related to MBIST/LBIST executions
- The STCU registers to get the self-test results


These sections are valid for both on-line and off-line modes.

6.1 MBIST reaction

Figure 8 shows the MBIST reaction scheme. Two independent modules collect results of the MBISTs:

- STCU which gives a passed/not passed result for each MBIST
- MEMU which gives additional information related to possible ECC events (for example address of the faulty location)

Figure 8. MBIST reaction scheme



MEMU is able to report correctable (single bit error) and uncorrectable error detected via MBIST. Unique errors are stored in correctable and non-correctable section of the reporting table of the MEMU and corresponding indication is generated to the FCCU. FCCU collects all errors (in this case related to MBIST execution) and, if configured properly, can move the device into a safe state.

FCCU can react in multiple ways to a detected fault, for example interrupt, an external signal or a short/long functional reset.


Here the list of STCU register related to MBIST results:

- STCU_CRCR: this register reports the value obtained at the end of the off-line/on-line self-test. It can be used for diagnose and also as additional check with respect to the CRCS[SW] bit of the STCU_ERR_STAT register. This value has to be compared to STCU_CRCE register value. It is common to LBIST.
- STCU_ERR_STAT: this register includes the status flags related to the STCU internal Error conditions occurred during the configuration or the on/off-line self-testing execution. It is common to LBIST.
- STCU_MBSL / STCU_MBSLSW: it is a status register. It contains the result of MBIST off-line test. Each bit is associated to a single MBIST, that is bit0 with MBIST0, bit1 with MBIST1 and so on (up to 31).
- STCU_MBSM / STCU_MBSMSW: as above, from 32 to 63 bit.
- STCU_MBSH / STCU_MBSHSW: as above, from 64 to 95 bit.
- STCU_MBEL / STCU_MBELSW: it is an end-flag register (low register). Each bit has an MBIST associated and gives information about if it has been performed or not.
- STCU_MBEM / STCU_MBEMSW: it is an end-flag register (medium register).
- STCU_MBEH / STCU_MBEHSW: it is an end-flag register (high register).
- STCU_MBUFML: it defines the fault mapping, in terms of unrecoverable or recoverable fault, of the MBIST in the range NMCUT = 0...31.
- STCU_MBUFMM: it defines the fault mapping, in terms of unrecoverable or recoverable fault, of the MBIST in the range NMCUT = 32...63.
- STCU_MBUFMH: it defines the fault mapping, in terms of unrecoverable or recoverable fault, of the MBIST in the range NMCUT = 64...95.

6.2 LBIST reaction

Below LBIST reaction:

Figure 9. LBIST reaction scheme



STCU is directly connected to LBIST controller (associated to different lakes).

Any failure detected by the LBIST is reported to FCCU.

FCCU collects all errors (in this case related to LBIST execution) and, if configured properly, can move the device into a safe state.

FCCU can react in multiple ways to a detected fault, for example interrupt, an external signal or a short/long functional reset.

Here the list of STCU register related to LBIST results:

- STCU_CRCCR: it is common to MBIST.
- STCU_ERR_STAT: it is common to MBIST.
- STCU_LBS / STCU_LBSSW: it is a status register. It contains the result of LBIST off-line test. Each bit is associated to a single LBIST, that is bit0 with LBIST0, bit1 with LBIST1 and so on (up to 31).
- STCU_LBE / STCU_LBESW: it is an end-flag register (low register). Each bit has an LBIST associated and gives information about if it has been performed or not.
- STCU_LB_MISRRL / STCU_LB_MISRRLSW: it reports the LSB part of the MISR obtained at the end of the off-line LBIST controller execution. To be compared with the value expected contained in the STCU_LB_MISREL register.
- STCU_LB_MISRRH / STCU_LB_MISRRHSW: it reports the HSB part of the MISR obtained at the end of the off-line LBIST controller execution. To be compared with the value expected contained in the STCU_LB_MISREH register.

7 Summary

This document describes how to perform the L/MBISTs to SPC58NN84xx device.

SPC58NN84xx is composed by 7 LBIST partitions (for the logical part) and 92 MBIST partitions (for the volatile memory part).

Self-test can run both in on-line and in off-line mode using different configurations.

Described concepts can be easily reused for other ST devices.

In order to facilitate the execution of off-line and on-line self-test, some examples are available.

Appendix A FCCU reaction

This section gives some details on the FCCU behavior during, and after, the execution of the on-line LBIST with main focus on the error-out pins.

Before proceeding it is worth recalling the main points about FCCU and STCU activities during the execution on-line LBIST.

[Figure 3](#) shows the connections involved during the execution of the on-line self-test.

If the STCU detects a failure, the not critical fault #7, such as NCF[7], is triggered to the FCCU.

Independently of the result of the self-test, after the LBIST execution, a functional reset request is generated by the STCU^(m):

RMG and STCU are not impacted by this functional reset, but FCCU is. Hereafter the main default configurations of the FCCU⁽ⁿ⁾:

- NCF[7], that is the one related to the STCU, is disabled
- error-out pins are disabled, which means they are in high impedance state

Software enables the NCF[7] and error-out pins by configuring the proper register in the SIUL and in the FCCU.

Note: *Registers to be configured are:*

SIUL.MSCR

FCCU.EOUT_SIG_EN[x]

FCCU.NCFE = 0x0000_0080

Note: *It is assumed that, before the safety application starts, software:*

enables the NCF[7]

configures NCF[7]'s reaction to move the FCCU FSM to FAULT state

activates the error-out pins

FCCU is a flexible peripheral which configuration can be adapted to the specific user's needs. Other configuration may be assumed.

Hereafter two simplified flows about FCCU status during the LBIST execution:

- [Figure 10](#) assumes no fault is detected
- [Figure 11](#) assumes at least a fault is detected

[Figure 10](#) and [Figure 11](#) show 4 parameters:

- application phases are the phase of the running application
- FCCU FSM is the current status of the FCCU state machine
- ERROR OUT is the status of the error-out pins
- STCU is the message sent by the STCU to the FCCU

With reference to [Figure 10](#) it is described below the flow in case no fault is detected.

m. No functional reset is triggered after the MBIST execution.

n. This is the FCCU configuration after its reset.

1. Device goes out of reset (or POR).
FCCU is in its default state, that is NORMAL.
Error-out functionality has not been enabled yet and its pins are in Hi-Z.
2. Software configures the whole MCU including the SIUL and the FCCU.
During this phase the FCCU goes to CONFIG state and error-out pins remain in Hi-Z.
3. Safety function runs.
FCCU is in NORMAL state and error-out pins signal Normal phase.
4. STCU is configured to run one or more LBIST. FCCU and error-out pins are kept unchanged.
5. LBIST is executing.
Two cases can be differentiated depending whether LBIST #2, which includes the FCCU, is executed.
 - LBIST #2 is NOT executed
FCCU is in NORMAL state and error-out pins signal Normal phase
 - LBIST #2 is executed
Integrity of the FCCU is checked by the LBIST #2
FCCU state is not available while the LBIST runs. Error-out pins are in Hi-Z.
6. A functional reset is triggered by the STCU.
FCCU goes back to its default status as phase (1).
7. SIUL and FCCU are configured as in phase (2).
8. Safety function runs as in phase (3).

In case the LBIST detects a fault, the flow does not change till phase (5). With reference to

[Figure 11](#) only phases starting from (6) are replaced by the following:

9. A functional reset is triggered by the STCU.
Since the LBIST detects a fault, the STCU triggers the NCF[7] to the FCCU. FCCU goes back to its default status as phase (1).
Since by default the reaction to NCF[7] is disabled, FCCU remains in Normal state and error-out pins in Hi-Z.
10. SIUL and FCCU are configured and, depending on the fault management of the application, the STCU and FCCU can be cleaned.
11. Two different cases can be distinguished depending on the application fault management.
 - Status of STCU and FCCU is cleaned on phase (7).
FCCU is in NORMAL state, error-out pins signal Normal phase and STCU stops triggering NCF[7] to the FCCU.
 - Status of STCU and FCCU is not cleaned on phase (7).
As a result the FCCU goes to FAULT state and error-out pins start signaling the Error phase.
STCU keeps signaling the NCF[7] to the FCCU.

This is a basic example on how the FCCU, STCU and RGM work together during the on-line LBIST execution. Other configurations can be implemented, for example the FCCU may go into ALARM state and trigger an interrupt in case of fault detected by the LBIST instead of going directly to the FAULT state.

Figure 10. Behavior of the FCCU in case NO fault is detected by LBIST





Figure 11. Behavior of the FCCU in case at least a fault is detected by LBIST



Appendix B Reference code

This section describes the self-test algorithm in on-line mode applied on SPC58NN84xx.

LB1 to LB6 run in parallel mode at 50 MHz (provided by PLL1) plus all MBIST (from 0 to 91) in parallel mode at 50 MHz

The software used is:

- compiler: GHS version 6.1.4
- debugger: Lauterbach Trace32

```
void OnlineSelfTest(void)
{
    STCU_Init(0xFFFEFFFA); RUN_MBIST();
    RAM_initialization();
    writeMEMU_in_NVM(...); //store the MEMU context in the NVM
    STCU_Init(0xFFDDEEAA);
    RUN_LBIST();
}

/***** STCU_Init *****/
//! this is the STCU initialization. Here is defined how much the
watchdog window size.
//! 'window size' is the parameter used to defined it.
//! key1 and key2 are the keys used in on line mode to unlock the
STCU
/*!
\return void
*/

void STCU_Init(tU32 window_size)
{
    //unlock the Online STCU2 access writing the key1/key2
    STCU2.SKC.R = 0x753F924E; //key1
    STCU2.SKC.R = 0x8AC06DB1; //key2
    STCU2.WDG.R = window_size;
}

/***** RUN_MBIST *****/
//! Here is defined clock configuration and the list of MBIST to be
run.
//! They are 39 MIST, from 0 to 38 in parallel mode.
```

```
/*!  
\return void  
*/  
void RUN_MBIST(void)  
{  
    STCU2.CFG.R = 0x105A0010; // set Initial MBIST pointer - #16  
                                // PMOS bit set 1  
  
    STCU2.MB_CTRL[0].R = 0x11800000;  
    STCU2.MB_CTRL[1].R = 0x12800000;  
    STCU2.MB_CTRL[2].R = 0x13800000;  
    STCU2.MB_CTRL[3].R = 0x14800000;  
    STCU2.MB_CTRL[4].R = 0x15800000;  
    STCU2.MB_CTRL[5].R = 0x16800000;  
    STCU2.MB_CTRL[6].R = 0x17800000;  
    STCU2.MB_CTRL[7].R = 0x18800000;  
    STCU2.MB_CTRL[8].R = 0x19800000;  
    STCU2.MB_CTRL[9].R = 0x1A800000;  
    STCU2.MB_CTRL[10].R = 0x1B800000;  
    STCU2.MB_CTRL[11].R = 0x21800000;  
    STCU2.MB_CTRL[17].R = 0x22800000;  
    STCU2.MB_CTRL[18].R = 0x23800000;  
    STCU2.MB_CTRL[19].R = 0x24800000;  
    STCU2.MB_CTRL[20].R = 0x25800000;  
    STCU2.MB_CTRL[21].R = 0x26800000;  
    STCU2.MB_CTRL[22].R = 0x27800000;  
    STCU2.MB_CTRL[23].R = 0x28800000;  
    STCU2.MB_CTRL[24].R = 0x29800000;  
    STCU2.MB_CTRL[25].R = 0x2A800000;  
    STCU2.MB_CTRL[26].R = 0x2B800000;  
    STCU2.MB_CTRL[27].R = 0x2C800000;  
    STCU2.MB_CTRL[28].R = 0x2D800000;  
  
    STCU2.MB_CTRL[29].R = 0x2E800000;  
    STCU2.MB_CTRL[30].R = 0x2F800000;  
    STCU2.MB_CTRL[31].R = 0x30800000;  
  
    STCU2.MB_CTRL[32].R = 0x31800000;  
    STCU2.MB_CTRL[33].R = 0x32800000;  
    STCU2.MB_CTRL[34].R = 0x33800000;  
    STCU2.MB_CTRL[35].R = 0x34800000;  
    STCU2.MB_CTRL[36].R = 0x35800000;  
    STCU2.MB_CTRL[37].R = 0x36800000;  
    STCU2.MB_CTRL[38].R = 0x37800000;  
    STCU2.MB_CTRL[39].R = 0x38800000;  
    STCU2.MB_CTRL[40].R = 0x39800000;  
    STCU2.MB_CTRL[41].R = 0x3A800000;  
    STCU2.MB_CTRL[42].R = 0x3B800000;  
    STCU2.MB_CTRL[43].R = 0x3C800000;  
    STCU2.MB_CTRL[44].R = 0x3D800000;  
    STCU2.MB_CTRL[45].R = 0x1C800000;
```

```
STCU2.MB_CTRL[12].R = 0x1D800000;
STCU2.MB_CTRL[13].R = 0x1e800000;
STCU2.MB_CTRL[14].R = 0x1f800000;
STCU2.MB_CTRL[15].R = 0x20800000;
STCU2.MB_CTRL[16].R = 0x3E800000;

STCU2.MB_CTRL[46].R = 0x3F800000;
STCU2.MB_CTRL[47].R = 0x40800000;
STCU2.MB_CTRL[48].R = 0x41800000;
STCU2.MB_CTRL[49].R = 0x42800000;
STCU2.MB_CTRL[50].R = 0x43800000;
STCU2.MB_CTRL[51].R = 0x44800000;
STCU2.MB_CTRL[52].R = 0x45800000;
STCU2.MB_CTRL[53].R = 0x46800000;
STCU2.MB_CTRL[54].R = 0x47800000;
STCU2.MB_CTRL[55].R = 0x48800000;
STCU2.MB_CTRL[56].R = 0x49800000;
STCU2.MB_CTRL[57].R = 0x4A800000;
STCU2.MB_CTRL[58].R = 0x4B800000;
STCU2.MB_CTRL[59].R = 0x4C800000;
STCU2.MB_CTRL[60].R = 0x4D800000;
STCU2.MB_CTRL[61].R = 0x4E800000;
STCU2.MB_CTRL[62].R = 0x4F800000;
STCU2.MB_CTRL[63].R = 0x50800000;
STCU2.MB_CTRL[64].R = 0x51800000;
STCU2.MB_CTRL[65].R = 0x52800000;
STCU2.MB_CTRL[66].R = 0x53800000;
STCU2.MB_CTRL[67].R = 0x54800000;
STCU2.MB_CTRL[68].R = 0x55800000;
STCU2.MB_CTRL[69].R = 0x56800000;
STCU2.MB_CTRL[70].R = 0x57800000;
STCU2.MB_CTRL[71].R = 0x58800000;
STCU2.MB_CTRL[72].R = 0x59800000;
STCU2.MB_CTRL[74].R = 0x5B800000;
STCU2.MB_CTRL[75].R = 0x5C800000;
STCU2.MB_CTRL[76].R = 0x5D800000;
STCU2.MB_CTRL[77].R = 0x5E800000;
```

```
STCU2.MB_CTRL[78].R = 0x5F800000;
STCU2.MB_CTRL[79].R = 0x60800000;
STCU2.MB_CTRL[80].R = 0x61800000;
STCU2.MB_CTRL[81].R = 0x62800000;
STCU2.MB_CTRL[82].R = 0x63800000;
STCU2.MB_CTRL[83].R = 0x64800000;
STCU2.MB_CTRL[84].R = 0x65800000;
STCU2.MB_CTRL[85].R = 0x66800000;
STCU2.MB_CTRL[86].R = 0x67800000;
STCU2.MB_CTRL[87].R = 0x68800000;
STCU2.MB_CTRL[88].R = 0x69800000;
STCU2.MB_CTRL[89].R = 0x6A800000;
STCU2.MB_CTRL[90].R = 0x6B800000;
STCU2.MB_CTRL[91].R = 0xFF000000;
STCU2.RUNSW.R = 0x00000001;

/***** RAM_initialization *****/
//! After the MBIST test the RAM contains random data. Before
LBIST execution, it's necessary to initialize the RAM
/*!
\return void
*/
void RAM_initialization(void)
{
    #pragma asm
    //*****
    // Skip normal entry point as nothing is initialized*
    //*****
    .globl _init_ram
    .vle
    _init_ram:
        e_lis r5, 0x0000
        e_or2i r5, 0x0200
```

```
        mtctr r5; /* Move to counter for use with "bdnz" */
    /*# Base Address of the Local SRAM

    e_lis r5, 0x4000;
    e_or2i r5, 0x0000;

    /*# Fill Local SRAM with writes of 32GPRs
    sram_init_loop;;
        e_stmw r0,0(r5); /* Write all 32 registers to SRAM */
        e_addi r5,r5,128; /* Increment the RAM pointer to next 128bytes
*/
        e_bdnz sram_init_loop; /* Loop for all of SRAM */

    #pragma endasm
}

/***** RUN_LBIST *****/
//! Here is defined clock configuration and the list of LBIST to
    be run.
//!
\return void
*/
void RUN_LBIST(void) {
    STCU2.CFG.R = 0x015A0010;
    STCU2.LB[1].CTRL.R = 0x02804400;
    STCU2.LB[1].PCS.R = 0x137E; /*4990*/
    STCU2.LB[1].LB_PRPGL.R = 0xFFFFFFFF;
    STCU2.LB[1].MISRELSW.R = 0xdaf5582b;
    STCU2.LB[1].MISREHSW.R = 0x3b2e32fa;

    STCU2.LB[2].CTRL.R = 0x03804400;
    STCU2.LB[2].PCS.R = 0x137E; /*4990*/
    STCU2.LB[2].LB_PRPGL.R = 0xFFFFFFFF;
    STCU2.LB[2].MISRELSW.R = 0x41e3fa5d;
    STCU2.LB[2].MISREHSW.R = 0xad475ea0;
```



```
STCU2.LB[3].CTRL.R = 0x04804400;
STCU2.LB[3].PCS.R = 0x137E; /*4990*/
STCU2.LB[3].LB_PRPGL.R = 0xFFFFFFFF;
STCU2.LB[3].MISRELSW.R = 0x1DF4D30E;
STCU2.LB[3].MISREHSW.R = 0xFFFB7696;

STCU2.LB[4].CTRL.R = 0x05804400;
STCU2.LB[4].PCS.R = 0x137E; /*4990*/
STCU2.LB[4].LB_PRPGL.R = 0xFFFFFFFF;
STCU2.LB[4].MISRELSW.R = 0x2f07f39c;
STCU2.LB[4].MISREHSW.R = 0xaf9195ce;

STCU2.LB[5].CTRL.R = 0x06804400;
STCU2.LB[5].PCS.R = 0x137E; /*4990*/
STCU2.LB[5].LB_PRPGL.R = 0xFFFFFFFF;
STCU2.LB[5].MISRELSW.R = 0xae48deec;
STCU2.LB[5].MISREHSW.R = 0xa446dd7c;

STCU2.LB[6].CTRL.R = 0xFF004400;
STCU2.LB[6].PCS.R = 0xE3D; /*3645*/
STCU2.LB[6].LB_PRPGL.R = 0xFFFFFFFF;
STCU2.LB[6].MISRELSW.R = 0xB4002B88;
STCU2.LB[6].MISREHSW.R = 0x4EA80A8E;

STCU2_LBRMSW = 0x0000007E;
STCU2_RUNSW.R = 0x00000101;
}
```

Appendix C Other informations

C.1 Document reference

- *SPC58xNx 32-bit Power Architecture® microcontroller for automotive ASILD applications* (RM0421, DocID028528, Rev3).

C.2 Acronyms

Table 5. Acronyms

Acronyms	Meaning
DCF	Device Configuration Format (DCF) Records
UTest	User Test flash block
STCU	Self-Test Control Unit
SSCM	System Status and Configuration Module
RGM	Reset Generation Module
FCCU	Fault Collection and Control Unit

Revision history

Table 6. Document revision history

Date	Revision	Changes
26-Jun-2017	1	Initial release.
28-Mar-2019	2	Updated Section 1.3: Modules used in self-test phase : given more details about MBPllen/LBPllen and MBSWPlLen/LBSWPlLen flag of the STCU_RUN register. Updated Section 1.5: Clock configurations of self-test : added detail about how the clock works during reset phase and STCU core clock setting.
03-Jun-2020	3	Updated Table 3: MBIST partition . Updated Table 4: LBIST partition

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics – All rights reserved