

STM32 standard peripheral library to STM32Cube low-layer API migration tool

Data brief

Features

- Step-by-step user source code migration status is displayed
- Free user-friendly license terms
- C code generation covering all STM32 series, compliant with IAR™, Keil™ and GCC compilers
- Available as standalone software running on Windows®, Linux® and macOS® operating systems (macOS® is a trademark of Apple Inc., registered in the U.S. and other countries)


Description

The STM32 portfolio is continuously growing with a variety of solutions available to developers, notably STM32Cube low-layer (LL) drivers, for balancing cost, power, and performance.

It is important that designers of STM32 microcontroller applications can easily upgrade their microcontroller type as well as their firmware solution. Additionally, since the standard peripheral library is not delivered for the most recent STM32 series, the SPL2LL-Converter migration tool is essential to the harmonization of existing applications with the range of new embedded product features and the ecosystem evolution.

The STM32 standard peripheral library (SPL) to STM32Cube low-layer API migration tool is designed to help developers to easily migrate their source code based on STM32 SPL drivers to any other STM32 series supporting STM32Cube low-layer drivers. It ensures full migration within a given STM32 series and partial migration across STM32 series. The migration is possible only for STM32 peripherals covered by STM32Cube LL drivers.

SPL2LL-Converter is a script that manages the migration of user source code provided that it



complies with some defined C-coding rules such as no alias, no call to API as parameter, or single operation on interrupt and flags.

SPL2LL-Converter comes with a GUI. This graphical software configuration tool allows the script to be executed without using a shell command.

As a first step, the user selects the STM32 source and destination series.

The user then selects the input path for source files based on SPL drivers and the output path for the storage of source files based on STM32Cube LL drivers.

Finally, the user launches the source code migration based on the selected configuration. The user application project needs to be created or updated on the basis of the migrated code.



Ordering information

SPL2LL-Converter is available for free download from the www.st.com website.

Revision history

Table 1. Document revision history

Date	Revision	Changes
04-Jul-2017	1	Initial release.

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2017 STMicroelectronics – All rights reserved