



VL53L0X Quick Start Guide

Version 1.1



Version	Date	Comments
1.0	6 June 2016	Initial
1.1	24 June 2016	SW Pre-requisites slide moved before SW deliverables description



A color code is used in the document for each component of the eco-system

VL53L0X GUI
User Manual - Embedded

X-CUBE-53L0A1 (STM32Cube)
User Manual – UM2046


X-NUCLEO-53L0A1 (HW)
User Manual – UM2047

Documentation



VL53L0X Eval GUI - STSW-IMG006
Get ranging live curves on your PC
Change key settings of the device
Data logging capabilities

STSW-LINK009
STSW-LINK007




X-CUBE-53L0A1 package
Full integration in STM32 MCU (real-time)
All source code provided
Full access to product settings
Data logging capabilities
Ranging and Gesture detection demo



Hardware
P-NUCLEO-53L0A1
X-NUCLEO-53L0A1

VL53L0X API User Manual - UM2039




VL53L0X C API package – STSW-IMG005
Discover API Source code

VL53L0X Datasheet – DS11555
VL53L0X Quick Start Guide
Applications Notes



VL53L0X : Miniature ToF Ranging & Gesture Sensor



As for all X-NUCLEO boards, **LINK007** and **LINK009** STM32 software are accessible from P-NUCLEO-53L0A1 and X-NUCLEO-53L0A1 web pages

VL53L0X eco-system glossary & links

Name	Definition	Links
VL53L0X	ST's FlightSense Time-of-Flight ranging and gesture detection sensor	<ul style="list-style-type: none">• Search for vl53l0x on st.com to go to the product main page.
VL53L0X Quick Start Guide	This document	<ul style="list-style-type: none">• Search for VL53L0X Quick Start Guide on st.com
VL53L0X Datasheet	VL53L0X product datasheet	<ul style="list-style-type: none">• Search for DS11555 on st.com
VL53L0X API	Set of C functions to control VL53L0X and get ranging data	<ul style="list-style-type: none">• Search for STSW-IMG005 on st.com
VL53L0X API User Manual	Document describing VL53L0X API in details	<ul style="list-style-type: none">• Search for UM2039 on st.com

VL53L0X eco-system glossary & links

Name	Definition	Links
NUCLEO (F401 or L476)	STM32-based board which can be combined with an expansion board for evaluation purpose	<ul style="list-style-type: none">• Search for nucleo on st.com
X-NUCLEO-53L0A1	Nucleo expansion board with VL53L0X sensor plus optional VL53L0X satellites	<ul style="list-style-type: none">• Search for X-NUCLEO-53L0A1 on st.com
P-NUCLEO-53L0A1	Hardware pack composed of the X-NUCLEO-53L0A1 expansion board plus one STM32 F401Nucleo board, and 2x VL53L0X satellites	<ul style="list-style-type: none">• Search for P-NUCLEO-53L0A1 on st.com
X-CUBE-53L0A1	Software package containing source code for P-NUCLEO-53L0A1 hardware	<ul style="list-style-type: none">• Search for X-CUBE-53L0A1 on st.com
X-CUBE-53L0A1 User Manual	X-CUBE package detailed documentation	<ul style="list-style-type: none">• Search for UM2046 on st.com
VL53L0X Eval GUI	PC Graphical User Interface to display ranging data from VL53L0X	<ul style="list-style-type: none">• Search for STSW-IMG006 on st.com
VL53L0X GUI User Manual	PC GUI detailed documentation	<ul style="list-style-type: none">• Install the GUI and open the embedded documentation
STSW-LINK009	PC driver to enable Virtual Com Port with Nucleo board (used for data logging, GUI)	<ul style="list-style-type: none">• Search for STSW-LINK009 on st.com
STSW-LINK007	Nucleo STLINK FW upgrade to get best speed performances through Virtual Com Port	<ul style="list-style-type: none">• Search for STSW-LINK007 on st.com


Evaluation tools HW description

- VL53L0X Evaluation tools are based on following hardware elements:
 1. STM32 F401RE Nucleo board
 2. X-NUCLEO-53L0A1 Nucleo Expansion board, which includes:
 - Two VL53L0X satellites
 - One cover glass and 3x spacers with different heights
- Search for ***P-NUCLEO-53L0A1*** on st.com to order the full pack (1+2)
- or search for ***X-NUCLEO-53L0A1*** to get only the Nucleo expansion board (2)
- Hardware documentation (schematics) also available on st.com



Removing the protective liner on the sensor


- When using the VL53L0X sensor, or the X-NUCLEO expansion board, remove the liner before use !
- Don't touch too much the sensor with fingers




SW pre-requisites : to be done once

- API examples, X-CUBE data logging and GUI communicate with Nucleo through Serial com over USB (Virtual Com Port). Following SW packages must be installed
 - STSW-LINK009 : PC USB driver
 - STSW-LINK007 : Nucleo ST-LINK FW upgrade
- Connect the Nucleo pack to the PC through USB
 - Wait for the board to be recognized as a mass storage device (some drivers will be installed automatically)

- Install ST-Link Virtual Com port drivers on the PC (**STSW-LINK009**)
 - Search for STSW-LINK009 on st.com, download, unzip
 - Launch stlink_winusb_install.bat



- Upgrade ST-Link FW on the Nucleo board to get the latest version and benefit from best performances for UART over USB transfers (**STSW-LINK007**)
 - Search for STSW-LINK007 on st.com, download, unzip
 - Connect Nucleo board to the PC through USB



• Launch ST-LinkUpgrade.exe, press Device Connect, then Yes

VL53L0X API : Purpose

10

- Small SW package containing VL53L0X API source code and few basic examples than can be run on the PC connected with Nucleo hardware pack (P-NUCLEO-53L0A1)
- Starting from this software package, user can:
 - Discover VL53L0X API (browse the code, read Doxygen documentation)
 - Run simple .exe programs on the PC to do ranging from VL53L0X
- Related documentation:
 - VL53L0X API User Manual
- Download from st.com searching for **STSW-IMG005**

X-CUBE-53L0A1 : Purpose

- Give a full example of how VL53L0X device is integrated into a MCU sub-system taking benefit from the STM32 Open Development Environment
- Starting from this software package, user can:
 - Run Ranging and Gesture detection demos with a simple drag & drop
 - Get basic data logging on PC through Virtual Com Port (Teraterm, Putty, etc...) to collect data or build simple PC GUIs
 - Import a project in his favorite IDE (Keil, IAR or STM32 Workbench) to browse the code, (re) compile, (re)flash Nucleo and debug (breakpoints, step into the code, etc...)
 - Understand how VL53L0X API has been ported on Nucleo
 - Get a working and real-time example of interrupt-based ranging mode
 - Modify the project code to change VL53L0X settings for the targeted application
- Related Documentation
 - X-CUBE-53L0A1 User Manual (UM2046)
- Download from st.com searching for **X-CUBE-53L0A1**

VL53L0X GUI : Purpose

- PC Graphical User Interface which allows to:
 - Display (in live) key ranging data (distance, signal rate)
 - Change key parameters of VL53L0X
 - Perform calibration phases (offset and xTalk with cover glass)
 - Get data logging (.csv file)
- GUI is running on the PC connected to a P-NUCLEO-53L0A1 pack
 - VL53L0X API running on the PC side
 - Run simple .exe programs on the PC to do ranging from VL53L0X
- Related Documentation
 - User Manual embedded in the tool (See the About tab)
- Download from st.com searching for **STSW-IMG006**
 - Run the installer with Admin privileges or change default installation directory