
L9963 14 Cells BMC IC Evaluation Board Quick Guide

Introduction

This document is intended as quick guide to help the user in the startup phase of EVAL-L9963-MCU combining and summarizing the information contained in EVAL-L9963-MCU and STSW-L9963 user manuals.

1 What you need

- EVAL-L9963-MCU
- USB cable
- Power supply (at least 3 output 0 – 30 V (if possible 60V):
 - 1 output to power L9963 (0:60 V)
 - 1 output to simulate Cells common mode voltage (0:60 V)
 - 1 output to simulate Cell voltage (0:5 V)
- L9963 evaluation GUI STSW-L9963
- NI Labview-runtime 2014
- NI VISA-RUNTIME

Note: Before using the UART/USB bridge FT232RL, the Virtual Com Port (VCP D2XX) driver needs to be installed. It can be downloaded by the FTDI Chip website.

Figure 1. EVAL-L9963-MCU board





Figure 2. EVAL-L9963-NDS board



2 Board description

Figure 3. Main components and connectors




Note:

1. EVAL-L9963-MCU can be considered the only stage or the first stage of several stages. The port is the isolated vertical interface to the next stage (EVAL-L9963-NDS);
2. A second L9963T (optional) may be needed to create a direct loop with the last stage (dual ring access);
3. MCU can be supplied either by USB or by L9001 (PMIC);
4. On board MCU can be bypassed in case a different MCU is needed for the user trials; these pins allow an SPI connection with an external MCU (upon a specific board configuration). Anyway a specific board derivative of EVAL-L9963-MCU has been designed for this purpose (same form factor/layout with MCU not mounted: EVAL- L9963).


3 Block diagram

Figure 4. EVAL-L9963-MCU block diagram




4 Microcontroller Power supply

Figure 5. Microcontroller Power supply




5 L9963 external connection and power supply



Figure 6. L9963 external connection and power supply


6 Transceiver settings

Figure 7. Transceiver settings



7 Possible connection for battery simulation

Figure 8. Battery simulation 1

Figure 9. Battery simulation 2


8 Preliminary action to open the GUI


Install the following SW on your PC:

- NI Labview-runtime 2014
- NI VISA-RUNTIME
- FTDI driver
 - Before using the UART/USB bridge FT2232H, the Virtual Com Port (VCP) driver needs to be installed. It can be downloaded by the FTDI Chip website.

When all is installed reboot your PC and open STSW-L9963.exe

9 USB to PC connection


Figure 10. USB to PC connection



10 Device Manager appearance

If FTDI Virtual COM PORT (VCP D2XX) driver has been correctly installed, you will find in Windows Device manager a USB serial port under Ports (COM&LPT). Take note of the COM port number (i.e. COM13).

Figure 11. Windows Device Manger COM port number




11 GUI usage and setup

11.1 Connection

Steps:

1. Select COM port according to your device manager. The COM led will become green;
2. Press on “get firmware version” button to check the communication with uC and the firmware version. The version should be 1.5;
3. In the “ID assignment” text box write 1 because you are using 1 L9963 then press “Configure IDs Button”, ACK LED will become green. If D13 LED on the board was switched OFF it will be switched ON and will not switch OFF anymore.

Figure 12. GUI connection



11.2 Threshold configuration

Steps:

1. Select Cell overvoltage and undervoltage. i.e. UV 2.8 V and OV 4.250 V;
2. The VCELL_THRESH_UV_OV register will be automatically updated;
3. Select Dev ID 1;
4. Select Write;
5. Press on “Single write/read” button;
6. If communication with L9963 is ok the ACK LED will become green.

Figure 13. Threshold configuration 1

The screenshot shows the 'Automotive' diagnostic tool interface for L9963. The main configuration area is divided into several sections:


- GPIO Thresholds:** A grid of 14 fields for GPIO3_OT_TH through GPIO9_UT_TH, all set to 0.000.
- Cell Voltage Thresholds:**
 - threshVcellOV:** Set to 4.250 (highlighted with a red box and labeled '1').
 - threshVcellUV:** Set to 2.800 (highlighted with a red box and labeled '1').
 - VBATT_SUM_OV_TH:** Set to 59.500.
 - VBATT_SUM_UV_TH:** Set to 59.200.
 - CSA_THRESH_NORM (mV):** Set to 0.0000000.
 - ADC_FILTER_SOC:** Set to 290 us.
 - adc_cwr_curr_threshold_sleep (mV):** Set to 0.0000000.
- Configuration Registers:**
 - VCELL_THRESH_UV_OV:** The register address field is highlighted with a red box and labeled '2'.
 - Write:** The 'Write' dropdown menu is highlighted with a red box and labeled '3'.
 - Dev ID:** The 'Dev ID' dropdown menu is set to '1' and highlighted with a red box and labeled '3'.
 - Single write/read:** The 'Single write/read' button is highlighted with a red box and labeled '5'.
- ACK LED:** The 'COM ACK' LED is highlighted with a red box and labeled '6', indicating a successful communication.

Other visible elements include PCB open wire diagnostic LEDs (C0-C14), various diagnostic checkboxes (e.g., GPIO_CONV, CELL_TERM_CONV, SOC, HWSC), and a bottom status bar with 'Configure device' and 'ACK' indicators.

Steps:

1. Select Battery overvoltage and undervoltage. i.e. UV 39.2 V and OV 59.5 V;
2. The VBATT_SUM_TH register will be automatically updated;
3. Select Dev ID 1;
4. Select Write;
5. Press on “Single write/read” button;
6. If communication with L9963 is ok the ACK LED will become green.

Figure 14. Threshold configuration 2



11.3 Measure enabling

Steps:

1. Select cell voltage gauge with the EN check box. At least Cells 1, 2, 13, 14 must be selected;
2. The VCELLS_EN register will be automatically updated;
3. Select Dev ID 1;
4. Select Write;
5. Press on “Single write/read” button;
6. If communication with L9963 it's ok the ACK LED will become green.

Figure 15. Measure enabling

The screenshot displays the L9963 evaluation GUI with the following elements:


- Cell Voltage Gauges:** A 4x4 grid of gauges for cells 1-14. Each gauge has an 'EN' checkbox. Cells 1, 2, 13, and 14 are selected.
- Configuration Panel (Right):** Shows the 'VCELLS_EN' register being updated. The 'Write' button is selected, and 'Dev ID 1' is chosen.
- Status Bar (Bottom):** The 'ACK' LED is green, indicating successful communication.

11.4 Measure starting

Steps:


1. Select time interval. i.e. 100 ms. This is the refresh rate of GUI measurement;
2. Press on “Time interval” button to apply setting. ACK LED will become green;
3. Check Diagnostic checkbox to start measurement.

Figure 16. Measure starting



11.5 Alternative measure setting

Figure 17. Alternative measure setting



Selecting Chart, the voltage will be plotted on a time diagram

11.6 Measurements example

Figure 18. Setup






Figure 19. Results



11.7 Diagnostic

All the diagnostics are available in the Diagnostic-Information tab. They are updated at the same rate as measurement.

Figure 20. Diagnostic



Appendix A Reference documents

Table 1. Reference documents

Doc Name	ID	Title
UM2698	034111	EVAL-L9963-MCU Evaluation Board
UM2734	034356	L9963 evaluation graphical user interface

Revision history

Table 2. Document revision history

Date	Version	Changes
15-Sep-2020	1	Initial release.
17-Nov-2020	2	Updated Title in cover page.

Contents

1	What you need	2
2	Board description	3
3	Block diagram	4
4	Microcontroller Power supply	5
5	L9963 external connection and power supply	6
6	Transceiver settings	7
7	Possible connection for battery simulation	8
8	Preliminary action to open the GUI	9
9	USB to PC connection	10
10	Device Manager appearance	11
11	GUI usage and setup	12
11.1	Connection	12
11.2	Threshold configuration	13
11.3	Measure enabling	15
11.4	Measure starting	16
11.5	Alternative measure setting	17
11.6	Measurements example	18
11.7	Diagnostic	19
Appendix A	Reference documents	20
	Revision history	21

List of tables

Table 1.	Reference documents	20
Table 2.	Document revision history	21

List of figures

Figure 1.	EVAL-L9963-MCU board	2
Figure 2.	EVAL-L9963-NDS board	2
Figure 3.	Main components and connectors	3
Figure 4.	EVAL-L9963-MCU block diagram	4
Figure 5.	Microcontroller Power supply	5
Figure 6.	L9963 external connection and power supply	6
Figure 7.	Transceiver settings	7
Figure 8.	Battery simulation 1	8
Figure 9.	Battery simulation 2	8
Figure 10.	USB to PC connection	10
Figure 11.	Windows Device Manger COM port number	11
Figure 12.	GUI connection	12
Figure 13.	Threshold configuration 1	13
Figure 14.	Threshold configuration 2	14
Figure 15.	Measure enabling	15
Figure 16.	Measure starting	16
Figure 17.	Alternative measure setting	17
Figure 18.	Setup	18
Figure 19.	Results	18
Figure 20.	Diagnostic	19

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics – All rights reserved